PS127 Quickguide color: CMYK size: 148mmW x 210mm

FC 🗹 🖒 🗵



Quick Start Guide

FCC Authentication

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (9) this device man coupt any interference neceived, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could vide the user's authority to operate the equipment.

for compliance could void the user's authority to operate the sequipment. MOTE: This equipment has been tested and found to comply with the finite for a Class B digital device, pursuant to Part 15 of the PCC Ruber. These initials are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, use and can radder and for feequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference oul indicates the instructions. If the equipment dose cause harmful occur is a particular installation. If the equipment dose cause harmful occur is a particular installation. If the equipment dose cause harmful occur is a particular installation. If the equipment dose cause harmful occur is a particular installation. If the equipment dose cause harmful occur is a particular installation. If the equipment dose cause harmful occur is a particular installation. If the equipment dose cause harmful occur is a particular installation. If the equipment dose cause harmful occur is a particular installation of the community of the com

Overview of Your Cruz PS127





Using Wi-Fi

From the Home Screen, select the Wi-Fi Settings shortcut icon, and ensure that both Wi-Fi and Network Notification are enabled with green check marks.

green check marks.

After a moment, your Wi-Fi networks list should populate.

Tap the network you wish to connect to and then click Connect. The Wi-Fi icon should now appear next to the date and time.

Turn Wi-Fi off to save power

When you are not using Wi-Fi, turn it off via the Settings Menu, to save battery power

Set up: turning on your Cruz PS127 for 1st. time

Watch a Quick Video
 The first time you turn on your Cruz PS127, there is a brief video to help you with the set-up and registration process of your Cruz PS127.

you with the set-up and registration process of your Cruz PS127.

2. Read and Accept the Terms of Service
When the video has finished, your Cruz PS127 displays its Terms of
Service. Read the terms. To accept them, tap Accept
3. Select your Time Zone
Tap on your time zone (for example, Eastern Standard Time). Then tap Next.

About your Cruz PS127

Cruz PS127 is a multi-task, touch screen device providing unlimited

possibilities.

Cruz through ebooks, videos, games, and the Web. With its user friendly
AndroidTM interface, your Cruz PS127 contains all the functions you need
for home or on the move. Explore this quick user guide to learn more.

Benefits of using Cruz PS127

The Cruz PS127 in a portable, high performance touch screen device running the Audroid™ 2.1 interface. Lightweight and slim, the Cruz PS127 is the perfect tool to streamline your operations for business, family and entertainment.

entertainment.

The Cruz PS1312 has full Web browser support and provides a richer experience than traditional Exotor readers. You can enjoy orline shopping, movies, social medica and E-books. The builds he E-book Brary portal application allows you to access over 700,000 in store publications. Plan, you will find an open portal for developmenting psp., magazines, and videos from a broad array of content providers. You can store photos, videos and formed airs of 30 cross from a broad array of content providers. Thou can store photos, videos and formed airs of 30 cross from a broad array of content providers. Thou can store photos, videos and formed airs of 30 cross, and will be plot 10 most builty life, you can enjoy the providers of the provid

Apps on Your Cruz PS127

Your Cruz PS127 comes with a suite of pre-installed apps, including:

Your Cruz PS127 comes with a suite of pre-installed apps, recluding: Anton - your file management application, one spot access to an enormous world of literature in electronic form. From classics to contemporary writing, find it all coline to enjoy at your leasure. CruzMarket - Firid applications apecally selected for the Cruz PS127. Many of them set Psi.

seally or liefling at their.

FaceBook Mobile – Log into your Facebook account.

Gallery – Access photo or video files for play or display.

Office Suite – Allows you to view Microsoft® Office files.

Learn More
Please read the User Guide for comprehensive information on the Cruz
PS127. You'll find a copy in the library of the Cruz PS127, and you can
download a copy to your PC from www.cruzreader.com.

Accessories supplied with your Cruz PS127

A Power Adapter and a USB Cable are provided with your Cruz PS127 Before the first time it is used with only battery power, your Cruz PS127 must be fully charged. Plug it into a wall outlet using the Power Adapter and the USB Cable.

The Charging LED by the on/off button will glow red when charging, green when charged. This LED only lights up when the Cruz PS127 is connected to mains nower.

. Fully charging your Cruz should take around 3 hours. You can use it whilst charging.



Email set up

Seeding Email

• Tap the Email con.

• Type a name or email address in the To field.

• Type a name or email address in the To field.


• Type a name or email address in the To field.

• Type Caption of you want to copy the message to others, or change the account you send the message from. If you have more than one email account, you can tap the From field to change the account you're sending to.

• Effert a subject, then your message.

• Tap Send.

5 Your Home Screen



6

The Touch Screen



