



		File NO:
MODEL: Q013		Drawing NO:
TITLE:		STANDARD:
scн: V0.2	PCB: VO.2	CHECK:
DESIGN:		APPROVE:

## BASEBAND-POWER




## Check, Trace 4mil is enough





Buck	VCORE	1.2	200	,
RF LDO	VRF	2.8	200	
	VTCXO	2.8	20	
Analog	VA	2.8	12.5	
LDO	VCAM_A	1.5/1.8/2.5/2.8	150	
	VM	1.8/2.8	200	VM_SEL
	VIO	2.8	100	
Digital	VSIM	1.8/3.0	100	
LDO	VUSB	3.3	100	
	VBT	1.3/1.5/1.8/2.5/2.8/3.0/3.3	100	
	VCAM_D	1.3/1.5/1.8/2.5/2.8/3.0/3.3	100	
	VSIM2	1.3/1.5/1.8/2.5/2.8/3.0/3.3	100	
Vibrator	VIBR	1.8/3.0	200	
RTC	VBACKUP	2.8	2	
Boost Converter	VB00ST1	3.4~5.5	100	


LZ0701 DELETE GOLD-BATTERY: DELETE DUAL-DIODE DESIGN;

LZ0701 change L203 tobe 0603 package; LZ0716 ADD R208 OR FOR MOTOR; delete D203 add L214;













		File NO:
MODEL: Q013		Drawing NO:
TITLE:		STANDARD:
scн: V0.2	PCB: V0.2	CHECK:
DESIGN:		APPROVE:







		File NO:	
MODEL: Q013		Drawing NO:	
TITLE:		STANDARD:	
sch: V0.2	PCB: V0.2	CHECK:	
DESIGN:		APPROVE:	









		File NO:
MODEL: Q013		Drawing NO:
TITLE:		STANDARD:
scн: V0.2	PCB: V0.2	CHECK:
DESIGN:		APPROVE:










		File NO:
MODEL: Q013		Drawing NO:
TITLE:		STANDARD:
scн: V0.2	PCB: V0.2	CHECK:
DESIGN:		APPROVE:










		File NO:
MODEL: Q013		Drawing NO:
TITLE:		STANDARD:
scн: V0.2	PCB: V0.2	CHECK:
DESIGN:		APPROVE:











		File NO:
MODEL: Q013		Drawing NO:
TITLE:		STANDARD:
sch: V0.2	PCB: VO.2	CHECK:
DESIGN:		APPROVE:

