


## 1.5 User Manual



Speaker

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by Fish Phonics responsible for compliance could void the user's authority to operate the equipment.





## HOW TO ...

CHARGE YOUR BATTERY first over right using the USB charge cord provided. It has a normal USB connector for your computer and a standard Micro USB connection. You should get 3 hours of last kime and 150 hours standby time. A red indicator light appears when charging and will turn blue when fully charged.

PAIR EARZEE TO YOUR PHONE, first find the Bluetooth search button on your phone. Most smart phones these days support Bluetooth devices. Check your manual. Next press the on/off switch on Earzee until the light sequence blinks red, blue, red, blue continuously. It is now looking for your phone. Press the search button on your phone to find new audio device. Phone will ask you to accept paining to FISH 20. Upon acceptance you are now paired. A slow blue blinking light will appear on your phone when Earzee is in standby mode.

MAKE A CALL on your Stretch Earzee simply dial on your phone the number required. A fast blue blinking light will show when connecting. No need to press any buttons. Stretch speaker up between fingers and hold in usual hand held position to talk. To end a call we suggest you press the on off switch once otherwise if your receiver doesn't hang up properly you might still be connected. ANSWER A CALL on your Stretch Earzee, there is no need to touch your phone. A vibration will be felt on your wrist when a caller wants to speak to you. Answer by pressing the side button ONCE, and stretch speaker up between fingers to talk in the usual hand held position. You will never miss a call again. It's Earzee. If you check your phone and don't wish to speak to a caller, press button twice.

TURN OFF YOUR EARZEE, press button until red light appears

RECONNECT YOUR EARZEE, most phones will remember your preferred Bluetooth devices. When Fish 20 is selected it will automatically find you again without paining operation again. If you move too far away from your phone you may be disconnected and have to connect again.

QUICK REDIAL a previous caller by pressing the button on your Earzee, twice quickly.

Other important information can be found on our web site

www.fishphonics.com or www.earzee.co.uk



Care and Warranty  Your Stretch Earzee has been prepared by skilled workers that pride themselves in workmanship. Included on this card is a tracking code and 12 months warranty. To commence your warranty please complete this card and post within one month of purchase. If any reasonable manufacturing fault is found we will replace item at our discretion.  Your Stretch Earzee is not water proof. Please take care when washing your hands or doing the dishes. Lithium battery life will be limited if you do not charge over night the first time.	Tracking Code:  Model: FISH 20  Store Name & Stamp:  Date of Purchase:
Post this warranty card to Fish Phonics Pty Ltd  802 Pacific Hwy Gordon NSW 2072 Australia  Within one month of purchase.  Email technical support go to  www.fishphonics.com  or  www.earzee.co.uk	Name:Address: