IMPORTANT OPERATING INFORMATION

Please read, follow and keep these instructions.

SAFETY

PROPER INSTALLATION

Before installing this device, make sure the TV receiver is mounted to the wall, furniture or stand as required by the manufacturer to maintain stability and prevent tip over if accessible to children. Carefully route cords away from areas accessible by young children to reduce the chance of the cords being pulled, resulting in the TV and device being pulled off the mounting surface. A TV can cause severe injury or death if pulled over and falls on small children.

LITHIUM COIN CELL SAFETY NOTICE

KEEP COIN CELL BATTERIES OUT OF REACH OF CHILDREN. Coin cell batteries can be accidentally ingested. If ingested, these batteries may leak harmful contents causing chemical burns, perforation of soft tissue, and in severe cases, death. Lithium coin batteries must be removed immediately if swallowed. Seek medical attention immediately. If you or your doctor suspects that a battery has been ingested, in the US, call the US NATIONAL BATTERY INGESTION HOTLINE any time at (202) 625-3333; in Canada, call (416) 813-5900.

POWER CORD CAUTION

If the provided power supply plug pins do not fit into your outlet, consult an electrician for replacement of the obsolete outlet. Do not plug the power supply into an extension cord as it is intended to be connected to the wall outlet.

It is recommended that the device be placed upon a dedicated circuit; that is, a single outlet circuit which powers only the device and has no additional outlets or branch circuits. Check the specification page of the owner's manual to be certain.

Do not connect too many devices to the same AC power outlet as this could result in fire or electric shock.

Do not overload wall outlets, or the power supply receptacle. Overloaded wall outlets, loose or damaged wall outlets, extension cords, frayed power cords, and damaged or cracked wire insulation are dangerous. Any of these conditions could result in electric shock or fire. Periodically examine the cord of this device and, if its appearance indicates damage or deterioration, unplug it, discontinue use of the device, and have it replaced with an exact replacement part by an authorized servicer. Protect the power cord from physical or mechanical abuse, such as being twisted, kinked, pinched, closed in a door, or walked upon. Pay particular attention to plugs, wall outlets, and the point where the cord exits the device.

Protect the power cords from being walked on, crushed or pinched.

Do not use this device near water.

MAINTENANCE

CLEANING

Clean only with a dry cloth. When cleaning, unplug the power cord and scrub gently with a soft cloth to prevent scratching. Do not spray water or other liquids directly on the device or TV as electric shock may occur. Do not clean with chemicals such as alcohol, thinners or benzene.

VENTILATION AND HEAT

Install the device where there is proper ventilation. Do not install in a confined space such as a bookcase. Do not cover the device with cloth or other materials (e.g.) plastic while plugged in. Do not install in excessively dusty places. Do not block any ventilation openings. Install in accordance with the instructions provided.

Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat. Keep the device away from direct sunlight.

SERVICING

If you smell smoke or other odors coming from the device or hear strange sounds, unplug the power cord and contact Customer Care.

Refer all servicing to qualified service personnel.

Servicing is required when the device has been damaged in any way, for example the device has been exposed to rain or moisture, does not operate normally, or has been dropped.

FCC NOTICE

Class B digital device

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against the device creating harmful interference in a residential installation. This device generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the device and receiver
- Connect the device to an outlet on a circuit different from that to which the receiver is connected
- Consult Customer Care for help

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device contains a wireless adapter that when operating in the frequency range 5.15 to 5.25 GHz remains indoors to reduce the potential for harmful interference to co-channel Mobile Satellite systems. High power radars are allocated as primary users of the 5.25 to 5.35 GHz and 5.65 to 5.85 GHz bands. These radar stations can cause interference with and /or damage the wireless adapter installed.

NOTE: The combined radiated output power of the wireless modules installed is far below the FCC radio frequency exposure limits. Nevertheless, this device should be used in such a manner that the potential for human contact during normal operation is minimized. To avoid the possibility of exceeding the FCC radio frequency exposure limits, you should keep a distance of at least 20 cm between you (or any other person in the vicinity) and the antenna that is built into this device. Details of the authorized configurations can be found at http://www.fcc.gov/oet/ea/ by entering the FCC ID numbers on the device.