





CON4 TRF-11008ZB-PBW T_FLASH_CARD_01 C52 C53 10uF/16V 0.1uF/16V C0805 C0402 DAT2 H4 H CH CL CD/DAT3 Z DAT0 DAT1 CMD 6 VSS MLVG040Z100NV05
TVS0402
TVS040 MLVG0402100NV05 TVS0402 (V28 VDD 3V3 MLVG0402100NV05 TVS0402 (V18 SD D2 R59 100R/5% R0402 RN9 10K/5%/0402*4 RN_0402 0.1uF/16V 0.1uF/16V VDD_3V3 TF CARD (1) SD_D2 (1) SD_D3 (1) SD_CMD [1] SD_CLK (1) SD_D0 (1) SD_D1 (1) SD_CD







