
About File Browser

Use File Browser on the Media Center, view files in the folders on lacal SD card or USB devices, also manage them by cut, copy, paste, delete, rename or share.



File Edit

Click and then file can be cut,

copy, paste, delete, rename and share.

File Sort

Click , and then select Sort by Name, Sort by Date or Sort by Size

10105 png
Sort
1128 png
1128 png
1122 png
1

About Settings

Use Settings on the Media Center to configure network connection, set display resolution, and change other settings.

Wi-Fi Networks

Turn Wi-Fi on or off: Choose Wi-Fi, and then turn Wi-Fi on or off.

Join a Wi-Fi network: Select Wi-Fi setting, wait for completion of scanning wireless networks in the field, and then select a network. If necessary, enter the password, and then click Connect.

Join a closed Wi-Fi network: To join a Wi-Fi network that isn't shown in the list of networks, choose Add Network, and then enter the network name. If the network requires a password, click Security, click the type of security the network uses, and enter the password.






Ethernet Configuration

Join Ethernet network: Choose Ethernet configuration,
If choose DHCP, you can click Save directly.
If choose Static IP, you will need to input your IP address, Mask, DNS and Default
Router, and then click Save.

Ethernet Switch On or Off: Choose Ethernet, and then toggle Ethernet on or off.



Sound

Choose Digital audio output, and then select PCM or RAW.



Display

Choose Display, and then select 480i, 480p, 576i, 576p, 720p, 1080i or 1080p.



Language & input

Language Setting: enter select language and move up or down the cursor in language list, and select the language you want to use.





Language & input(continue)

Backup & reset




Please select the right time zone you are staying to make sure the right time setting of the system. Serving Source Appar Ap

Upgrade

You have 2 ways to upgrade the media center, locally or online.

You can upgrade with local upgrade software, before you upgrade, the upgrade package should be copied to the U disk, and then select local upgrade.



After System scanned files, select the file you want to upgrade



Also you can upgrade you system online, click the online upgrade and find the upgrade package you want to upgrade with and click.



Do not disconnect the power or unplug the equipment storage upgrade package during the upgrade process.



Warning MC300

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help.

