# Octopus Speaker Creature Instructions







# **#SpeakerCreature**

### **Pairing Your Speaker**

- 1. Turn the speaker switch to "on"
- 2. Turn Bluetooth™ device on
- 3. Pair to Bt2711
- Blue light in suction cup becomes solid after paired



## Charging

- 1. Open Octopus eye cover.
- 2. Plug in supplied USB cable
- Light in suction cup becomes red when charging
- 4. Light turns blue when fully charged

## Placement

- 1. Wet the suction cup
- 2. Place on a smooth surface
- Use on tile or glass only
- 3. Secure by pressing hard and pulling lightly to ensure it is on tight
- 4. Open eye cover and turn on <u>before</u> the speaker is wet
- 5. Remove from the wall after use and turn off
- \* Speaker creatures aren't meant to live on walls and OnHand doesn't want to see your creature fall and die in the shower. Please make sure to remove him/her after use.

#### Playing Music



\*Speakers are not waterproof, do not fully submerge or put in direct flow of water.

## FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

**Warning:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

## RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.