






Figure 5
General Appearance of the EUT



**Figure 6** Inside of the EUT















Figure 8
Inside of the EUT





**P**age 15-5

Figure 9
Component Side of the PCB




Figure 10
Component Side of the PCB






Figure 11
Component Side of the PCB





Figure 12
Component Side of the PCB










Figure 13
Component Side of the PCB




Figure 14 Component Side of the PCB







**P**age 15-8

Figure 15
Component Side of the PCB



Figure 16
Component Side of the PCB







IC: 9976A-BDHTS001 Page 15-9

Figure 17 Component Side of the PCB





Figure 18
Component Side of the PCB











Figure 20 Component Side of the PCB





**P**age 15-11

Figure 21
Component Side of the PCB




Figure 22
Component Side of the PCB











Figure 24
Remote Controller







**P**age 15-13

**Figure 25** AV Cable



**Figure 26** AV Cable



Figure 27



