2.4 GHz Wireless Keyboard

Model #: KB8706

User's Manual

All brand name and trademarks are the property of their respective owners

USER'S RECORD:

To provide quality customer service and technical support, it is suggested that you keep the following information as well as your store receipt and this user's manual.

Date of Purchase:		
Model Number:		
Product Rev Number	(located below the UPC on the package):	

PACKAGE CONTENTS:

Your new wireless keyboard will ship with the following items.

- 2.4GHz Wireless Keyboard
- Nano USB Receiver
- User's Manual & Warranty Information
- 2AAA Batteries For the Keyboard

SYSTEM REQUIREMENTS:

Please be sure that you meet all of the system requirements below to avoid difficulties during installation.

- PCs & Mac® Compatibles
- Windows® XP, Vista, 7 and 8
- Mac[®] OS 10.3 and Above
- An Available USB Port

SYSTEM SPECIFICATIONS:

Your new wireless keyboard complies with the following specifications.

- USB Interface
- 2.4 GHz Wireless Technology

INSTALLING THE BATTERIES:

1. Release the latch at the bottom of your keyboard and remove the Battery Compartment Cover from your keyboard.



2. Install two AAA batteries into your keyboard following the battery orientation guide in the battery bay.



3. Replace the Battery Compartment Cover back onto your keyboard until it securely locks. The LED indicator on your keyboard will light up for 2 seconds after the batteries are installed successfully. (Note: The LED indicator on the keyboard will blink when the battery is low.)



CONNECTING TO A COMPUTER:

- 1. Turn on your computer.
- 2. Make sure batteries for your keyboard have been properly installed, refer to the Installing the batteries section in this manual if necessary. Power on your keyboard, a red LED indicator in the right of the keyboard will light on, and then ESC+Q will search to link.
- 3. Insert the enclosed receiver into an available USB port on your computer.



- 4. Your computer will detect and install the necessary drivers automatically
- 5. Your wireless keyboard is now ready to be used.

KEYBOARD SPECIAL FUNCTION KEYS:

	E-mail	Open Default Mail Software.
a	Home	Open Internet Explorer's default home page.
□ ;	Favorite	Open "My Favorite".
D/II	Play/Pause	Play/pause currently playing multimedia file
\€	Volume up	Turn volume up.
Ç	Volume down	Turn volume down.
1	Mute	Mute volume.
1	Back	Turn the page back
P	Forward	Turn the page forward
8	Stop	Stop the page

FCC WARNNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interfer ence, and (2) this device must accept any interference received, including interference that may cause undesired operation