

---

# Pre-tutorial setup: Tailscale

*Programming SmartNICs: From Packet Processing to Programmable Transport*

ACM SIGCOMM 2026

Fernando Ramos  Muhammad Shahbaz  Mina Tahmasbi Arashloo  Mario Baldi 

Francisco Pereira  Bilal Saleem   Tyler Liu  Chenxingyu Zhao 

 INESC-ID, Instituto Superior Técnico, University of Lisbon  University of Michigan  University of Waterloo  
 NVIDIA  Purdue University  University of Washington

---

During this tutorial, you will be programming [NVIDIA BlueField-3 SmartNICs](#). The tutorial focus on hands-on programming, and you will be given access to 12 BlueField-3 cards, each with a different configuration. You will be able to run your own code on the cards, and see how it behaves in a real network environment.

The BlueField-3 cards you will be programming live in racks at five sites across four universities and NVIDIA. They are not reachable from the public internet, and no SmartNIC will be physically provided during the tutorial.

You will use **Tailscale** to connect to the tutorial network and access the BlueField cards. Tailscale is a VPN that allows you to put your laptop and the BlueField cards on the same small private network, as if they were on the same LAN.

We ask you to **install the tailscale client and join the tutorial network before you arrive**. With that in mind, we wrote this small guide to help you get set up for the tutorial.

You do **not** need a Tailscale account, and you will not be asked to sign in with Google, GitHub, or anything else. Your laptop joins with a key we provide to you.

At the end of this guide, you will be able to join the tutorial network and see the Bluefield-3 cards. However, ssh access to the cards is only provided at the start of the tutorial, and closed again by the end of the conference.

## What you need

- A laptop, with permission to install software on it.
- Internet connection.

## Step 1 — Install the client

We will now install the tailscale client on your laptop. After installing, there is *no need* for you to sign in or create an account. The authentication key we provide to you in step 2 is all you need to join the tutorial network.

### macOS

You can download it from [tailscale.com/download/mac](https://tailscale.com/download/mac), or install it with [Homebrew](#):

```
$ brew install --cask tailscale
```

Launch Tailscale from Applications once, so it can install its system components. It runs as a menu-bar

icon.

The tailscale command lives inside the app bundle and may not be on your path. Link it, so step 2 works:

```
$ sudo ln -s /Applications/Tailscale.app/Contents/MacOS/Tailscale /usr/local/bin/tailscale
```

## Windows

Download and run the installer from [tailscale.com/download/windows](https://tailscale.com/download/windows). Tailscale then starts on its own and lives in the system tray, and tailscale.exe is available in PowerShell.

## Linux

The install script covers every mainstream distribution:

```
$ curl -fsSL https://tailscale.com/install.sh | sh
```

It installs the client and enables the tailscaled service.

## Step 2 — Join the tutorial network

Run the command for your platform, with the key we provide to you in place of the one below.

On **Linux**:

```
$ sudo tailscale up --auth-key=tskey-auth-PLACEHOLDER-NOT-A-REAL-KEY
```

On **macOS**:

```
$ tailscale up --auth-key=tskey-auth-PLACEHOLDER-NOT-A-REAL-KEY
```

On **Windows**, in PowerShell:

```
$ tailscale.exe up --auth-key=tskey-auth-PLACEHOLDER-NOT-A-REAL-KEY
```

## Step 3 — Check that it worked

You can now check that your laptop is on the tutorial network, and able to see the BlueField-3 cards:

```
# On Windows, use `tailscale.exe` instead of `tailscale`.
$ tailscale status
100.124.27.9    bf3-nvidia-1    tagged-devices    linux    -
100.115.117.14 bf3-nvidia-2    tagged-devices    linux    -
100.103.195.108 bf3-nvidia-3    tagged-devices    linux    -
100.88.192.90   bf3-nvidia-4    tagged-devices    linux    -
100.103.77.119  bf3-ulisbon-1   tagged-devices    linux    -
100.97.207.2    bf3-ulisbon-2   tagged-devices    linux    -
100.116.169.79  bf3-ulisbon-3   tagged-devices    linux    -
100.101.195.64  bf3-umich-1     tagged-devices    linux    -
100.118.32.66   bf3-umich-2     tagged-devices    linux    -
100.83.137.121  bf3-uwashington-1 tagged-devices    linux    -
100.110.170.20  bf3-uwashington-2 tagged-devices    linux    -
100.118.190.119 bf3-uwaterloo-1 tagged-devices    linux    -
```

You should also see your own laptop listed with a 100.x.y.z address.

## On the day

Bring the laptop as you left it. At the start of the session we open access to the cards, and you will be able to ssh into them with the shared tutorial account:

| User | Password          |
|------|-------------------|
| s26t | sigcomm26tutorial |