




CH32X035R8-6
PC15/CC2/I2C1_FLT#
PC14/VCC1/TIC1_/I2C2_
PC13/GDP/RTC1/TX_/I2C_/RX4_/T1E/PC13
PC12/GDM/TIC4/TX_/I2C_/RX_/CTS1/PC12
PC11/D-/TIC3_/I2C3_/RX_/CTS2/PC11
PC10/D+/TIC2_/I2C2_/RX2_/PC10
PC9/SCK/TIC1_/I2C1_/RX1_/CTS3/PC9
PB15/MOSI/TIC1N_/PB15
PB14/MISO/TIC2N_/PB14
PB13/SCK/TIC3N_/PB13
PB12/NSS/TIC4N_/PB12
PB11/TIC3/TIC1N_/RX1
PB10/TIC2/TIC2N_/TX2
PB9/TIC1/MCO/TX1_
PB8/TIC3N/CC3/I2C1_/SDA
PB7/TIC2N/CC2/I2C1_/SCL
PB6/TIC4N/CC1/I2C2_/SDA_/RX3_/CC2
PB5/I2C1_/SCL_/T1BK_/RX3_/CC1
PB4/NJTRST/TIC1_/TX3_/CC3
PB3/JTDO/TIC2_/SPI1_/SCK_/TX4_/CC4
PA15/JTDI/TIC1N_/SPI1_/NSS_/RX4_
PA14/SWCLK/TX1_/I2C1_/SDA_
PA13/SWDIO/RX1_/I2C1_/SCL_
PA12/TX2_/CAN_TX_/USBDP
PA11/RX2_/CAN_RX_/USBDM
PA10/TX1_/TIC1_/USBID
PA9/RX1_/TIC2_/VBUS
PA8/MCO/TIC1_/CC1
PB0/TIC3N/CC3/ADC_IN8
PB1/TIC4N/CC4/ADC_IN9
PB2/BOOT1
PA7/RX1_/TIC1N_/ADC_IN7
PA6/TX1_/TIC3N_/ADC_IN6
PA5/SCK1_/TIC2N_/ADC_IN5
PA4/NSS1_/TIC4N_/ADC_IN4
PA3/RX2_/TIC2_/ADC_IN3
PA2/TX2_/TIC3_/ADC_IN2
PA1/RX1_/TIC4_/ADC_IN1
PA0/CTS1_/TIC1_/ADC_IN0
VDD
VSS
U1



TYPE-C 24P
SSRXA1
SSRXA2
SSTXA1
SSTXA2
SBU1
SBU2
VBUS
CC1
CC2
J1


SSRXA1
SSRXA2
SSTXA1
SSTXA2
SBU1
SBU2
VBUS
CC1
CC2
J1



CH334F
RESET/SDP
SDA
SCL
INT
GPIO3
GPIO2
GPIO1
U5


SSRXA1
SSRXA2
SSTXA1
SSTXA2
SBU1
SBU2
VBUS
CC1
CC2
J2


TYPE-C 24P
SSRXA1
SSRXA2
SSTXA1
SSTXA2
SBU1
SBU2
VBUS
CC1
CC2
J3


SSRXA1
SSRXA2
SSTXA1
SSTXA2
SBU1
SBU2
VBUS
CC1
CC2
J3


CH224Q
CFG1
CFG2
VBUS
CC1
CC2
U8


CH217K
VDD
VDDIN
VDDOUT
CC1
CC2
U2

CH340E
U6


CH32V307
U6


CH32V307
U7


AO3401A
Q1


AO3401A
Q2


TST_VBUS
VBUS_IN
5V
TST_CC1
TST_CC2
CHG_SCL
CHG_SDA
CHG_5V
CHG_HV
TST_SBU1
TST_SBU2
SBU_G