

Tabela Dos Sensores TCRT5000

Cm	Volts
1	0.14
2	0.19
3	0.24
4	1.31
5	1.82
6	2.04
7	2.24
8	2.40
9	2.55
10	2.65
11	2.72
12	2.76