


TABLE OF CONTENTS

<u>PAGEBLOCK</u>	<u>TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
31-11-01/400		U	Oct 30/15
	MAIN PANEL - REMOVAL/INSTALLATION		
31-11-01-000-801-A		U	Oct 30/15
	<i>EFFECTIVITY: AIRCRAFT WITH RMU INSTALLED ON THE CONTROL PEDESTAL</i>		
	MAIN INSTRUMENT PANEL - REMOVAL		
31-11-01-400-801-A		U	Oct 30/15
	<i>EFFECTIVITY: AIRCRAFT WITH RMU INSTALLED ON THE CONTROL PEDESTAL</i>		
	MAIN INSTRUMENT PANEL - INSTALLATION		
31-11-01-000-802-A		U	Oct 30/15
	<i>EFFECTIVITY: AIRCRAFT WITH RMU INSTALLED ON THE MAIN INSTRUMENT PANEL</i>		
	MAIN INSTRUMENT PANEL - REMOVAL		
31-11-01-400-802-A		U	Oct 30/15
	<i>EFFECTIVITY: AIRCRAFT WITH RMU INSTALLED ON THE MAIN INSTRUMENT PANEL</i>		
	MAIN INSTRUMENT PANEL - INSTALLATION		
31-12-01/400		U	Oct 30/15
	GLARESHIELD PANEL - REMOVAL/INSTALLATION		
31-12-01-000-801-A		U	Oct 30/15
	GLARESHIELD PANEL - REMOVAL		
31-12-01-400-801-A		U	Oct 30/15
	GLARESHIELD PANEL - INSTALLATION		
31-14-01/400		U	Oct 30/15
	CONTROL PEDESTAL - REMOVAL/INSTALLATION		
31-14-01-000-801-A		U	Oct 30/15
	<i>EFFECTIVITY: AIRCRAFT WITH RMU INSTALLED ON THE CONTROL PEDESTAL</i>		
	CONTROL PEDESTAL - REMOVAL		
31-14-01-400-801-A		U	Oct 30/15
	<i>EFFECTIVITY: AIRCRAFT WITH RMU INSTALLED ON THE CONTROL PEDESTAL</i>		
	CONTROL PEDESTAL - INSTALLATION		

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 – EMB135

AIRCRAFT
MAINTENANCE MANUAL


PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
31-14-01-000-803-A <i>EFFECTIVITY: AIRCRAFT WITH RMU INSTALLED ON THE MAIN INSTRUMENT PANEL</i> CONTROL PEDESTAL - REMOVAL	U	Oct 30/15
31-14-01-400-803-A <i>EFFECTIVITY: AIRCRAFT WITH RMU INSTALLED ON THE MAIN INSTRUMENT PANEL</i> CONTROL PEDESTAL - INSTALLATION	U	Oct 30/15
31-16-01/400 CIRCUIT BREAKER PANEL - REMOVAL/INSTALLATION	U	Oct 30/15
31-16-01-000-801-A CIRCUIT BREAKER PANEL - REMOVAL	U	Oct 30/15
31-16-01-400-801-A CIRCUIT BREAKER PANEL - INSTALLATION	U	Oct 30/15
31-17-01/400 MAINTENANCE PANEL - REMOVAL/INSTALLATION	U	Oct 30/15
31-17-01-000-801-A MAINTENANCE PANEL - REMOVAL	U	Oct 30/15
31-17-01-400-801-A MAINTENANCE PANEL - INSTALLATION	U	Oct 30/15
31-21-00/500 CLOCK - ADJUSTMENT/TEST	U	Oct 30/15
31-21-00-700-801-A PILOT DIGITAL CLOCK INFORMATION - CHECK	U	Oct 30/15
31-21-00-700-802-A DIGITAL CLOCK - OPERATIONAL TEST	U	Oct 30/15
31-21-01/400 DIGITAL CLOCK - REMOVAL/INSTALLATION	U	Oct 30/15
31-21-01-000-801-A DIGITAL CLOCK - REMOVAL	U	Oct 30/15
31-21-01-400-801-A DIGITAL CLOCK - INSTALLATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 31
Page 2 of 13
Rev 55 - Oct 29/18




EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL

PAGEBLOCK <u>TASK</u>		<u>REVISION STATUS</u>	<u>REVISION DATE</u>
31-31-00/500	FLIGHT DATA RECORDER - ADJUSTMENT/TEST	U	Oct 30/15
31-31-00-700-801-A	<i>EFFECTIVITY: AIRCRAFT WITHOUT AFDAU/AFDAMU</i> FLIGHT DATA RECORDER - FUNCTIONAL TEST	R	Oct 29/18
31-31-00-700-802-A	FLIGHT DATA RECORDER - OPERATIONAL TEST	U	Oct 30/15
31-31-00-700-803-A	FDR DATA - PERSONAL COMPUTER DOWNLOADING	U	Apr 27/18
31-31-00-700-804-A	<i>EFFECTIVITY: AIRCRAFT WITH AFDAU/AFDAMU</i> FLIGHT DATA RECORDER - FUNCTIONAL TEST	R	Oct 29/18
31-31-00-700-805-A	FLIGHT DATA RECORDER - FUNCTIONAL TEST BY ANALYSIS OF DOWNLOADED DATA	U	Apr 27/18
31-31-01/400	FLIGHT DATA RECORDER - REMOVAL/INSTALLATION	U	Oct 30/15
31-31-01-000-801-A	FLIGHT DATA RECORDER - REMOVAL	U	Oct 30/15
31-31-01-400-801-A	FLIGHT DATA RECORDER - INSTALLATION	U	Oct 30/15
31-31-01/600	FLIGHT DATA RECORDER - INSPECTION/CHECK	U	Oct 30/15
31-31-01-200-801-A	FDR ULB BATTERY - GENERAL VISUAL INSPECTION	U	Oct 30/15
31-31-02/200	FDR UNDERWATER LOCATOR BEACON - MAINTENANCE PRACTI- CES	U	Oct 30/15
31-31-02-900-801-A	FDR UNDERWATER LOCATOR BEACON (ULB) - RESTORE	U	Oct 30/15
31-31-02-960-801-A	FDR UNDERWATER LOCATOR BEACON (ULB) - DISCARD	U	Apr 27/18

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted




EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL

PAGEBLOCK <u>TASK</u>		<u>REVISION STATUS</u>	<u>REVISION DATE</u>
31-31-02/400	FDR UNDERWATER LOCATOR BEACON - REMOVAL/INSTALLATION	U	Oct 30/15
31-31-02-000-801-A	FDR UNDERWATER LOCATOR BEACON - REMOVAL	U	Oct 30/15
31-31-02-400-801-A	FDR UNDERWATER LOCATOR BEACON - INSTALLATION	U	Oct 30/15
31-31-02/500	FDR UNDERWATER LOCATOR BEACON - ADJUSTMENT/TEST	U	Oct 30/15
31-31-02-700-801-A	FDR UNDERWATER LOCATOR BEACON - OPERATIONAL TEST	U	Apr 27/18
31-31-03/400	TRIAXIAL ACCELEROMETER - REMOVAL/INSTALLATION	U	Oct 30/15
31-31-03-000-801-A	FDR TRIAXIAL ACCELEROMETER - REMOVAL	U	Oct 30/15
31-31-03-400-801-A	FDR TRIAXIAL ACCELEROMETER - INSTALLATION	U	Oct 30/15
31-31-04/400	POTENTIOMETERS - REMOVAL/INSTALLATION	U	Oct 30/15
31-31-04-000-801-A	FDR AILERON POTENTIOMETERS - REMOVAL	U	Oct 30/15
31-31-04-400-801-A	FDR AILERON POTENTIOMETERS - INSTALLATION	U	Oct 30/15
31-31-04-000-802-A	FDR ELEVATOR POTENTIOMETERS - REMOVAL	U	Oct 30/15
31-31-04-400-802-A	FDR ELEVATOR POTENTIOMETERS - INSTALLATION	U	Oct 30/15
31-31-04-000-803-A	FDR RUDDER POTENTIOMETER - REMOVAL	U	Oct 30/15
31-31-04-400-803-A	FDR RUDDER POTENTIOMETER - INSTALLATION	U	Oct 30/15
31-31-04/500	POTENTIOMETERS - ADJUSTMENT/TEST	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
31-31-04-700-801-A FDR POTENTIOMETERS - ADJUSTMENT	U	Oct 30/15
31-31-05/400 FDR IMPACT SWITCH - REMOVAL/INSTALLATION	U	Oct 30/15
31-31-05-000-802-A FDR IMPACT SWITCH - REMOVAL	U	Oct 30/15
31-31-05-400-802-A FDR IMPACT SWITCH - INSTALLATION	U	Oct 30/15
31-31-06/400 <i>EFFECTIVITY: AIRCRAFT WITH RVDTs/RVITS</i> RVDTs/RVITs - REMOVAL/INSTALLATION	U	Oct 30/15
31-31-06-000-801-A <i>EFFECTIVITY: AIRCRAFT WITH RVDTs/RVITS</i> FDR AILERON RVDTs/RVITS - REMOVAL	U	Oct 30/15
31-31-06-400-801-A <i>EFFECTIVITY: AIRCRAFT WITH RVDTs/RVITS</i> FDR AILERON RVDTs/RVITS - INSTALLATION	U	Oct 30/15
31-31-06-000-802-A <i>EFFECTIVITY: AIRCRAFT WITH RVDTs/RVITS</i> FDR ELEVATOR RVDTs/RVITS - REMOVAL	U	Oct 30/15
31-31-06-400-802-A <i>EFFECTIVITY: AIRCRAFT WITH RVDTs/RVITS</i> FDR ELEVATOR RVDTs/RVITS - INSTALLATION	U	Oct 30/15
31-31-06-000-803-A <i>EFFECTIVITY: AIRCRAFT WITH RVDTs/RVITS</i> FDR RUDDER RVDT/RVIT - REMOVAL	U	Oct 30/15
31-31-06-400-803-A <i>EFFECTIVITY: AIRCRAFT WITH RVDTs/RVITS</i> FDR RUDDER RVDT/RVIT - INSTALLATION	U	Oct 30/15
31-31-06-000-804-A <i>EFFECTIVITY: AIRCRAFT POST-MOD SB 145-55-0020, WITH MECHANICAL GUST LOCK AND WITHOUT PROVISIONS FOR ELECTRO-MECHANICAL GUST LOCK</i> FDR ELEVATOR RVDTs/RVITS SUPPORT - REMOVAL	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 31
Page 5 of 13
Rev 55 - Oct 29/18



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
31-31-06-400-804-A <i>EFFECTIVITY: AIRCRAFT POST-MOD SB 145-55-0020, WITH MECHANICAL GUST LOCK AND WITHOUT PROVISIONS FOR ELECTROMECHANICAL GUST LOCK</i> FDR ELEVATOR RVDTS/RVITS SUPPORT - INSTALLATION	U	Oct 30/15
31-31-06-000-805-A <i>EFFECTIVITY: AIRCRAFT POST-MOD S.B. 145-31-0045, WITH ELECTROMECHANICAL GUST LOCK</i> FDR ELEVATOR RVDTS/RVITS SUPPORT - REMOVAL	U	Oct 30/15
31-31-06-400-805-A <i>EFFECTIVITY: AIRCRAFT POST-MOD S.B. 145-31-0045, WITH ELECTROMECHANICAL GUST LOCK</i> FDR ELEVATOR RVDTS/RVITS SUPPORT - INSTALLATION	U	Oct 30/15
31-31-06-500 <i>EFFECTIVITY: AIRCRAFT WITH RVDTs/RVITS</i> RVDTs/RVITs - ADJUSTMENT/TEST	U	Oct 30/15
31-31-06-820-801-A <i>EFFECTIVITY: AIRCRAFT WITH RVDTs/RVITS</i> FDR AILERON RVDTS/RVITS - CALIBRATION	U	Oct 30/15
31-31-06-820-802-A <i>EFFECTIVITY: AIRCRAFT WITH RVDTs/RVITS</i> FDR ELEVATOR RVDTS/RVITS - CALIBRATION	U	Oct 30/15
31-31-06-820-803-A <i>EFFECTIVITY: AIRCRAFT WITH RVDTs/RVITS</i> FDR RUDDER RVDT/RVIT - CALIBRATION	U	Oct 30/15
31-31-07/200 <i>EFFECTIVITY: AIRCRAFT WITH AFDAMU</i> AUXILIARY FLIGHT-DATA ACQUISITION UNIT (AFDAU) / AUXILIARY FLIGHT-DATA ACQUISITION AND MANAGEMENT UNIT (AFDAMU) - MAINTENANCE PRACTICES	U	Oct 30/15
31-31-07-860-802-A <i>EFFECTIVITY: AIRCRAFT WITH AFDAMU</i> AFDAMU CONFIGURATION CARD - PROGRAMMING	U	Oct 30/15
31-31-07-860-803-A <i>EFFECTIVITY: AIRCRAFT WITH AFDAMU</i> AFDAMU CONFIGURATION CARD - UPLOADING	U	Oct 30/15
31-31-07-900-801-A <i>EFFECTIVITY: AIRCRAFT WITH AFDAMU</i> AFDAMU - RESTORE	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC


Chapter 31
Page 6 of 13
Rev 55 - Oct 29/18



AIRCRAFT MAINTENANCE MANUAL

PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
31-31-07-970-804-A <i>EFFECTIVITY: AIRCRAFT WITH AFDAMU</i> AFDAMU CONFIGURATION CARD - READING	U	Oct 30/15
31-31-07/400 <i>EFFECTIVITY: AIRCRAFT WITH AFDAU/AFDAMU</i> AUXILIARY FLIGHT-DATA ACQUISITION UNIT (AFDAU) / AUXILIARY FLIGHT-DATA ACQUISITION AND MANAGEMENT UNIT (AFDAMU) - REMOVAL/INSTALLATION	U	Oct 30/15
31-31-07-000-801-A <i>EFFECTIVITY: AIRCRAFT WITH AFDAU/AFDAMU</i> AFDAU/AFDAMU - REMOVAL	U	Oct 30/15
31-31-07-400-801-A <i>EFFECTIVITY: AIRCRAFT WITH AFDAU/AFDAMU</i> AFDAU/AFDAMU - INSTALLATION	U	Oct 30/15
31-31-07-000-802-A <i>EFFECTIVITY: AIRCRAFT WITH AFDAMU</i> AFDAMU MEMORY CARD - REMOVAL	U	Oct 30/15
31-31-07-400-802-A <i>EFFECTIVITY: AIRCRAFT WITH AFDAU/AFDAMU</i> AFDAMU MEMORY CARD - INSTALLATION	U	Oct 30/15
31-31-07/500 AUXILIARY FLIGHT-DATA ACQUISITION UNIT (AFDAU) / AUXILIARY FLIGHT-DATA ACQUISITION AND MANAGEMENT UNIT (AFDAMU) - ADJUSTMENT/TEST	U	Oct 30/15
31-31-07-700-801-A <i>EFFECTIVITY: AIRCRAFT WITH AFDAU</i> AFDAU - OPERATIONAL TEST	U	Oct 30/15
31-31-07-700-802-A <i>EFFECTIVITY: AIRCRAFT WITH AFDAMU</i> AFDAMU - OPERATIONAL TEST	U	Oct 30/15
31-31-08/400 <i>EFFECTIVITY: AIRCRAFT WITH LOAD CELLS</i> AMPLIFIER/ANALOG-TO-DIGITAL CONVERTER - REMOVAL/INSTALLATION	U	Oct 30/15
31-31-08-000-801-A <i>EFFECTIVITY: AIRCRAFT WITH LOAD CELLS</i> AMPLIFIER/ANALOG-TO-DIGITAL CONVERTER - REMOVAL	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
31-31-08-400-801-A <i>EFFECTIVITY: AIRCRAFT WITH LOAD CELLS</i> AMPLIFIER/ANALOG-TO-DIGITAL CONVERTER - INSTALLATION	U	Oct 30/15
31-33-00/500 CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH EQAR</i> EXTENDED QUICK ACCESS RECORDER (EQAR) SYSTEM - ADJUSTMENT/TEST	U	Oct 30/15
31-33-00-700-801-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH EQAR</i> EXTENDED QUICK ACCESS RECORDER (EQAR) - OPERATIONAL TEST	U	Oct 30/15
31-33-00/500 CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH EQAR</i> EXTENDED QUICK ACCESS RECORDER (EQAR) SYSTEM - ADJUSTMENT/TEST	U	Oct 30/15
31-33-00-700-801-A CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH EQAR</i> EXTENDED QUICK ACCESS RECORDER (EQAR) - OPERATIONAL TEST	U	Oct 30/15
31-33-01/200 <i>EFFECTIVITY: AIRCRAFT WITH EQAR</i> EQAR DISK - MAINTENANCE PRACTICES	U	Oct 30/15
31-33-01-000-803-A <i>EFFECTIVITY: AIRCRAFT WITH EQAR</i> EQAR RECORDED DATA DISK - READING	U	Oct 30/15
31-33-01-400-803-A <i>EFFECTIVITY: AIRCRAFT WITH EQAR</i> EQAR CONFIGURATION DISK - UPLOADING	U	Oct 30/15
31-33-01/400 <i>EFFECTIVITY: AIRCRAFT WITH EQAR</i> EQAR DISK - REMOVAL/INSTALLATION	U	Oct 30/15
31-33-01-000-801-A <i>EFFECTIVITY: AIRCRAFT WITH EQAR</i> EQAR RECORDED DATA DISK - REMOVAL	U	Oct 30/15
31-33-01-400-801-A <i>EFFECTIVITY: AIRCRAFT WITH EQAR</i> EQAR DATA DISK - INSTALLATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC


Chapter 31
Page 8 of 13
Rev 55 - Oct 29/18



AIRCRAFT
MAINTENANCE MANUAL

PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
31-33-02/400 CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH EQAR</i> EQAR RECORDER - REMOVAL/INSTALLATION	U	Oct 30/15
31-33-02-000-801-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH EQAR</i> EQAR RECORDER - REMOVAL	U	Oct 30/15
31-33-02-400-801-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH EQAR</i> EQAR RECORDER - INSTALLATION	U	Oct 30/15
31-33-02/400 CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH EQAR</i> EQAR RECORDER - REMOVAL/INSTALLATION	U	Oct 30/15
31-33-02-000-801-A CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH EQAR</i> EQAR RECORDER - REMOVAL	U	Oct 30/15
31-33-02-400-801-A CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH EQAR</i> EQAR RECORDER - INSTALLATION	U	Oct 30/15
31-33-03/400 <i>EFFECTIVITY: AIRCRAFT WITH EQAR</i> EQAR BATTERY - REMOVAL/INSTALLATION	U	Oct 30/15
31-33-03-000-801-A <i>EFFECTIVITY: AIRCRAFT WITH EQAR</i> EQAR BATTERY - REMOVAL	U	Oct 30/15
31-33-03-400-801-A <i>EFFECTIVITY: AIRCRAFT WITH EQAR</i> EQAR BATTERY- INSTALLATION	U	Oct 30/15
31-34-00/500 CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH OQAR</i> OPTICAL QUICK ACCESS RECORDER (OQAR) SYSTEM - ADJUSTMENT/TEST	U	Oct 30/15
31-34-00-700-801-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH OQAR</i> OPTICAL QUICK-ACCESS RECORDER (OQAR) - OPERATIONAL TEST	U	Oct 30/15


Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



AIRCRAFT MAINTENANCE MANUAL

<u>PAGEBLOCK TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
31-34-01/400 CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH OQAR</i> OQAR DISK - REMOVAL/INSTALLATION	U	Oct 30/15
31-34-01-000-801-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH OQAR</i> OQAR OPTICAL DISK - REMOVAL (OQAR POWERED)	U	Oct 30/15
31-34-01-400-801-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH OQAR</i> OQAR OPTICAL DISK - INSTALLATION	U	Oct 30/15
31-34-01-000-802-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH OQAR</i> OQAR OPTICAL DISK - REMOVAL (OQAR UNPOWERED)	U	Oct 30/15
31-34-02/400 CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH OQAR</i> OQAR UNIT - REMOVAL/INSTALLATION	U	Oct 30/15
31-34-02-000-801-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH OQAR</i> OQAR UNIT - REMOVAL	U	Oct 30/15
31-34-02-400-801-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH OQAR</i> OQAR UNIT - INSTALLATION	U	Oct 30/15
31-34-03/400 CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH OQAR</i> OQAR INVERTER - REMOVAL/INSTALLATION	U	Oct 30/15
31-34-03-000-801-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH OQAR</i> OQAR INVERTER - REMOVAL	U	Oct 30/15
31-34-03-400-801-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH OQAR</i> OQAR INVERTER - INSTALLATION	U	Oct 30/15
31-41-00/500 EICAS - ADJUSTMENT/TEST	U	Oct 30/15
31-41-00-700-801-A DAU CHANNEL REVERSION - OPERATIONAL TEST	U	Oct 30/15
31-41-00-700-802-A EICAS - OPERATIONAL TEST	U	Oct 30/15


Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



AIRCRAFT MAINTENANCE MANUAL

<u>PAGEBLOCK TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
31-41-01/400 DATA ACQUISITION UNIT (DA-800) - REMOVAL/INSTALLATION	U	Oct 30/15
31-41-01-000-801-A DATA ACQUISITION UNIT - REMOVAL	U	Oct 30/15
31-41-01-400-801-A DATA ACQUISITION UNIT - INSTALLATION	U	Oct 30/15
31-41-02/400 EICAS BEZEL - REMOVAL/INSTALLATION	U	Oct 30/15
31-41-02-000-801-A EICAS BEZEL - REMOVAL	U	Oct 30/15
31-41-02-400-801-A EICAS BEZEL - INSTALLATION	U	Oct 30/15
31-41-03/400 EICAS REVERSION PANEL - REMOVAL/INSTALLATION	U	Oct 30/15
31-41-03-000-801-A <i>EFFECTIVITY: AIRCRAFT WITH EICAS REVERSION PANEL</i> EICAS REVERSION PANEL - REMOVAL	U	Oct 30/15
31-41-03-400-801-A <i>EFFECTIVITY: AIRCRAFT WITH EICAS REVERSION PANEL</i> EICAS REVERSION PANEL - INSTALLATION	U	Oct 30/15
31-41-03-000-802-A <i>EFFECTIVITY: AIRCRAFT WITH EICAS REVERSION/EGPWS/LG CUT-OUT COMBINED PANEL</i> EICAS REVERSION PANEL - REMOVAL	U	Oct 30/15
31-41-03-400-802-A <i>EFFECTIVITY: AIRCRAFT WITH EICAS REVERSION/EGPWS/LG CUT-OUT COMBINED PANEL</i> EICAS REVERSION PANEL - INSTALLATION	U	Oct 30/15
31-42-00/500 INTEGRATED COMPUTERS - ADJUSTMENT/TEST	U	Oct 30/15
31-42-00-700-801-A INTEGRATED COMPUTERS - OPERATIONAL TEST	U	Oct 30/15
31-42-01/400 INTEGRATED COMPUTER (IC-600) - REMOVAL/INSTALLATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
31-42-01-000-801-A INTEGRATED COMPUTER (IC-600) - REMOVAL	U	Oct 30/15
31-42-01-400-801-A INTEGRATED COMPUTER (IC-600) - INSTALLATION	U	Oct 30/15
31-42-02/200 <i>EFFECTIVITY: AIRCRAFT WITH IC-600 CONFIGURATION MODULE (IM-600)</i> IC-600 CONFIGURATION MODULE (IM-600) - MAINTENANCE PRACTICES	U	Oct 30/15
31-42-02-860-801-A <i>EFFECTIVITY: AIRCRAFT WITH IC-600 CONFIGURATION MODULE (IM-600)</i> IC-600 CONFIGURATION MODULE - DOWNLOADING	U	Oct 30/15
31-42-02/400 <i>EFFECTIVITY: AIRCRAFT WITH IC-600 CONFIGURATION MODULE (IM-600)</i> IC-600 CONFIGURATION MODULE (IM-600) - REMOVAL/INSTALLATION	U	Oct 30/15
31-42-02-000-803-A <i>EFFECTIVITY: AIRCRAFT WITH IC-600 CONFIGURATION MODULE (IM-600)</i> IC-600 CONFIGURATION MODULE (IM-600) - REMOVAL	U	Oct 30/15
31-42-02-400-803-A <i>EFFECTIVITY: AIRCRAFT WITH IC-600 CONFIGURATION MODULE (IM-600)</i> IC-600 CONFIGURATION MODULE (IM-600) - INSTALLATION	U	Oct 30/15
31-51-00/500 AURAL WARNING - ADJUSTMENT/TEST	U	Oct 30/15
31-51-00-700-801-A AURAL WARNING UNIT - OPERATIONAL TEST	U	Oct 30/15
31-51-01/400 AURAL WARNING UNIT - REMOVAL/INSTALLATION	U	Oct 30/15
31-51-01-000-801-A AURAL WARNING UNIT - REMOVAL	U	Oct 30/15
31-51-01-400-801-A AURAL WARNING UNIT - INSTALLATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 31
Page 12 of 13
Rev 55 - Oct 29/18



AIRCRAFT
MAINTENANCE MANUAL

PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
31-61-01/400 AVIONICS POWER DIODE BOX - REMOVAL/INSTALLATION	U	Oct 30/15
31-61-01-000-801-A AVIONICS POWER DIODE BOX - REMOVAL	U	Oct 30/15
31-61-01-400-801-A AVIONICS POWER DIODE BOX - INSTALLATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 31
Page 13 of 13
Rev 55 - Oct 29/18

