

**TABLE OF CONTENTS**

| <u>PAGEBLOCK<br/>TASK</u>  | <u>REVISION<br/>STATUS</u> | <u>REVISION<br/>DATE</u> |
|--|----------------------------|--------------------------|
| 28-00-00/200<br>FUEL - MAINTENANCE PRACTICES   | U                          | Oct 30/15                |
| 28-00-01/400<br>FUEL PLUMBING - REMOVAL/INSTALLATION   | U                          | Oct 30/15                |
| 28-00-01-000-801-A<br>FUEL PLUMBING - REMOVAL  | U                          | Oct 30/15                |
| 28-00-01-400-801-A<br>FUEL PLUMBING - INSTALLATION   | U                          | Oct 30/15                |
| 28-10-00/200<br>STORAGE - MAINTENANCE PRACTICES  | U                          | Oct 30/15                |
| 28-10-00-910-801-A<br>WING-TO-WING FUEL TRANSFER   | U                          | Oct 30/15                |
| 28-11-00/500<br>FUEL TANKS - ADJUSTMENT/TEST   | U                          | Oct 30/15                |
| 28-11-00-700-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>FUELED-TANK LEAK CHECK - OPERATIONAL CHECK   | U                          | Oct 30/15                |
| 28-11-00-700-802-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>DEFUELED-TANK LEAK CHECK - OPERATIONAL CHECK | U                          | Oct 30/15                |
| 28-11-00-700-803-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>FUELED-TANK LEAK CHECK - OPERATIONAL CHECK   | U                          | Oct 30/15                |
| 28-11-00-700-804-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>DEFUELED-TANK LEAK CHECK - OPERATIONAL CHECK | U                          | Oct 30/15                |
| 28-11-00-700-805-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>WING FUEL TANK - BONDING TEST                | R                          | Oct 29/18                |
| 28-11-00-700-806-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>WING FUEL TANK - BONDING TEST                | U                          | Oct 30/15                |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 - EMB135

AIRCRAFT  
MAINTENANCE MANUAL

| PAGEBLOCK<br>TASK  | REVISION<br>STATUS | REVISION<br>DATE |
|--|--------------------|------------------|
| 28-11-00/600<br>FUEL TANKS - INSPECTION/CHECK  | U                  | Oct 30/15        |
| 28-11-00-200-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>FUEL TANK SURFACES - INSPECTION        | U                  | Oct 30/15        |
| 28-11-00-200-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>FUEL TANK SURFACES - INSPECTION        | U                  | Oct 30/15        |
| 28-11-00/700<br>FUEL TANKS - CLEANING/PAINTING   | U                  | Oct 30/15        |
| 28-11-00-300-801-A<br>FUEL-TANK ANTI BIOLOGICAL COATING - APPLICATION PROCEDURES                           | U                  | Oct 30/15        |
| 28-11-00-300-802-A<br>DECONTAMINATION OF INTEGRAL FUEL TANKS   | U                  | Apr 29/16        |
| 28-11-00-300-803-A<br>PERIODICAL ANALYSIS FOR PRESENCE OF MICROORGANISMS IN THE TANKS                      | U                  | Apr 29/16        |
| 28-11-00-300-804-A<br>APPLY BIOCIDE PRODUCTS   | U                  | Oct 31/17        |
| 28-11-01/400<br>FUEL-TANK ACCESS PANEL - REMOVAL/INSTALLATION  | U                  | Oct 30/15        |
| 28-11-01-000-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>FUEL-TANK ACCESS PANELS - REMOVAL      | U                  | Oct 30/15        |
| 28-11-01-400-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>FUEL-TANK ACCESS PANELS - INSTALLATION | U                  | Oct 30/15        |
| 28-11-01-000-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>FUEL-TANK ACCESS PANELS - REMOVAL      | U                  | Oct 30/15        |
| 28-11-01-400-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>FUEL-TANK ACCESS PANELS - INSTALLATION | U                  | Oct 30/15        |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 28  
Page 2 of 21  
Rev 55 - Oct 29/18



AIRCRAFT  
MAINTENANCE MANUAL

| PAGEBLOCK<br>TASK  | REVISION<br>STATUS | REVISION<br>DATE |
|--|--------------------|------------------|
| 28-11-02/400<br>DRAIN VALVE - REMOVAL/INSTALLATION   | U                  | Oct 30/15        |
| 28-11-02-000-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>DRAIN VALVE - REMOVAL      | U                  | Oct 30/15        |
| 28-11-02-400-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>DRAIN VALVE - INSTALLATION | U                  | Oct 30/15        |
| 28-11-02-000-802-A<br>DRAIN VALVE SEAT O-RING - REMOVAL  | U                  | Oct 30/15        |
| 28-11-02-400-802-A<br>DRAIN-VALVE SEAT O-RING - INSTALLATION                                   | U                  | Oct 30/15        |
| 28-11-02-000-803-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>DRAIN VALVE - REMOVAL      | U                  | Oct 30/15        |
| 28-11-02-400-803-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>DRAIN VALVE - INSTALLATION | U                  | Oct 30/15        |
| 28-11-03/400<br>DUMP VALVE - REMOVAL/INSTALLATION  | U                  | Oct 30/15        |
| 28-11-03-000-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>DUMP VALVE - REMOVAL       | U                  | Oct 30/15        |
| 28-11-03-400-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>DUMP VALVE - INSTALLATION  | U                  | Oct 30/15        |
| 28-11-03-000-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>DUMP VALVE - REMOVAL       | U                  | Oct 30/15        |
| 28-11-03-400-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>DUMP VALVE - INSTALLATION  | U                  | Oct 30/15        |
| 28-11-04/400<br>FLAP VALVE - REMOVAL/INSTALLATION  | U                  | Oct 30/15        |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 – EMB135

AIRCRAFT  
MAINTENANCE MANUAL


| PAGEBLOCK<br>TASK  | REVISION<br>STATUS | REVISION<br>DATE |
|--|--------------------|------------------|
| 28-11-04-000-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB<br/>FLAP VALVES - REMOVAL</i>           | U                  | Oct 30/15        |
| 28-11-04-400-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB<br/>FLAP VALVES - INSTALLATION</i>      | U                  | Oct 30/15        |
| 28-11-04-000-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB<br/>FLAP VALVES - REMOVAL</i>           | U                  | Oct 30/15        |
| 28-11-04-400-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB<br/>FLAP VALVES - INSTALLATION</i>      | U                  | Oct 30/15        |
| 28-11-04/500<br>FLAP VALVE - ADJUSTMENT/TEST   | U                  | Oct 30/15        |
| 28-11-04-700-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB<br/>FLAP VALVES - OPERATIONAL CHECK</i> | U                  | Oct 30/15        |
| 28-11-04-700-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB<br/>FLAP VALVES - OPERATIONAL CHECK</i> | U                  | Oct 30/15        |
| 28-11-05/600<br>FUEL FILLER CAP SEAL - INSPECTION/CHECK  | U                  | Oct 30/15        |
| 28-11-05-200-801-A<br>FUEL FILLER CAP SEAL - INSPECTION  | U                  | Oct 30/15        |
| 28-11-06/400<br>GRAVITY FILLER CAP - REMOVAL/INSTALLATION  | U                  | Oct 30/15        |
| 28-11-06-000-801-A<br>GRAVITY FILLER CAP - REMOVAL   | U                  | Oct 30/15        |
| 28-11-06-400-801-A<br>GRAVITY FILLER CAP - INSTALLATION  | U                  | Oct 30/15        |
| 28-12-01/400<br>FLOAT VALVE - REMOVAL/INSTALLATION   | U                  | Oct 30/15        |
| 28-12-01-000-801-A<br>FLOAT VALVE - REMOVAL  | U                  | Oct 30/15        |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 28  
Page 4 of 21  
Rev 55 - Oct 29/18



AIRCRAFT  
MAINTENANCE MANUAL

| PAGEBLOCK<br>TASK   | REVISION<br>STATUS | REVISION<br>DATE |
|---|--------------------|------------------|
| 28-12-01-400-801-A<br>FLOAT VALVE - INSTALLATION            | U                  | Oct 30/15        |
| 28-12-01/500<br>FLOAT VALVE - ADJUSTMENT/TEST               | U                  | Oct 30/15        |
| 28-12-01-700-801-A<br>VENT FLOAT VALVES - OPERATIONAL CHECK | U                  | Oct 30/15        |
| 28-12-02/600<br>TANK VENT PLUMBING - INSPECTION/CHECK       | U                  | Oct 30/15        |
| 28-12-02-200-801-A<br>TANK VENT PLUMBING - INSPECTION       | U                  | Oct 30/15        |
| 28-12-03/600<br>NACA AIR INLET - INSPECTION/CHECK           | U                  | Oct 30/15        |
| 28-12-03-200-801-A<br>NACA AIR INLET - INSPECTION           | U                  | Oct 30/15        |
| 28-12-04/500<br>FLAP VALVE - ADJUSTMENT/TEST                | U                  | Oct 30/15        |
| 28-12-04-700-801-A<br>FLAP VALVES - OPERATIONAL CHECK       | U                  | Oct 30/15        |
| 28-12-05/400<br>FLAME ARRESTOR - REMOVAL/INSTALLATION       | U                  | Oct 30/15        |
| 28-12-05-000-801-A<br>FLAME ARRESTOR - REMOVAL              | U                  | Oct 30/15        |
| 28-12-05-400-801-A<br>FLAME ARRESTOR - INSTALLATION         | U                  | Oct 30/15        |
| 28-12-05/500<br>FLAME ARRESTOR - ADJUSTMENT/TEST            | U                  | Oct 30/15        |
| 28-12-05-700-801-A<br>FLAME ARRESTOR - OPERATIONAL CHECK    | U                  | Oct 30/15        |
| 28-12-05/600<br>FLAME ARRESTOR - INSPECTION/CHECK           | U                  | Oct 30/15        |


Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



AIRCRAFT  
MAINTENANCE MANUAL

| PAGEBLOCK<br>TASK   | REVISION<br>STATUS | REVISION<br>DATE |
|---|--------------------|------------------|
| 28-12-05-200-801-A<br>FLAME ARRESTOR - INSPECTION   | U                  | Oct 30/15        |
| 28-20-00/600<br>DISTRIBUTION - INSPECTION/CHECK   | U                  | Oct 30/15        |
| 28-20-00-200-801-A<br>FUEL LINE SHROUD DRAINS - INSPECTION  | U                  | Oct 30/15        |
| 28-20-04/400<br>FUEL CONTROL PANEL - REMOVAL/INSTALLATION   | U                  | Oct 30/15        |
| 28-20-04-000-801-A<br>FUEL CONTROL PANEL - REMOVAL  | U                  | Oct 30/15        |
| 28-20-04-400-801-A<br>FUEL CONTROL PANEL - INSTALLATION   | U                  | Oct 30/15        |
| 28-20-04/500<br>FUEL CONTROL PANEL - ADJUSTMENT/TEST  | U                  | Oct 30/15        |
| 28-20-04-700-801-A<br>FUEL CONTROL PANEL - OPERATIONAL TEST   | U                  | Oct 30/15        |
| 28-21-01/400<br>ELECTRIC FUEL PUMP - REMOVAL/INSTALLATION   | U                  | Oct 30/15        |
| 28-21-01-000-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>ELECTRICAL FUEL PUMP - REMOVAL      | U                  | Oct 30/15        |
| 28-21-01-400-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>ELECTRICAL FUEL PUMP - INSTALLATION | U                  | Oct 30/15        |
| 28-21-01-000-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>ELECTRICAL FUEL PUMP - REMOVAL      | U                  | Oct 30/15        |
| 28-21-01-400-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>ELECTRICAL FUEL PUMP - INSTALLATION | U                  | Oct 30/15        |
| 28-21-01-040-801-A<br>ELECTRICAL FUEL PUMP - DEACTIVATION   | U                  | Oct 30/15        |
| 28-21-01-440-801-A<br>ELECTRICAL FUEL PUMP - REACTIVATION   | U                  | Oct 30/15        |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 - EMB135

AIRCRAFT  
MAINTENANCE MANUAL

| PAGEBLOCK<br><u>TASK</u> |  | REVISION<br>STATUS | REVISION<br>DATE |
|--------------------------|--|--------------------|------------------|
| 28-21-01/600             | ELECTRIC FUEL PUMP - INSPECTION/CHECK  | U                  | Oct 30/15        |
| 28-21-01-200-801-A       | <i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>WING ELECTRIC FUEL-PUMP CONNECTOR - INSPECTION     | U                  | Oct 30/15        |
| 28-21-01-200-802-A       | <i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>WING ELECTRIC FUEL-PUMP CONNECTOR - INSPECTION     | U                  | Oct 30/15        |
| 28-21-01-200-803-A       | <i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>FUEL-PUMP ELECTRICAL HARNESS - DETAILED INSPECTION | U                  | Oct 30/15        |
| 28-21-01-200-804-A       | <i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>FUEL-PUMP ELECTRICAL HARNESS - DETAILED INSPECTION | U                  | Oct 30/15        |
| 28-21-02/400             | EJECTOR PUMP - REMOVAL/INSTALLATION  | U                  | Oct 30/15        |
| 28-21-02-000-801-A       | EJECTOR PUMP - REMOVAL   | U                  | Oct 30/15        |
| 28-21-02-400-801-A       | EJECTOR PUMP - INSTALLATION  | U                  | Oct 30/15        |
| 28-21-02/600             | EJECTOR PUMP - INSPECTION/CHECK  | U                  | Oct 30/15        |
| 28-21-02-200-801-A       | EJECTOR PUMP - VISUAL INSPECTION   | U                  | Oct 30/15        |
| 28-21-03/400             | RELIEF VALVE - REMOVAL/INSTALLATION  | U                  | Oct 30/15        |
| 28-21-03-000-801-A       | <i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>CHECK/RELIEF VALVE - REMOVAL                       | U                  | Oct 30/15        |
| 28-21-03-400-801-A       | <i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>CHECK/RELIEF VALVE - INSTALLATION                  | U                  | Oct 30/15        |
| 28-21-03-000-802-A       | <i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>CHECK/RELIEF VALVE - REMOVAL                       | U                  | Oct 30/15        |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 - EMB135

AIRCRAFT  
MAINTENANCE MANUAL


| PAGEBLOCK<br>TASK   | REVISION<br>STATUS | REVISION<br>DATE |
|---|--------------------|------------------|
| 28-21-03-400-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB<br/>CHECK/RELIEF VALVE - INSTALLATION</i>        | U                  | Oct 30/15        |
| 28-21-03/500<br>RELIEF VALVE - ADJUSTMENT/TEST  | U                  | Oct 30/15        |
| 28-21-03-700-801-A<br>CHECK RELIEF VALVE - FUNCTIONAL CHECK   | U                  | Oct 30/15        |
| 28-21-04/400<br>FUEL-CROSSFEED VALVE - REMOVAL/INSTALLATION   | U                  | Oct 30/15        |
| 28-21-04-000-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB<br/>CROSSFEED VALVE - REMOVAL</i>                | U                  | Oct 30/15        |
| 28-21-04-400-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB<br/>CROSSFEED VALVE - INSTALLATION</i>           | U                  | Oct 30/15        |
| 28-21-04-000-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB<br/>CROSSFEED VALVE - REMOVAL</i>                | U                  | Oct 30/15        |
| 28-21-04-400-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB<br/>CROSSFEED VALVE - INSTALLATION</i>           | U                  | Oct 30/15        |
| 28-21-04/500<br>FUEL-CROSSFEED VALVE - ADJUSTMENT/TEST  | U                  | Oct 30/15        |
| 28-21-04-700-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB<br/>FUEL CROSSFEED VALVE - OPERATIONAL CHECK</i> | U                  | Oct 30/15        |
| 28-21-04-700-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB<br/>FUEL CROSSFEED VALVE - OPERATIONAL CHECK</i> | U                  | Oct 30/15        |
| 28-21-05/400<br>ENGINE SHUT-OFF VALVE - REMOVAL/INSTALLATION  | U                  | Oct 30/15        |
| 28-21-05-000-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB<br/>ENGINE SHUT-OFF VALVE - REMOVAL</i>          | U                  | Oct 30/15        |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 28  
Page 8 of 21  
Rev 55 - Oct 29/18



EMB145 - EMB135

AIRCRAFT  
MAINTENANCE MANUAL

| PAGEBLOCK<br>TASK  | REVISION<br>STATUS | REVISION<br>DATE |
|--|--------------------|------------------|
| 28-21-05-400-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB<br/>ENGINE SHUT-OFF VALVE - INSTALLATION</i>              | U                  | Oct 30/15        |
| 28-21-05-000-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB<br/>ENGINE SHUT-OFF VALVE - REMOVAL</i>                   | U                  | Oct 30/15        |
| 28-21-05-400-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB<br/>ENGINE SHUT-OFF VALVE - INSTALLATION</i>              | U                  | Oct 30/15        |
| 28-21-05/500<br><i>ENGINE SHUT-OFF VALVE - ADJUSTMENT/TEST</i>   | U                  | Oct 30/15        |
| 28-21-05-700-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB<br/>ENGINE 1/2 SHUT-OFF VALVES - OPERATIONAL CHECK</i>    | U                  | Oct 30/15        |
| 28-21-05-700-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB<br/>ENGINE 1/2 SHUT-OFF VALVES - OPERATIONAL CHECK</i>    | U                  | Oct 30/15        |
| 28-21-06/400<br><i>FUEL-FEED-LINE SUCTION CHECK VALVE - REMOVAL/INSTALLA-<br/>TION</i>                                 | U                  | Oct 30/15        |
| 28-21-06-000-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB<br/>FUEL-FEED-LINE SUCTION/CHECK VALVE - REMOVAL</i>      | U                  | Oct 30/15        |
| 28-21-06-400-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB<br/>FUEL-FEED-LINE SUCTION/CHECK VALVE - INSTALLATION</i> | U                  | Oct 30/15        |
| 28-21-06-000-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB<br/>FUEL-FEED-LINE SUCTION/CHECK VALVE - REMOVAL</i>      | U                  | Oct 30/15        |
| 28-21-06-400-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB<br/>FUEL-FEED-LINE SUCTION/CHECK VALVE - INSTALLATION</i> | U                  | Oct 30/15        |
| 28-21-09/600<br><i>MOTIVE-FLOW SUPPLY LINE - INSPECTION/CHECK</i>  | U                  | Oct 30/15        |
| 28-21-09-200-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB<br/>MOTIVE-FLOW SUPPLY LINE - VISUAL INSPECTION</i>       | U                  | Oct 30/15        |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 – EMB135

AIRCRAFT  
MAINTENANCE MANUAL


| PAGEBLOCK<br>TASK  | REVISION<br>STATUS | REVISION<br>DATE |
|--|--------------------|------------------|
| 28-21-09-200-802-A<br><br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>MOTIVE-FLOW SUPPLY LINE - VISUAL INSPECTION              | U                  | Oct 30/15        |
| 28-21-10/200 CONFIG-1<br><br><i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i><br>FUEL-FEED-LINE SHROUD - MAINTENANCE PRACTICES          | U                  | Oct 30/15        |
| 28-21-10-300-801-A CONFIG-1<br><br><i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i><br>FUEL-LINE SHROUD SEALING - MAINTENANCE PRACTICES | U                  | Oct 30/15        |
| 28-21-10/200 CONFIG-2<br><br><i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i><br>FUEL-FEED-LINE SHROUD - MAINTENANCE PRACTICES          | U                  | Oct 30/15        |
| 28-21-10-300-802-A CONFIG-2<br><br><i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i><br>FUEL-LINE SHROUD SEALING - MAINTENANCE PRACTICES | U                  | Oct 30/15        |
| 28-21-10/400 CONFIG-1<br><br><i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i><br>FUEL-FEED-LINE SHROUD - REMOVAL/INSTALLATION           | U                  | Oct 30/15        |
| 28-21-10-000-801-A CONFIG-1<br><br><i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i><br>FUEL-FEED-LINE SHROUD - REMOVAL                  | U                  | Oct 30/15        |
| 28-21-10-400-801-A CONFIG-1<br><br><i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i><br>FUEL-FEED-LINE SHROUD - INSTALLATION             | U                  | Oct 30/15        |
| 28-21-10/400 CONFIG-2<br><br><i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i><br>FUEL-FEED-LINE SHROUD - REMOVAL/INSTALLATION           | U                  | Oct 30/15        |
| 28-21-10-000-802-A CONFIG-2<br><br><i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i><br>FUEL-FEED-LINE SHROUD - REMOVAL                  | U                  | Oct 30/15        |
| 28-21-10-400-802-A CONFIG-2<br><br><i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i><br>FUEL-FEED-LINE SHROUD - INSTALLATION             | U                  | Oct 30/15        |
| 28-21-10/500 CONFIG-1<br><br><i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i><br>FUEL-FEED-LINE SHROUD - ADJUSTMENT/TEST                | U                  | Oct 30/15        |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 28  
Page 10 of 21  
Rev 55 - Oct 29/18



EMB145 – EMB135

AIRCRAFT  
MAINTENANCE MANUAL

| PAGEBLOCK<br>TASK   | REVISION<br>STATUS | REVISION<br>DATE |
|---|--------------------|------------------|
| 28-21-10-700-801-A CONFIG-1<br><i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i><br>ENGINE FUEL-FEED-LINE SHROUD - OPERATIONAL TEST | U                  | Oct 30/15        |
| 28-21-10/500 CONFIG-2<br><i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i><br>FUEL-FEED-LINE SHROUD - ADJUSTMENT/TEST               | U                  | Oct 30/15        |
| 28-21-10-700-802-A CONFIG-2<br><i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i><br>ENGINE FUEL-FEED-LINE SHROUD - OPERATIONAL TEST | U                  | Oct 30/15        |
| <b>28-21-11/500</b><br>FUEL FEED LINE - ADJUSTMENT/TEST   | U                  | Oct 30/15        |
| <b>28-21-11-700-801-A</b><br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>FUEL-FEED-LINE LEAK TEST - OPERATIONAL TEST      | U                  | Oct 30/15        |
| <b>28-21-11-700-802-A</b><br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>FUEL-FEED-LINE LEAK TEST - OPERATIONAL TEST      | U                  | Oct 30/15        |
| <b>28-21-11/800</b><br>FUEL FEED LINE - REPAIR  | U                  | Oct 30/15        |
| <b>28-21-11-300-801-A</b><br>FUEL FLEXIBLE HOSE - REPAIR  | U                  | Oct 30/15        |
| <b>28-21-12/400</b><br>MOTIVE-FLOW CHECK VALVE - REMOVAL/INSTALLATION   | U                  | Oct 30/15        |
| <b>28-21-12-000-801-A</b><br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>MOTIVE-FLOW CHECK VALVE - REMOVAL                | U                  | Oct 30/15        |
| <b>28-21-12-400-801-A</b><br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>MOTIVE-FLOW CHECK VALVE - INSTALLATION           | U                  | Oct 30/15        |
| <b>28-21-12-000-802-A</b><br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>MOTIVE-FLOW CHECK VALVE - REMOVAL                | U                  | Oct 30/15        |
| <b>28-21-12-400-802-A</b><br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>MOTIVE-FLOW CHECK VALVE - INSTALLATION           | U                  | Oct 30/15        |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 28  
Page 11 of 21  
Rev 55 - Oct 29/18



EMB145 - EMB135

AIRCRAFT  
MAINTENANCE MANUAL

| PAGEBLOCK<br><u>TASK</u> |   | <u>REVISION<br/>STATUS</u> | <u>REVISION<br/>DATE</u> |
|--------------------------|---|----------------------------|--------------------------|
| 28-21-13/400             | FUEL LINE JOINTS - REMOVAL/INSTALLATION   | U                          | Oct 30/15                |
| 28-21-13-000-801-A       | <i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>FUEL LINE JOINTS - REMOVAL        | U                          | Oct 30/15                |
| 28-21-13-400-801-A       | <i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>FUEL LINE JOINTS - INSTALLATION   | U                          | Oct 30/15                |
| 28-21-13-000-802-A       | <i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>FUEL LINE JOINTS - REMOVAL        | U                          | Oct 30/15                |
| 28-21-13-400-802-A       | <i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>FUEL LINE JOINTS - INSTALLATION   | U                          | Oct 30/15                |
| 28-21-14/400             | FUEL PUMP CONTACTOR - REMOVAL/INSTALLATION                                      | U                          | Oct 30/15                |
| 28-21-14-000-801-A       | FUEL PUMP CONTACTOR - REMOVAL   | U                          | Oct 30/15                |
| 28-21-14-400-801-A       | FUEL PUMP CONTACTOR - INSTALLATION  | U                          | Oct 30/15                |
| 28-22-01/400             | APU SHUT-OFF VALVE - REMOVAL/INSTALLATION                                       | U                          | Oct 30/15                |
| 28-22-01-000-801-A       | <i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>APU SHUT-OFF VALVE - REMOVAL      | U                          | Oct 31/17                |
| 28-22-01-400-801-A       | <i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>APU SHUT-OFF VALVE - INSTALLATION | U                          | Oct 31/17                |
| 28-22-01-000-802-A       | <i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>APU SHUT-OFF VALVE - REMOVAL      | U                          | Oct 30/15                |
| 28-22-01-400-802-A       | <i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>APU SHUT-OFF VALVE - INSTALLATION | U                          | Oct 30/15                |
| 28-22-01-040-801-A       | APU SHUT-OFF VALVE - DEACTIVATION   | U                          | Oct 30/15                |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 28  
Page 12 of 21  
Rev 55 - Oct 29/18



AIRCRAFT  
MAINTENANCE MANUAL

| PAGEBLOCK<br>TASK  | REVISION<br>STATUS | REVISION<br>DATE |
|--|--------------------|------------------|
| 28-22-01-440-801-A<br>APU SHUT-OFF VALVE - REACTIVATION  | U                  | Oct 30/15        |
| 28-22-01/500<br>APU SHUT-OFF VALVE - ADJUSTMENT/TEST   | U                  | Oct 30/15        |
| 28-22-01-700-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>APU SHUT-OFF VALVE - OPERATIONAL CHECK               | U                  | Oct 30/15        |
| 28-22-01-700-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>APU SHUT-OFF VALVE - OPERATIONAL CHECK               | U                  | Oct 30/15        |
| 28-22-03/500 CONFIG-1<br><i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i><br>APU FUEL FEED LINE SHROUD - ADJUSTMENT/TEST        | U                  | Oct 30/15        |
| 28-22-03-700-801-A CONFIG-1<br><i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i><br>APU FUEL-FEED-LINE SHROUD - OPERATIONAL TEST | U                  | Oct 30/15        |
| 28-22-03/500 CONFIG-2<br><i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i><br>APU FUEL FEED LINE SHROUD - ADJUSTMENT/TEST        | U                  | Oct 30/15        |
| 28-22-03-700-802-A CONFIG-2<br><i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i><br>APU FUEL-FEED-LINE SHROUD - OPERATIONAL TEST | U                  | Oct 30/15        |
| 28-23-01/400<br>FUELING/DEFUELING ADAPTER - REMOVAL/INSTALLATION   | U                  | Oct 30/15        |
| 28-23-01-000-801-A<br>PRESSURE FUELING/DEFUELING ADAPTER - REMOVAL   | U                  | Oct 30/15        |
| 28-23-01-400-801-A<br>PRESSURE FUELING/DEFUELING ADAPTER - INSTALLATION  | U                  | Oct 30/15        |
| 28-23-02/400<br>FUELING SHUT-OFF VALVE - REMOVAL/INSTALLATION  | U                  | Oct 30/15        |
| 28-23-02-000-801-A<br>FUELING SHUT-OFF VALVE - REMOVAL   | U                  | Oct 30/15        |
| 28-23-02-400-801-A<br>FUELING SHUT-OFF VALVE - INSTALLATION  | U                  | Oct 30/15        |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 - EMB135

AIRCRAFT  
MAINTENANCE MANUAL


| <u>PAGEBLOCK<br/>TASK</u> |   | <u>REVISION<br/>STATUS</u> | <u>REVISION<br/>DATE</u> |
|---------------------------|---|----------------------------|--------------------------|
| 28-23-03/400              | PILOT VALVE - REMOVAL/INSTALLATION                                | U                          | Oct 30/15                |
| 28-23-03-000-801-A        | EFFECTIVITY: ACFT WITH WET WINGSTUB<br>PILOT VALVE - REMOVAL      | U                          | Oct 30/15                |
| 28-23-03-400-801-A        | EFFECTIVITY: ACFT WITH WET WINGSTUB<br>PILOT VALVE - INSTALLATION | U                          | Apr 29/16                |
| 28-23-03-000-802-A        | EFFECTIVITY: ACFT WITH DRY WINGSTUB<br>PILOT VALVE - REMOVAL      | U                          | Oct 30/15                |
| 28-23-03-400-802-A        | EFFECTIVITY: ACFT WITH DRY WINGSTUB<br>PILOT VALVE - INSTALLATION | U                          | Apr 29/16                |
| 28-23-03/600              | PILOT VALVE - INSPECTION/CHECK                                    | U                          | Oct 30/15                |
| 28-23-03-200-801-A        | PILOT VALVE HARNESS - INSPECTION                                  | U                          | Oct 30/15                |
| 28-23-04/400              | VENT VALVE - REMOVAL/INSTALLATION                                 | U                          | Oct 30/15                |
| 28-23-04-000-801-A        | VENT VALVE - REMOVAL  | U                          | Oct 30/15                |
| 28-23-04-400-801-A        | VENT VALVE - INSTALLATION   | U                          | Apr 29/16                |
| 28-23-04/600              | VENT VALVE - INSPECTION/CHECK                                     | U                          | Oct 30/15                |
| 28-23-04-200-801-A        | VENT VALVE HARNESS - INSPECTION                                   | U                          | Oct 30/15                |
| 28-23-05/400              | FUEL PRESSURE SWITCH - REMOVAL/INSTALLATION                       | U                          | Oct 30/15                |
| 28-23-05-000-801-A        | FUEL PRESSURE SWITCH - REMOVAL                                    | U                          | Oct 30/15                |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 28  
Page 14 of 21  
Rev 55 - Oct 29/18



AIRCRAFT  
MAINTENANCE MANUAL

| PAGEBLOCK<br>TASK   | REVISION<br>STATUS | REVISION<br>DATE |
|---|--------------------|------------------|
| 28-23-05-400-801-A<br>FUEL PRESSURE SWITCH - INSTALLATION   | U                  | Oct 30/15        |
| 28-23-06/400<br>FUEL RESTRICTOR - REMOVAL/INSTALLATION  | U                  | Oct 30/15        |
| 28-23-06-000-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>FUEL RESTRICTOR - REMOVAL               | U                  | Oct 30/15        |
| 28-23-06-400-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>FUEL RESTRICTOR - INSTALLATION          | U                  | Oct 30/15        |
| 28-23-06-000-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>FUEL RESTRICTOR - REMOVAL               | U                  | Oct 30/15        |
| 28-23-06-400-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>FUEL RESTRICTOR - INSTALLATION          | U                  | Oct 30/15        |
| 28-23-07/400<br>DEFUELING SHUT-OFF VALVE - REMOVAL/INSTALLATION   | U                  | Oct 30/15        |
| 28-23-07-000-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>DEFUELING SHUT-OFF VALVE - REMOVAL      | U                  | Oct 30/15        |
| 28-23-07-400-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>DEFUELING SHUT-OFF VALVE - INSTALLATION | U                  | Oct 30/15        |
| 28-23-07-000-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>DEFUELING SHUT-OFF VALVE - REMOVAL      | U                  | Oct 30/15        |
| 28-23-07-400-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>DEFUELING SHUT-OFF VALVE - INSTALLATION | U                  | Oct 30/15        |
| 28-23-07-040-801-A<br>DEFUELING SHUT-OFF VALVE - DEACTIVATION   | U                  | Oct 30/15        |
| 28-23-07-440-801-A<br>DEFUELING SHUT-OFF VALVE - REACTIVATION   | U                  | Oct 30/15        |
| 28-23-07/500<br>DEFUELING SHUT-OFF VALVE - ADJUSTMENT/TEST  | U                  | Oct 30/15        |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 - EMB135

AIRCRAFT  
MAINTENANCE MANUAL


| PAGEBLOCK<br>TASK   | REVISION<br>STATUS | REVISION<br>DATE |
|---|--------------------|------------------|
| 28-23-07-700-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB<br/>DEFUELING SHUT-OFF VALVE - OPERATIONAL CHECK</i>   | U                  | Oct 30/15        |
| 28-23-07-700-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB<br/>DEFUELING SHUT-OFF VALVE - OPERATIONAL CHECK</i>   | U                  | Oct 30/15        |
| 28-23-08/400<br><i>FUEL-QUANTITY-SELECTOR REPEATER INDICATOR - REMOVAL/<br/>INSTALLATION</i>  | U                  | Oct 30/15        |
| 28-23-08-000-801-A<br><i>FUEL-QUANTITY-SELECTOR REPEATER - REMOVAL</i>  | U                  | Oct 30/15        |
| 28-23-08-400-801-A<br><i>FUEL-QUANTITY-SELECTOR REPEATER - INSTALLATION</i>   | U                  | Oct 30/15        |
| 28-23-09/400<br><i>REFUELING/DEFUELING CONTROL PANEL - REMOVAL/INSTALLA-<br/>TION</i>   | U                  | Oct 30/15        |
| 28-23-09-000-801-A<br><i>REFUELING/DEFUELING CONTROL PANEL - REMOVAL</i>  | U                  | Oct 30/15        |
| 28-23-09-400-801-A<br><i>REFUELING/DEFUELING CONTROL PANEL - INSTALLATION</i>   | U                  | Oct 30/15        |
| 28-23-18/400<br><i>EFFECTIVITY: AIRCRAFT WITH HIGH LEVEL EXCEEDING INDICA-<br/>TIONS SYSTEM<br/>WING HIGH LEVEL EXCEEDING FLOAT SWITCH - REMOVAL/INSTAL-<br/>LATION</i> | U                  | Oct 30/15        |
| 28-23-18-000-801-A<br><i>EFFECTIVITY: AIRCRAFT WITH HIGH LEVEL EXCEEDING INDICA-<br/>TIONS SYSTEM<br/>WING HIGH-LEVEL EXCEEDING FLOAT SWITCH - REMOVAL</i>              | U                  | Oct 30/15        |
| 28-23-18-400-801-A<br><i>EFFECTIVITY: AIRCRAFT WITH HIGH LEVEL EXCEEDING INDICA-<br/>TIONS SYSTEM<br/>WING HIGH-LEVEL EXCEEDING FLOAT SWITCH - INSTALLATION</i>         | U                  | Oct 30/15        |
| 28-23-19/400<br><i>EFFECTIVITY: AIRCRAFT WITH HIGH LEVEL EXCEEDING INDICATIONS<br/>SYSTEM<br/>WING LEVEL CONTROL UNIT - REMOVAL/INSTALLATION</i>                        | U                  | Oct 30/15        |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 28  
Page 16 of 21  
Rev 55 - Oct 29/18



AIRCRAFT  
MAINTENANCE MANUAL

| PAGEBLOCK<br>TASK   | REVISION<br>STATUS | REVISION<br>DATE |
|---|--------------------|------------------|
| 28-23-19-000-801-A<br><i>EFFECTIVITY: AIRCRAFT WITH HIGH LEVEL EXCEEDING INDICATIONS SYSTEM</i><br>WING LEVEL CONTROL UNIT - REMOVAL      | U                  | Oct 30/15        |
| 28-23-19-400-801-A<br><i>EFFECTIVITY: AIRCRAFT WITH HIGH LEVEL EXCEEDING INDICATIONS SYSTEM</i><br>WING LEVEL CONTROL UNIT - INSTALLATION | U                  | Oct 30/15        |
| 28-23-21/400<br>FUELING/DEFUELING ADAPTER CAP - REMOVAL/INSTALLATION  | U                  | Oct 30/15        |
| 28-23-21-000-801-A<br>FUELING/DEFUELING ADAPTER CAP - REMOVAL   | U                  | Oct 30/15        |
| 28-23-21-400-801-A<br>FUELING/DEFUELING ADAPTER CAP - INSTALLATION  | U                  | Oct 30/15        |
| 28-41-00/500<br>ELECTRICAL FUEL QUANTITY INDICATING - ADJUSTMENT/TEST   | U                  | Oct 30/15        |
| 28-41-00-700-801-A<br>ELECTRICAL FUEL QUANTITY - OPERATIONAL CHECK  | U                  | Oct 30/15        |
| 28-41-00/600 CONFIG-1<br><i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i><br>ELECTRICAL FUEL QUANTITY INDICATING - INSPECTION/CHECK              | U                  | Oct 30/15        |
| 28-41-00-200-801-A CONFIG-1<br><i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i><br>FUEL-QUANTITY INDICATION HARNESS - INSPECTION                 | U                  | Oct 30/15        |
| 28-41-00/600 CONFIG-2<br><i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i><br>ELECTRICAL FUEL QUANTITY INDICATING - INSPECTION/CHECK              | U                  | Oct 30/15        |
| 28-41-00-200-801-A CONFIG-2<br><i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i><br>FUEL-QUANTITY INDICATION HARNESS - INSPECTION                 | U                  | Oct 30/15        |
| 28-41-01/400<br>FUEL CONDITIONING UNIT (FCU) - REMOVAL/INSTALLATION   | U                  | Oct 30/15        |
| 28-41-01-000-801-A<br>FUEL CONDITIONING UNIT - REMOVAL  | U                  | Oct 30/15        |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 - EMB135

AIRCRAFT  
MAINTENANCE MANUAL


| PAGEBLOCK<br>TASK  | REVISION<br>STATUS | REVISION<br>DATE |
|--|--------------------|------------------|
| 28-41-01-400-801-A<br>FUEL CONDITIONING UNIT - INSTALLATION  | U                  | Oct 30/15        |
| 28-41-01/500<br>FUEL CONDITIONING UNIT (FCU) - ADJUSTMENT/TEST   | U                  | Oct 30/15        |
| 28-41-01-700-801-A<br>FUEL CONDITIONING UNIT - FUNCTIONAL TEST   | U                  | Oct 30/15        |
| 28-41-02/400<br>TANK UNIT - REMOVAL/INSTALLATION   | U                  | Oct 30/15        |
| 28-41-02-000-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>TANK UNITS - REMOVAL                                 | U                  | Oct 30/15        |
| 28-41-02-400-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>TANK UNITS - INSTALLATION                            | U                  | Oct 30/15        |
| 28-41-02-000-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>TANK UNITS - REMOVAL                                 | U                  | Oct 30/15        |
| 28-41-02-400-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>TANK UNITS - INSTALLATION                            | U                  | Oct 30/15        |
| 28-41-02/600<br>TANK UNIT - INSPECTION/CHECK   | U                  | Oct 30/15        |
| 28-41-02-200-801-A<br><i>EFFECTIVITY: EMB-145LR/LU AND EMB-135LR/KL MODELS</i><br>TANK-UNITS - INSPECTION                | U                  | Oct 30/15        |
| 28-41-02-200-802-A<br><i>EFFECTIVITY: EMB-145MR/MP/MK/ER/EP/EU AND EMB-135ER/KE</i><br>MODELS<br>TANK-UNITS - INSPECTION | U                  | Oct 30/15        |
| 28-41-03/400<br>TANK-UNIT HARNESS ASSEMBLY - REMOVAL/INSTALLATION  | U                  | Oct 30/15        |
| 28-41-03-000-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>TANK-UNIT HARNESS ASSEMBLY - REMOVAL                 | U                  | Oct 30/15        |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 28  
Page 18 of 21  
Rev 55 - Oct 29/18



EMB145 - EMB135

AIRCRAFT  
MAINTENANCE MANUAL

| PAGEBLOCK<br>TASK  | REVISION<br>STATUS | REVISION<br>DATE |
|--|--------------------|------------------|
| 28-41-03-400-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB<br/>TANK-UNIT HARNESS ASSEMBLY - INSTALLATION</i>             | U                  | Oct 30/15        |
| 28-41-03-000-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB<br/>TANK-UNIT HARNESS ASSEMBLY - REMOVAL</i>                  | U                  | Oct 30/15        |
| 28-41-03-400-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB<br/>TANK-UNIT HARNESS ASSEMBLY - INSTALLATION</i>             | U                  | Oct 30/15        |
| 28-41-03/600<br>TANK-UNIT HARNESS ASSEMBLY - INSPECTION/CHECK  | U                  | Oct 30/15        |
| 28-41-03-200-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB<br/>TANK-UNIT HARNESS ASSEMBLY - INSPECTION</i>               | U                  | Oct 30/15        |
| 28-41-03-200-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB<br/>TANK-UNIT HARNESS ASSEMBLY - INSPECTION</i>               | U                  | Oct 30/15        |
| 28-42-01/400<br>MEASURING STICK ASSEMBLY - REMOVAL/INSTALLATION  | U                  | Oct 30/15        |
| 28-42-01-000-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB<br/>MEASURING STICK ASSEMBLY - REMOVAL</i>                    | U                  | Oct 30/15        |
| 28-42-01-400-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB<br/>MEASURING STICK ASSEMBLY - INSTALLATION</i>               | U                  | Oct 30/15        |
| 28-42-01-000-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB<br/>MEASURING STICK ASSEMBLY - REMOVAL</i>                    | U                  | Oct 30/15        |
| 28-42-01-400-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB<br/>MEASURING STICK ASSEMBLY - INSTALLATION</i>               | U                  | Oct 30/15        |
| 28-43-00/500<br>FUEL TEMPERATURE INDICATION - ADJUSTMENT/TEST  | U                  | Oct 30/15        |
| 28-43-00-700-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB<br/>FUEL-TEMPERATURE INDICATION SYSTEM - FUNCTIONAL CHECK</i> | U                  | Oct 30/15        |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 28  
Page 19 of 21  
Rev 55 - Oct 29/18



EMB145 - EMB135

AIRCRAFT  
MAINTENANCE MANUAL


| PAGEBLOCK<br>TASK   | REVISION<br>STATUS | REVISION<br>DATE |
|---|--------------------|------------------|
| 28-43-00-700-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>FUEL-TEMPERATURE INDICATION SYSTEM - FUNCTIONAL CHECK | U                  | Oct 30/15        |
| 28-43-01/400<br>FUEL TEMPERATURE TRANSMITTER - REMOVAL/INSTALLATION   | U                  | Oct 30/15        |
| 28-43-01-000-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>FUEL TEMPERATURE SENSOR - REMOVAL                     | U                  | Oct 30/15        |
| 28-43-01-400-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>FUEL TEMPERATURE SENSOR - INSTALLATION                | U                  | Oct 30/15        |
| 28-43-01-000-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>FUEL TEMPERATURE SENSOR - REMOVAL                     | U                  | Oct 30/15        |
| 28-43-01-400-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>FUEL TEMPERATURE SENSOR - INSTALLATION                | U                  | Oct 30/15        |
| 28-43-02/400<br>FUEL TEMPERATURE SENSOR HOUSING ASSEMBLY - REMOVAL/<br>INSTALLATION                                       | U                  | Oct 30/15        |
| 28-43-02-000-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>FUEL TEMPERATURE SENSOR HOUSING - REMOVAL             | U                  | Oct 30/15        |
| 28-43-02-400-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>FUEL TEMPERATURE SENSOR HOUSING - INSTALLATION        | U                  | Oct 30/15        |
| 28-43-02-000-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>FUEL TEMPERATURE SENSOR HOUSING - REMOVAL             | U                  | Oct 30/15        |
| 28-43-02-400-802-A<br>FUEL TEMPERATURE SENSOR HOUSING - INSTALLATION  | U                  | Oct 30/15        |
| 28-44-00/500<br>FUEL LOW LEVEL WARNING - ADJUSTMENT/TEST  | U                  | Oct 30/15        |
| 28-44-00-700-801-A<br>FUEL LOW LEVEL WARNING SYSTEM - FUNCTIONAL CHECK  | U                  | Oct 30/15        |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 28  
Page 20 of 21  
Rev 55 - Oct 29/18



EMB145 - EMB135

AIRCRAFT  
MAINTENANCE MANUAL

| PAGEBLOCK<br><u>TASK</u>   | <u>REVISION<br/>STATUS</u> | <u>REVISION<br/>DATE</u> |
|--|----------------------------|--------------------------|
| 28-44-01/400<br>LOW LEVEL SENSOR - REMOVAL/INSTALLATION  | U                          | Oct 30/15                |
| 28-44-01-000-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>LOW LEVEL SENSORS - REMOVAL      | U                          | Oct 30/15                |
| 28-44-01-400-801-A<br><i>EFFECTIVITY: ACFT WITH WET WINGSTUB</i><br>LOW LEVEL SENSORS - INSTALLATION | U                          | Oct 30/15                |
| 28-44-01-000-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>LOW LEVEL SENSORS - REMOVAL      | U                          | Oct 30/15                |
| 28-44-01-400-802-A<br><i>EFFECTIVITY: ACFT WITH DRY WINGSTUB</i><br>LOW LEVEL SENSORS - INSTALLATION | U                          | Oct 30/15                |
| 28-45-00/500<br>FUEL LOW PRESSURE WARNING - ADJUSTMENT/TEST  | U                          | Oct 30/15                |
| 28-45-00-700-801-A<br>FUEL LOW-PRESSURE WARNING SYSTEM - OPERATIONAL CHECK                           | U                          | Oct 30/15                |
| 28-45-01/400<br>ENGINE LOW-PRESSURE SWITCH - REMOVAL/INSTALLATION                                    | U                          | Oct 30/15                |
| 28-45-01-000-801-A<br>ENGINE LOW-PRESSURE SWITCH - REMOVAL   | U                          | Oct 30/15                |
| 28-45-01-400-801-A<br>ENGINE LOW-PRESSURE SWITCH - INSTALLATION                                      | U                          | Oct 30/15                |
| 28-45-02/400<br>APU LOW-PRESSURE SWITCH - REMOVAL/INSTALLATION                                       | U                          | Oct 30/15                |
| 28-45-02-000-801-A<br>APU LOW-PRESSURE SWITCH - REMOVAL  | U                          | Oct 30/15                |
| 28-45-02-400-801-A<br>APU LOW-PRESSURE SWITCH - INSTALLATION   | U                          | Oct 30/15                |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 28  
Page 21 of 21  
Rev 55 - Oct 29/18

