



## AIRCRAFT MAINTENANCE MANUAL

### BAGGAGE DOOR - SERVICING

EFFECTIVITY: ALL

#### 1. General

- A. The procedure for the lubrication of the Baggage Door is given in [AMM TASK 52-31-00-600-801-A/300](#).

