



## AIRCRAFT MAINTENANCE MANUAL

### OIL FILTER ELEMENT - REMOVAL/INSTALLATION

EFFECTIVITY: ALL

#### 1. General

- A. This section gives the procedure to remove/install the Oil Filter Element.
- B. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
79-21-02-000-801-A	OIL FILTER ELEMENT - REMOVAL	ALL
79-21-02-400-801-A	OIL FILTER ELEMENT - INSTALLATION	ALL



EMB145 - EMB135

AIRCRAFT  
MAINTENANCE MANUAL

TASK 79-21-02-000-801-A

EFFECTIVITY: ALL

2. OIL FILTER ELEMENT - REMOVAL

A. General

- (1) To do the task, see the instructions contained in Rolls-Royce MM CSP 34022.

B. References

REFERENCE	DESIGNATION
AMM MPP 71-00-00/200	- MAINTENANCE PRACTICES
AMM TASK 71-12-01-000-801-A/400	ENGINE LOWER COWLING - OPENING

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
413	Lower Cowling	LH Engine
423	Lower Cowling	RH Engine

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

ITEM	DESCRIPTION	PURPOSE	QTY
Commercially available	Work Stand	To get access to the engine	1

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Engine

I. Preparation

SUBTASK 841-002-A

**WARNING: BEFORE YOU DO THE TASK OBEY THE SAFETY PRECAUTIONS GIVEN IN ( AMM MPP 71-00-00/200) TO PREVENT INJURY TO THE PERSONS AND DAMAGE TO THE MATERIAL.**

- (1) On the circuit breaker panel, open the circuit breakers below and attach a DO-NOT-CLOSE tag to them.
- START 1/2.



AIRCRAFT  
MAINTENANCE MANUAL

- (2) Put the work stand in the work area.
- (3) Open the lower cowling ( [AMM TASK 71-12-01-000-801-A/400](#) ) to get access to the engine oil tank.

J. Removal

SUBTASK 020-002-A

- (1) Remove the Oil Filter Element. Refer to the last revision of Rolls-Royce MM CSP 34022.

**TASK 79-21-02-400-801-A**
**EFFECTIVITY: ALL**
**3. OIL FILTER ELEMENT - INSTALLATION**
**A. General**

- (1) To do the task, see the instructions contained in Rolls-Royce MM CSP 34022.

**B. References**

<i>REFERENCE</i>	<i>DESIGNATION</i>
AMM MPP 71-00-00/200	- MAINTENANCE PRACTICES
AMM TASK 71-12-01-400-801-A/400	ENGINE LOWER COWLING - CLOSING

**C. Zones and Accesses**

Not Applicable

**D. Tools and Equipment**

Not Applicable

**E. Auxiliary Items**

<i>ITEM</i>	<i>DESCRIPTION</i>	<i>PURPOSE</i>	<i>QTY</i>
Commercially available	Work Stand	To get access to the engine	1

**F. Consumable Materials**

Not Applicable

**G. Expandable Parts**

Not Applicable

**H. Persons Recommended**

<i>QTY</i>	<i>FUNCTION</i>	<i>PLACE</i>
1	Does the task	Engine

**I. Installation**
**SUBTASK 420-002-A**

**WARNING: BEFORE YOU DO THE TASK OBEY THE SAFETY PRECAUTIONS GIVEN IN ( AMM MPP 71-00-00/200) TO PREVENT INJURY TO THE PERSONS AND DAMAGE TO THE MATERIAL.**

- (1) Install the Oil Filter Element. Refer to the last revision of Rolls-Royce MM CSP 34022.

**J. Follow-on**
**SUBTASK 842-002-A**

- (1) Close the lower cowling ( AMM TASK 71-12-01-400-801-A/400).

- (2) Remove the work stand.



AIRCRAFT  
MAINTENANCE MANUAL

- (3) On the circuit breaker panel, close the circuit breakers below and remove the DO-NOT-CLOSE tag from them.
  - START 1/2.
- (4) Refer to the Rolls-Royce MM CSP 34022 to do the related check procedures after an engine LRU maintenance procedure, as applicable.

