



AIRCRAFT
MAINTENANCE MANUAL

**BAGGAGE-COMPARTMENT FIRE EXTINGUISHER BOTTLE CARTRIDGE - MAINTENANCE
PRACTICES**

EFFECTIVITY: CLASS-C BAGGAGE COMPARTMENT

1. General

- A. This section gives the procedures to replace and discard the cartridge of the baggage-compartment fire-extinguisher bottles.
- B. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

| <i>TASK NUMBER</i> | <i>DESCRIPTION</i> | <i>EFFECTIVITY</i> |
|----------------------|--|--------------------------------|
| 26-23-02-960-801-A ♦ | BAGGAGE FIRE EXTINGUISHER BOT- TLES CARTRIDGE - REPLACEMENT/ DISCARD | CLASS-C BAGGAGE COMPARTMENT |



EMB145 – EMB135

AIRCRAFT
MAINTENANCE MANUAL

TASK 26-23-02-960-801-A

EFFECTIVITY: CLASS-C BAGGAGE COMPARTMENT

2. BAGGAGE FIRE EXTINGUISHER BOTTLES CARTRIDGE - REPLACEMENT/DISCARD

A. General

- (1) To do the task, refer to the instructions in the Pacific Scientific CMM ATA 26-23-46 (for high-rate bottle) and Pacific Scientific CMM ATA 26-23-47 (for metering bottle).

B. References

| REFERENCE | DESIGNATION |
|-------------------------------------|--|
| AMM TASK 26-23-01-000-801-A/400 | BAGGAGE FIRE EXTINGUISHER BOTTLES - REMOVAL |
| AMM TASK 26-23-01-400-801-A/400 | BAGGAGE FIRE EXTINGUISHER BOTTLES - INSTALLATION |
| Pacific Scientific CMM ATA 26-23-46 | - |
| Pacific Scientific CMM ATA 26-23-47 | - |

C. Zones and Accesses

| ZONE | PANEL/DOOR | LOCATION |
|------|------------|------------------------|
| 272 | 272DR | Electronic compartment |

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

| ITEM | DESCRIPTION | PURPOSE | QTY |
|------------------------|-------------|---|-----|
| Commercially available | Ladder | To get access to the electronic compartment | 1 |

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

| QTY | FUNCTION | PLACE |
|-----|---------------|------------------------|
| 1 | Does the task | Electronic compartment |

I. Preparation

SUBTASK 841-002-A

- (1) Remove the baggage fire extinguisher bottles ([AMM TASK 26-23-01-000-801-A/400](#)).



AIRCRAFT
MAINTENANCE MANUAL

- J. Discard Baggage Fire Extinguishing Bottles (high rate and metering)Cartridges

SUBTASK 960-002-A

WARNING: THE CARTRIDGES ARE EXPLOSIVE DEVICES. ACCIDENTAL DETONATION OF A CARTRIDGE CAN CAUSE INJURY. DURING THE TASK, OBEY ALL SAFETY PRECAUTIONS CONTAINED IN THE PACIFIC SCIENTIFIC CMM.

(1) Remove and discard the cartridge. Refer to the last revision of Pacific Scientific CMM ATA 26-23-46 (for high-rate bottle) and Pacific Scientific CMM ATA 26-23-47 (for metering bottle).

(2) Install the new cartridge. Refer to the last revision of Pacific Scientific CMM ATA 26-23-46 (for high-rate bottle) and Pacific Scientific CMM ATA 26-23-47 (for metering bottle).

- K. Follow-on

SUBTASK 842-002-A

(1) Install the baggage fire extinguisher bottles ([AMM TASK 26-23-01-400-801-A/400](#)).

