


TABLE OF CONTENTS

| <u>PAGEBLOCK TASK</u> | <u>REVISION STATUS</u> | <u>REVISION DATE</u> |
|--|----------------------------|--------------------------|
| 21-00-00/200 AIR CONDITIONING - MAINTENANCE PRACTICES | U | Oct 30/15 |
| 21-00-00-860-801-A PROCEDURE TO TURN THE COOLING PACKS ON | R | Oct 29/18 |
| 21-00-00-860-802-A PROCEDURE TO TURN THE COOLING PACKS OFF | U | Oct 30/15 |
| 21-00-00-860-803-A CONNECTION/DISCONNECTION OF AN EXTERNAL CONDITIONED-AIR SOURCE | R | Oct 29/18 |
| 21-00-00-860-804-A PROCEDURE TO TURN THE COOLING PACKS ON UNDER COLD SOAK CONDITIONS | R | Oct 29/18 |
| 21-20-00/500 DISTRIBUTION - ADJUSTMENT/TEST | U | Oct 30/15 |
| 21-20-00-700-801-A CONDITIONED AIR DISTRIBUTION SYSTEM - OPERATIONAL CHECK | R | Oct 29/18 |
| 21-20-00/700 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> DISTRIBUTION - CLEANING/PAINTING | U | Oct 30/15 |
| 21-20-00-100-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> CONDITIONED AIR DUCTS - CLEANING | U | Oct 30/15 |
| 21-20-00-100-803-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> AIR CONDITIONING SYSTEM - OIL CONTAMINATION - CLEANING | U | Oct 31/16 |
| 21-20-00-100-805-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> CONDITIONED AIR DUCTS - OIL DECONTAMINATION - CLEANING | U | Oct 30/15 |
| 21-20-00/700 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> DISTRIBUTION - CLEANING/PAINTING | U | Oct 30/15 |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



AIRCRAFT MAINTENANCE MANUAL


| PAGEBLOCK <u>TASK</u> | <u>REVISION STATUS</u> | <u>REVISION DATE</u> |
|---|----------------------------|--------------------------|
| 21-20-00-100-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 CONDITIONED AIR DUCTS - CLEANING</i> | U | Oct 30/15 |
| 21-20-00-100-804-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 AIR CONDITIONING SYSTEM - OIL CONTAMINATION - CLEANING</i> | U | Oct 31/16 |
| 21-20-00-100-806-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 CONDITIONED AIR DUCTS - OIL DECONTAMINATION - CLEANING</i> | U | Oct 30/15 |
| 21-20-00/800 DISTRIBUTION - REPAIR | U | Oct 30/15 |
| 21-20-00-300-801-A CONDITIONED AIR POLYCARBONATE DUCTS - REPAIR | U | Oct 30/15 |
| 21-20-00-300-802-A CONDITIONED AIR POLYCARBONATE DUCTS - REPAIR | U | Oct 30/15 |
| 21-20-00-300-803-A CONDITIONED AIR GLASS FIBER DUCTS - REPAIR | U | Oct 30/15 |
| 21-20-00-300-804-A CONDITIONED AIR GLASS FIBER DUCTS - REPAIR | U | Oct 30/15 |
| 21-20-01/400 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 THERMAL INSULATING BLANKETS - REMOVAL/INSTALLATION</i> | U | Oct 30/15 |
| 21-20-01-000-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 THERMAL INSULATING BLANKET - REMOVAL</i> | U | Oct 30/15 |
| 21-20-01-400-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 THERMAL INSULATING BLANKET - INSTALLATION</i> | U | Oct 30/15 |
| 21-20-01/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 THERMAL INSULATING BLANKETS - REMOVAL/INSTALLATION</i> | U | Oct 30/15 |
| 21-20-01-000-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 THERMAL INSULATING BLANKET - REMOVAL</i> | U | Oct 30/15 |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 21
Page 2 of 30
Rev 55 - Oct 29/18



EMB145 – EMB135

AIRCRAFT
MAINTENANCE MANUAL


| PAGEBLOCK TASK | REVISION STATUS | REVISION DATE |
|---|--------------------|------------------|
| 21-20-01-400-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> THERMAL INSULATING BLANKET - INSTALLATION | U | Oct 30/15 |
| 21-20-02/400 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> THERMAL SWITCHES - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-20-02-000-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> THERMAL SWITCH - REMOVAL | U | Oct 30/15 |
| 21-20-02-400-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> THERMAL SWITCH - INSTALLATION | U | Oct 30/15 |
| 21-20-02/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> THERMAL SWITCHES - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-20-02-000-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> THERMAL SWITCH - REMOVAL | U | Oct 30/15 |
| 21-20-02-400-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> THERMAL SWITCH - INSTALLATION | U | Oct 30/15 |
| 21-20-02/800 THERMAL SWITCHES - REPAIR | U | Oct 30/15 |
| 21-20-02-300-801-A REPAIR OF THERMAL SWITCH BRACKET | U | Oct 30/15 |
| 21-20-03/400 DISTRIBUTION SYSTEM MUFFLERS - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-20-03-000-801-A DISTRIBUTION SYSTEM MUFFLERS - REMOVAL | U | Oct 30/15 |
| 21-20-03-400-801-A DISTRIBUTION SYSTEM MUFFLERS - INSTALLATION | U | Oct 30/15 |
| 21-20-04/400 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> AIR CONDITIONING DUCTS - REMOVAL/INSTALLATION | U | Oct 30/15 |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 21
Page 3 of 30
Rev 55 - Oct 29/18



AIRCRAFT MAINTENANCE MANUAL


| PAGEBLOCK TASK | REVISION STATUS | REVISION DATE |
|--|--------------------|------------------|
| 21-20-04-000-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 TYPICAL DUCT - REMOVAL</i> | U | Oct 30/15 |
| 21-20-04-400-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 TYPICAL DUCT - INSTALLATION</i> | U | Oct 30/15 |
| 21-20-04/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 AIR CONDITIONING DUCTS - REMOVAL/INSTALLATION</i> | U | Oct 30/15 |
| 21-20-04-000-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 TYPICAL DUCT - REMOVAL</i> | U | Oct 30/15 |
| 21-20-04-400-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 TYPICAL DUCT - INSTALLATION</i> | U | Oct 30/15 |
| 21-21-00/500 COCKPIT DISTRIBUTION - ADJUSTMENT/TEST | U | Oct 30/15 |
| 21-21-00-700-801-A EFIS DISPLAY VENTILATION SYSTEM - FUNCTIONAL CHECK | U | Oct 30/15 |
| 21-21-01/400 SHUTOFF VALVES OF PILOT'S FOOT OUTLETS - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-21-01-000-801-A SHUTOFF VALVES OF THE PILOT FOOT OUTLETS - REMOVAL | U | Oct 30/15 |
| 21-21-01-400-801-A SHUTOFF VALVES OF THE PILOT FOOT OUTLETS - INSTALLATION | U | Oct 30/15 |
| 21-21-02/600 COCKPIT AIR CONDITIONING OUTLETS - INSPECTION/CHECK | U | Oct 30/15 |
| 21-21-02-200-801-A COCKPIT CONDITIONED AIR OUTLETS - GENERAL VISUAL INSPECTION | U | Oct 30/15 |
| 21-21-03/600 COCKPIT AIR CONDITIONING DUCTS - INSPECTION/CHECK | U | Oct 30/15 |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC


Chapter 21
Page 4 of 30
Rev 55 - Oct 29/18



AIRCRAFT
MAINTENANCE MANUAL

| PAGEBLOCK TASK | REVISION STATUS | REVISION DATE |
|--|--------------------|------------------|
| 21-21-03-200-801-A COCKPIT CONDITIONED-AIR DUCTS - GENERAL VISUAL INSPECTION | U | Oct 30/15 |
| 21-21-04/400 EFIS VENTILATION SYSTEM SHUTOFF VALVES - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-21-04-000-801-A SHUTOFF VALVE - REMOVAL | U | Oct 30/15 |
| 21-21-04-400-801-A SHUTOFF VALVE - INSTALLATION | U | Oct 30/15 |
| 21-22-01/400 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> AIR DISTRIBUTION VALVE - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-22-01-000-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> AIR DISTRIBUTION VALVE - REMOVAL | U | Oct 30/15 |
| 21-22-01-400-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> AIR DISTRIBUTION VALVE - INSTALLATION | U | Oct 30/15 |
| 21-22-01-040-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> AIR DISTRIBUTION VALVE - DEACTIVATION PROCEDURES | U | Oct 30/15 |
| 21-22-01-440-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> AIR DISTRIBUTION VALVE - REACTIVATION PROCEDURES | U | Oct 30/15 |
| 21-22-01/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> AIR DISTRIBUTION VALVE - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-22-01-000-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> AIR DISTRIBUTION VALVE - REMOVAL | U | Oct 30/15 |
| 21-22-01-400-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> AIR DISTRIBUTION VALVE - INSTALLATION | U | Oct 30/15 |
| 21-22-01-040-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> AIR DISTRIBUTION VALVE - DEACTIVATION PROCEDURES | U | Oct 30/15 |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


| PAGEBLOCK TASK | REVISION STATUS | REVISION DATE |
|--|--------------------|------------------|
| 21-22-01-440-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> AIR DISTRIBUTION VALVE - REACTIVATION PROCEDURES | U | Oct 30/15 |
| 21-22-01/500 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> AIR DISTRIBUTION VALVE - ADJUSTMENT/TEST | U | Oct 30/15 |
| 21-22-01-800-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> AIR DISTRIBUTION VALVE - ADJUSTMENT | U | Oct 30/15 |
| 21-22-01/500 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> AIR DISTRIBUTION VALVE - ADJUSTMENT/TEST | U | Oct 30/15 |
| 21-22-01-800-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> AIR DISTRIBUTION VALVE - ADJUSTMENT | U | Oct 30/15 |
| 21-22-04/400 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> GROUND CONNECTION VALVE - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-22-04-000-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> GROUND CONNECTION VALVE - REMOVAL | U | Oct 31/17 |
| 21-22-04-400-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> GROUND CONNECTION VALVE - INSTALLATION | U | Oct 31/17 |
| 21-22-04-000-802-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> GROUND CONNECTION DOOR RUBBER SEAL RING - REMOVAL | U | Oct 30/15 |
| 21-22-04-400-802-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> GROUND CONNECTION DOOR RUBBER SEAL RING - INSTALLATION | U | Oct 30/15 |
| 21-22-04-040-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> GROUND CONNECTION VALVE - DEACTIVATION PROCEDURES | U | Oct 30/15 |
| 21-22-04-440-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> GROUND CONNECTION VALVE - REACTIVATION PROCEDURES | U | Oct 30/15 |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC


Chapter 21
Page 6 of 30
Rev 55 - Oct 29/18



AIRCRAFT
MAINTENANCE MANUAL

| PAGEBLOCK TASK | REVISION STATUS | REVISION DATE |
|---|--------------------|------------------|
| 21-22-04/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> GROUND CONNECTION VALVE - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-22-04-000-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> GROUND CONNECTION VALVE - REMOVAL | U | Oct 31/17 |
| 21-22-04-400-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> GROUND CONNECTION VALVE - INSTALLATION | U | Oct 31/17 |
| 21-22-04-000-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> GROUND CONNECTION DOOR RUBBER SEAL RING - REMOVAL | U | Oct 30/15 |
| 21-22-04-400-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> GROUND CONNECTION DOOR RUBBER SEAL RING - INSTALLATION | U | Oct 30/15 |
| 21-22-04-040-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> GROUND CONNECTION VALVE - DEACTIVATION PROCEDURES | U | Oct 30/15 |
| 21-22-04-440-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> GROUND CONNECTION VALVE - REACTIVATION PROCEDURES | U | Oct 30/15 |
| 21-22-04/500 GROUND CONNECTION VALVE - ADJUSTMENT/TEST | U | Oct 30/15 |
| 21-22-04-700-801-A GROUND CONNECTION VALVE - OPERATIONAL CHECK | U | Oct 30/15 |
| 21-22-05/600 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> PASSENGER CABIN AIR CONDITIONING DUCTS - INSPECTION/CHECK | U | Oct 30/15 |
| 21-22-05-200-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> PASSENGER-CABIN CONDITIONED-AIR DUCTS - GENERAL VISUAL INSPECTION | U | Oct 30/15 |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


| PAGEBLOCK TASK | REVISION STATUS | REVISION DATE |
|---|--------------------|------------------|
| 21-22-05/600 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> PASSENGER CABIN AIR CONDITIONING DUCTS - INSPECTION/CHECK | U | Oct 30/15 |
| 21-22-05-200-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> PASSENGER-CABIN CONDITIONED-AIR DUCTS - GENERAL VISUAL INSPECTION | U | Oct 30/15 |
| 21-22-06/400 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> PASSENGER CABIN DISTRIBUTION - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-22-06-000-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> CONDITIONED-AIR SUPPLY DUCT - REMOVAL | U | Oct 30/15 |
| 21-22-06-400-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> CONDITIONED-AIR SUPPLY DUCT - INSTALLATION | U | Apr 29/16 |
| 21-22-06/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> PASSENGER CABIN DISTRIBUTION - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-22-06-000-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> CONDITIONED-AIR SUPPLY DUCT - REMOVAL | U | Oct 30/15 |
| 21-22-06-400-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> CONDITIONED-AIR SUPPLY DUCT - INSTALLATION | U | Apr 29/16 |
| 21-23-01/400 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> GASPER SHUTOFF VALVE - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-23-01-000-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> GASPER SHUTOFF VALVE - REMOVAL | U | Oct 30/15 |
| 21-23-01-400-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> GASPER SHUTOFF VALVE - INSTALLATION | U | Oct 30/15 |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 21
Page 8 of 30
Rev 55 - Oct 29/18



EMB145 – EMB135

AIRCRAFT
MAINTENANCE MANUAL


| PAGEBLOCK TASK | REVISION STATUS | REVISION DATE |
|---|--------------------|------------------|
| 21-23-01/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> GASPER SHUTOFF VALVE - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-23-01-000-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> GASPER SHUTOFF VALVE - REMOVAL | U | Oct 30/15 |
| 21-23-01-400-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> GASPER SHUTOFF VALVE - INSTALLATION | U | Oct 30/15 |
| 21-23-01/500 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> GASPER SHUTOFF VALVE - ADJUSTMENT/TEST | U | Oct 30/15 |
| 21-23-01-800-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> GASPER SHUTOFF VALVE - ADJUSTMENT | U | Oct 30/15 |
| 21-23-01/500 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> GASPER SHUTOFF VALVE - ADJUSTMENT/TEST | U | Oct 30/15 |
| 21-23-01-800-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> GASPER SHUTOFF VALVE - ADJUSTMENT | U | Oct 30/15 |
| 21-23-03/400 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> GASPER FAN - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-23-03-000-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> GASPER FAN - REMOVAL | U | Oct 30/15 |
| 21-23-03-400-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> GASPER FAN - INSTALLATION | U | Oct 30/15 |
| 21-23-03/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> GASPER FAN - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-23-03-000-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> GASPER FAN - REMOVAL | U | Oct 30/15 |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 21
Page 9 of 30
Rev 55 - Oct 29/18



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


| PAGEBLOCK TASK | REVISION STATUS | REVISION DATE |
|--|--------------------|------------------|
| 21-23-03-400-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 GASPER FAN - INSTALLATION</i> | U | Oct 30/15 |
| 21-23-04/400 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 GASPER SYSTEM MUFFLERS - REMOVAL/INSTALLATION</i> | U | Oct 30/15 |
| 21-23-04-000-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 GASPER SYSTEM MUFFLERS - REMOVAL</i> | U | Oct 30/15 |
| 21-23-04-400-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 GASPER SYSTEM MUFFLERS - INSTALLATION</i> | U | Oct 30/15 |
| 21-23-04/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 GASPER SYSTEM MUFFLERS - REMOVAL/INSTALLATION</i> | U | Oct 30/15 |
| 21-23-04-000-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 GASPER SYSTEM MUFFLERS - REMOVAL</i> | U | Oct 30/15 |
| 21-23-04-400-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 GASPER SYSTEM MUFFLERS - INSTALLATION</i> | U | Oct 30/15 |
| 21-23-04/600 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 GASPER SYSTEM MUFFLERS - INSPECTION/CHECK</i> | U | Oct 30/15 |
| 21-23-04-200-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 GASPER SYSTEM - GENERAL VISUAL INSPECTION</i> | U | Oct 30/15 |
| 21-23-04/600 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 GASPER SYSTEM MUFFLERS - INSPECTION/CHECK</i> | U | Oct 30/15 |
| 21-23-04-200-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 GASPER SYSTEM - GENERAL VISUAL INSPECTION</i> | U | Oct 30/15 |
| 21-23-04/700 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 GASPER SYSTEM MUFFLERS - CLEANING/PAINTING</i> | U | Oct 30/15 |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC


Chapter 21
Page 10 of 30
Rev 55 - Oct 29/18



AIRCRAFT MAINTENANCE MANUAL

| PAGEBLOCK TASK | REVISION STATUS | REVISION DATE |
|--|--------------------|------------------|
| 21-23-04-100-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 GASPER SYSTEM - CLEANING</i> | U | Oct 30/15 |
| 21-23-04/700 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 GASPER SYSTEM MUFFLERS - CLEANING/PAINTING</i> | U | Oct 30/15 |
| 21-23-04-100-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 GASPER SYSTEM - CLEANING</i> | U | Oct 30/15 |
| 21-23-05/400 <i>EFFECTIVITY: AIRCRAFT WITH TOILET GASPER-HOSE FILTER INSTALLED TOILET GASPER-HOSE FILTER - REMOVAL/INSTALLATION</i> | U | Oct 30/15 |
| 21-23-05-000-801-A <i>EFFECTIVITY: AIRCRAFT WITH TOILET GASPER-HOSE FILTER INSTALLED TOILET GASPER-HOSE FILTER - REMOVAL</i> | U | Oct 30/15 |
| 21-23-05-400-801-A <i>EFFECTIVITY: AIRCRAFT WITH TOILET GASPER-HOSE FILTER INSTALLED TOILET GASPER-HOSE FILTER - INSTALLATION</i> | U | Oct 30/15 |
| 21-23-05/500 <i>EFFECTIVITY: AIRCRAFT WITH TOILET GASPER-HOSE FILTER INSTALLED TOILET GASPER-HOSE FILTER - ADJUSTMENT/TEST</i> | U | Oct 31/16 |
| 21-23-05-700-801-A <i>EFFECTIVITY: AIRCRAFT WITH TOILET GASPER-HOSE FILTER INSTALLED TOILET GASPER-HOSE FILTER - OPERATIONAL CHECK</i> | U | Oct 31/16 |
| 21-23-06/400 <i>GASPER FAN CONTACTOR - REMOVAL/INSTALLATION</i> | U | Oct 30/15 |
| 21-23-06-000-801-A <i>GASPER FAN CONTACTOR - REMOVAL</i> | U | Oct 30/15 |
| 21-23-06-400-801-A <i>GASPER FAN CONTACTOR - INSTALLATION</i> | U | Oct 30/15 |


Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



AIRCRAFT
MAINTENANCE MANUAL

| PAGEBLOCK <u>TASK</u> | <u>REVISION STATUS</u> | <u>REVISION DATE</u> |
|---|----------------------------|--------------------------|
| 21-24-01/400 RECIRCULATION FAN - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-24-01-000-801-A RECIRCULATION FAN - REMOVAL | U | Oct 30/15 |
| 21-24-01-400-801-A RECIRCULATION FAN - INSTALLATION | U | Oct 30/15 |
| 21-24-01-040-801-A RECIRCULATION FAN - DEACTIVATION PROCEDURES | U | Oct 30/15 |
| 21-24-01-440-801-A RECIRCULATION FAN - REACTIVATION PROCEDURES | U | Oct 30/15 |
| 21-24-02/200 RECIRCULATION SYSTEM MUFFLERS - MAINTENANCE PRACTICES | U | Oct 30/15 |
| 21-24-02-910-801-A INSTALLATION OF THE CONDITIONED AIR NOISE ATTENUATOR DUCTS | U | Oct 30/15 |
| 21-24-02/400 RECIRCULATION SYSTEM MUFFLERS - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-24-02-000-801-A RECIRCULATION SYSTEM MUFFLERS - REMOVAL | U | Oct 30/15 |
| 21-24-02-400-801-A RECIRCULATION SYSTEM MUFFLERS - INSTALLATION | U | Oct 30/15 |
| 21-24-02/600 RECIRCULATION SYSTEM MUFFLERS - INSPECTION/CHECK | U | Oct 30/15 |
| 21-24-02-200-801-A RECIRCULATION SYSTEM - GENERAL VISUAL INSPECTION | U | Oct 30/15 |
| 21-24-02/700 RECIRCULATION SYSTEM MUFFLERS - CLEANING/PAINTING | U | Oct 30/15 |
| 21-24-02-100-801-A RECIRCULATION SYSTEM - CLEANING | U | Oct 30/15 |
| 21-24-03/400 RECIRCULATION FAN CONTACTOR - REMOVAL/INSTALLATION | U | Oct 30/15 |


Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



AIRCRAFT
MAINTENANCE MANUAL

| PAGEBLOCK TASK | REVISION STATUS | REVISION DATE |
|--|--------------------|------------------|
| 21-24-03-000-801-A RECIRCULATION FAN CONTACTOR - REMOVAL | U | Oct 30/15 |
| 21-24-03-400-801-A RECIRCULATION FAN CONTACTOR - INSTALLATION | U | Oct 30/15 |
| 21-25-01/400 RAM AIR VALVE - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-25-01-000-801-A RAM AIR VALVE - REMOVAL | U | Oct 30/15 |
| 21-25-01-400-801-A RAM AIR VALVE - INSTALLATION | U | Oct 30/15 |
| 21-25-01-040-801-A RAM AIR VALVE - DEACTIVATION PROCEDURES | U | Oct 30/15 |
| 21-25-01-440-801-A RAM AIR VALVE - REACTIVATION PROCEDURES | U | Oct 30/15 |
| 21-25-01/500 RAM AIR VALVE - ADJUSTMENT/TEST | U | Oct 30/15 |
| 21-25-01-700-801-A RAM AIR VALVE - OPERATIONAL CHECK | U | Oct 30/15 |
| 21-25-01/600 RAM AIR VALVE - INSPECTION/CHECK | U | Oct 30/15 |
| 21-25-01-200-801-A FLAP OF RAM AIR VALVES - GENERAL VISUAL INSPECTION | U | Oct 30/15 |
| 21-25-02/400 RAM AIR CHECK VALVE - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-25-02-000-801-A RAM-AIR CHECK VALVE - REMOVAL | U | Oct 30/15 |
| 21-25-02-400-801-A RAM-AIR CHECK VALVE - INSTALLATION | U | Oct 30/15 |
| 21-25-02-040-801-A RAM-AIR CHECK VALVE - DEACTIVATION PROCEDURES | U | Oct 30/15 |
| 21-25-02-440-801-A RAM-AIR CHECK VALVE - REACTIVATION PROCEDURES | U | Oct 30/15 |


Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



AIRCRAFT MAINTENANCE MANUAL

| <u>PAGEBLOCK TASK</u> | | <u>REVISION STATUS</u> | <u>REVISION DATE</u> |
|---------------------------|---|----------------------------|--------------------------|
| 21-25-03/200 | LINEAR ACTUATOR - MAINTENANCE PRACTICES | U | Oct 30/15 |
| 21-25-03-800-801-A | LINEAR ACTUATOR - ADJUSTMENT | U | Oct 30/15 |
| 21-25-03/400 | LINEAR ACTUATOR - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-25-03-000-801-A | LINEAR ACTUATOR - REMOVAL | U | Oct 30/15 |
| 21-25-03-400-801-A | LINEAR ACTUATOR - INSTALLATION | U | Oct 30/15 |
| 21-26-00/500 | ELECTRONIC COMPARTMENT VENTILATION SYSTEM - ADJUSTMENT/TEST | U | Oct 30/15 |
| 21-26-00-700-801-A | ELECTRONIC COMPARTMENT VENTILATION SYSTEM - OPERATIONAL CHECK | U | Oct 30/15 |
| 21-26-01/400 | SHUTOFF VALVE - REMOVAL/INSTALLATION | U | Feb 16/16 |
| 21-26-01-000-801-A | SHUTOFF VALVE - REMOVAL | U | Feb 16/16 |
| 21-26-01-400-801-A | SHUTOFF VALVE - INSTALLATION | U | Feb 16/16 |
| 21-26-02/400 | FAN - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-26-02-000-801-A | FAN - REMOVAL | U | Oct 30/15 |
| 21-26-02-400-801-A | FAN - INSTALLATION | U | Oct 30/15 |
| 21-26-03/400 | INVERTER - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-26-03-000-801-A | INVERTER - REMOVAL | U | Oct 30/15 |


Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



AIRCRAFT
MAINTENANCE MANUAL

| PAGEBLOCK TASK | REVISION STATUS | REVISION DATE |
|---|--------------------|------------------|
| 21-26-03-400-801-A INVERTER - INSTALLATION | U | Oct 30/15 |
| 21-26-04/400 THERMAL SWITCH - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-26-04-000-801-A THERMAL SWITCH - REMOVAL | U | Oct 30/15 |
| 21-26-04-400-801-A THERMAL SWITCH - INSTALLATION | U | Oct 30/15 |
| 21-26-06/300 CHECK VALVE - SERVICING | U | Oct 30/15 |
| 21-26-06-600-801-A CHECK VALVE - LUBRICATION | U | Oct 30/15 |
| 21-26-06/400 CHECK VALVE - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-26-06-000-801-A CHECK VALVE - REMOVAL | U | Oct 30/15 |
| 21-26-06-400-801-A CHECK VALVE - INSTALLATION | U | Oct 30/15 |
| 21-26-06/700 CHECK VALVE - CLEANING/PAINTING | U | Oct 30/15 |
| 21-26-06-100-801-A CHECK VALVE - CLEANING | U | Oct 30/15 |
| 21-26-08/200 EXHAUST HOSES - MAINTENANCE PRACTICES | U | Oct 30/15 |
| 21-26-08-960-801-A EXHAUST HOSES - REPLACE | U | Oct 30/15 |
| 21-26-08/400 EXHAUST HOSES - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-26-08-000-801-A EXHAUST HOSES - REMOVAL | U | Oct 30/15 |
| 21-26-08-400-801-A EXHAUST HOSES - INSTALLATION | U | Oct 30/15 |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 – EMB135

AIRCRAFT
MAINTENANCE MANUAL


| PAGEBLOCK TASK | REVISION STATUS | REVISION DATE |
|--|--------------------|------------------|
| 21-26-11/400 <i>EFFECTIVITY: A/C WITH AVIONICS PROTECTIVES INSTALLED</i> ELECTRONIC COMPARTMENT PROTECTIVE SHIELD - REMOVAL/ INSTALLATION | U | Oct 30/15 |
| 21-26-11-000-801-A <i>EFFECTIVITY: ONLY A/C WITH AVIONICS PROTECTIVES INSTALLED</i> AVIONICS PROTECTIVE - REMOVAL | U | Oct 30/15 |
| 21-26-11-400-801-A <i>EFFECTIVITY: ONLY A/C WITH AVIONICS PROTECTIVES INSTALLED</i> AVIONICS PROTECTIVE - INSTALLATION | U | Oct 30/15 |
| 21-27-00/400 BAGGAGE COMPARTMENT VENTILATION SYSTEM - REMOVAL/ INSTALLATION | U | Oct 30/15 |
| 21-27-00-040-801-A BAGGAGE-COMPARTMENT VENTILATION SYSTEM - DEACTIVATION PROCEDURES | U | Oct 30/15 |
| 21-27-00-440-801-A BAGGAGE-COMPARTMENT VENTILATION SYSTEM - REACTIVATION PROCEDURES | U | Oct 30/15 |
| 21-27-00/500 <i>EFFECTIVITY: CLASS-C BAGGAGE COMPARTMENT</i> BAGGAGE COMPARTMENT VENTILATION SYSTEM - ADJUSTMENT/ TEST | U | Oct 30/15 |
| 21-27-00-700-801-A <i>EFFECTIVITY: CLASS-C BAGGAGE COMPARTMENT</i> BAGGAGE COMPARTMENT VENTILATION SYSTEM - OPERATIONAL CHECK | U | Oct 30/15 |
| 21-27-01/400 <i>EFFECTIVITY: CLASS-C BAGGAGE COMPARTMENT</i> BAGGAGE COMPARTMENT FAN - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-27-01-000-801-A <i>EFFECTIVITY: CLASS-C BAGGAGE COMPARTMENT</i> BAGGAGE COMPARTMENT FAN - REMOVAL | U | Oct 30/15 |
| 21-27-01-400-801-A <i>EFFECTIVITY: CLASS-C BAGGAGE COMPARTMENT</i> BAGGAGE COMPARTMENT FAN - INSTALLATION | U | Oct 30/15 |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 21
Page 16 of 30
Rev 55 - Oct 29/18



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


| PAGEBLOCK TASK | REVISION STATUS | REVISION DATE |
|--|--------------------|------------------|
| 21-27-02/300 <i>EFFECTIVITY: CLASS-C BAGGAGE COMPARTMENT BAGGAGE-COMPARTMENT CHECK VALVES - SERVICING</i> | U | Oct 30/15 |
| 21-27-02-600-801-A <i>EFFECTIVITY: CLASS-C BAGGAGE COMPARTMENT BAGGAGE-COMPARTMENT CHECK VALVES - LUBRICATION</i> | U | Oct 30/15 |
| 21-27-02/400 <i>EFFECTIVITY: CLASS-C BAGGAGE COMPARTMENT BAGGAGE-COMPARTMENT CHECK VALVES - REMOVAL/INSTALLA- TION</i> | U | Oct 30/15 |
| 21-27-02-000-801-A <i>EFFECTIVITY: CLASS-C BAGGAGE COMPARTMENT BAGGAGE COMPARTMENT CHECK VALVES - REMOVAL</i> | U | Oct 30/15 |
| 21-27-02-400-801-A <i>EFFECTIVITY: CLASS-C BAGGAGE COMPARTMENT BAGGAGE COMPARTMENT CHECK VALVES - INSTALLATION</i> | U | Oct 30/15 |
| 21-27-02/500 <i>EFFECTIVITY: CLASS-C BAGGAGE COMPARTMENT BAGGAGE-COMPARTMENT CHECK VALVES - ADJUSTMENT/TEST</i> | U | Oct 30/15 |
| 21-27-02-700-801-A <i>EFFECTIVITY: CLASS-C BAGGAGE COMPARTMENT BAGGAGE-COMPARTMENT CHECK VALVES - OPERATIONAL CHECK</i> | U | Oct 30/15 |
| 21-30-00/400 <i>PRESSURIZATION CONTROL - REMOVAL/INSTALLATION</i> | U | Oct 30/15 |
| 21-30-00-040-801-A <i>PRESSURIZATION CONTROL - DEACTIVATION PROCEDURES</i> | U | Oct 30/15 |
| 21-30-00-440-801-A <i>PRESSURIZATION CONTROL - REACTIVATION PROCEDURES</i> | U | Oct 30/15 |
| 21-31-00/200 <i>PRESSURIZATION CONTROL SYSTEM - MAINTENANCE PRACTICES</i> | U | Oct 30/15 |
| 21-31-00-860-801-A <i>PROCEDURE TO PRESSURIZE THE AIRCRAFT FOR MAINTENANCE</i> | U | Oct 30/15 |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 21
Page 17 of 30
Rev 55 - Oct 29/18



EMB145 – EMB135

AIRCRAFT
MAINTENANCE MANUAL


| PAGEBLOCK TASK | REVISION STATUS | REVISION DATE |
|--|--------------------|------------------|
| 21-31-00-860-802-A PROCEDURE TO DEPRESSURIZE THE AIRCRAFT FOR MAINTENANCE | U | Oct 30/15 |
| 21-31-00/500 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> PRESSURIZATION CONTROL SYSTEM - ADJUSTMENT/TEST | U | Oct 30/15 |
| 21-31-00-700-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> PRESSURIZATION CONTROL SYSTEM - OPERATIONAL CHECK IN MANUAL MODE | U | Oct 30/15 |
| 21-31-00-700-802-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> PRESSURIZATION CONTROL SYSTEM - FUNCTIONAL TEST IN AUTOMATIC MODE | U | Oct 30/15 |
| 21-31-00-700-803-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> OPERATIONAL TEST OF QUICK DEPRESSURIZATION IN AUTO AND MANUAL MODES | U | Oct 30/15 |
| 21-31-00-700-804-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> FUNCTIONAL TEST OF OUTFLOW VALVES | U | Oct 30/15 |
| 21-31-00-700-805-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> FUNCTIONAL TEST FOR CABIN LEAKAGE WITH THE PRESSURIZATION TEST BENCH | U | Oct 30/15 |
| 21-31-00-700-806-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> FUNCTIONAL TEST FOR LINE LEAKAGE | U | Oct 30/15 |
| 21-31-00-700-807-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> FUNCTIONAL TEST OF OVERPRESSURIZATION RELIEF DEVICES | U | Oct 30/15 |
| 21-31-00-700-808-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> FUNCTIONAL TEST FOR CABIN LEAKAGE WITH AIR BLED FROM THE ENGINE OR APU | U | Oct 30/15 |
| 21-31-00-700-809-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> FUNCTIONAL TEST OF OVERPRESSURIZATION RELIEF DEVICES WITH PITOT/STATIC SYSTEM TEST SET | U | Oct 30/15 |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC


Chapter 21
Page 18 of 30
Rev 55 - Oct 29/18



AIRCRAFT
MAINTENANCE MANUAL

| PAGEBLOCK TASK | REVISION STATUS | REVISION DATE |
|---|--------------------|------------------|
| 21-31-00/500 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> PRESSURIZATION CONTROL SYSTEM - ADJUSTMENT/TEST | U | Apr 28/17 |
| 21-31-00-700-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> PRESSURIZATION CONTROL SYSTEM - OPERATIONAL CHECK IN MANUAL MODE | U | Oct 30/15 |
| 21-31-00-700-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> PRESSURIZATION CONTROL SYSTEM - FUNCTIONAL TEST IN AU- TOMATIC MODE | U | Oct 30/15 |
| 21-31-00-700-803-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> OPERATIONAL TEST OF QUICK DEPRESSURIZATION IN AUTO AND MANUAL MODES | U | Oct 30/15 |
| 21-31-00-700-804-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> FUNCTIONAL TEST OF OUTFLOW VALVES | U | Oct 30/15 |
| 21-31-00-700-805-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> FUNCTIONAL TEST FOR CABIN LEAKAGE WITH THE PRESSURIZA- TION TEST BENCH | U | Oct 30/15 |
| 21-31-00-700-806-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> FUNCTIONAL TEST FOR LINE LEAKAGE | U | Apr 28/17 |
| 21-31-00-700-807-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> FUNCTIONAL TEST OF OVERPRESSURIZATION RELIEF DEVICES | U | Oct 30/15 |
| 21-31-00-700-808-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> FUNCTIONAL TEST FOR CABIN LEAKAGE WITH AIR BLED FROM THE ENGINE OR APU | U | Oct 30/15 |
| 21-31-00-700-809-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> FUNCTIONAL TEST OF OVERPRESSURIZATION RELIEF DEVICES WITH PITOT/STATIC SYSTEM TEST SET | U | Oct 30/15 |
| 21-31-01/400 DIGITAL CONTROLLER - REMOVAL/INSTALLATION | U | Oct 30/15 |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



AIRCRAFT MAINTENANCE MANUAL


| PAGEBLOCK <u>TASK</u> | <u>REVISION STATUS</u> | <u>REVISION DATE</u> |
|---|----------------------------|--------------------------|
| 21-31-01-000-801-A DIGITAL CONTROLLER - REMOVAL | U | Oct 30/15 |
| 21-31-01-400-801-A DIGITAL CONTROLLER - INSTALLATION | U | Oct 30/15 |
| 21-31-01/600 DIGITAL CONTROLLER - INSPECTION/CHECK | U | Oct 30/15 |
| 21-31-01-900-801-A DIGITAL CONTROLLER - DATA RECORDING | U | Oct 30/15 |
| 21-31-02/400 MANUAL CONTROLLER - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-31-02-000-801-A MANUAL CONTROLLER - REMOVAL | U | Oct 30/15 |
| 21-31-02-400-801-A MANUAL CONTROLLER - INSTALLATION | U | Oct 30/15 |
| 21-31-03/400 ELECTROPNEUMATIC OUTFLOW VALVE - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-31-03-000-801-A ELECTROPNEUMATIC OUTFLOW VALVE - REMOVAL | U | Oct 30/15 |
| 21-31-03-400-801-A ELECTROPNEUMATIC OUTFLOW VALVE - INSTALLATION | U | Oct 30/15 |
| 21-31-03-040-801-A ELECTROPNEUMATIC OUTFLOW VALVE - DEACTIVATION PROCEDURE | U | Oct 30/15 |
| 21-31-03-440-801-A ELECTROPNEUMATIC OUTFLOW VALVE - REACTIVATION PROCEDURE | U | Oct 30/15 |
| 21-31-03/700 ELECTROPNEUMATIC OUTFLOW VALVE - CLEANING/PAINTING | U | Oct 30/15 |
| 21-31-03-100-801-A ELECTROPNEUMATIC OUTFLOW VALVE - CLEANING | U | Oct 30/15 |
| 21-31-04/400 PNEUMATIC OUTFLOW VALVE - REMOVAL/INSTALLATION | U | Oct 30/15 |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 21
Page 20 of 30
Rev 55 - Oct 29/18



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


| PAGEBLOCK TASK | REVISION STATUS | REVISION DATE |
|--|--------------------|------------------|
| 21-31-04-000-801-A PNEUMATIC OUTFLOW VALVE - REMOVAL | U | Oct 30/15 |
| 21-31-04-400-801-A PNEUMATIC OUTFLOW VALVE - INSTALLATION | U | Oct 30/15 |
| 21-31-04-040-801-A PNEUMATIC OUTFLOW VALVE - DEACTIVATION PROCEDURE | U | Apr 27/18 |
| 21-31-04-440-801-A PNEUMATIC OUTFLOW VALVE - REACTIVATION PROCEDURE | U | Oct 30/15 |
| 21-31-04/700 PNEUMATIC OUTFLOW VALVE - CLEANING/PAINTING | U | Oct 30/15 |
| 21-31-04-100-801-A PNEUMATIC OUTFLOW VALVE - CLEANING | U | Oct 30/15 |
| 21-31-05/400 PRESSURE REGULATOR VALVE - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-31-05-000-801-A PRESSURE REGULATOR VALVE - REMOVAL | U | Oct 30/15 |
| 21-31-05-400-801-A PRESSURE REGULATOR VALVE - INSTALLATION | U | Oct 30/15 |
| 21-31-06/400 VACUUM PUMP - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-31-06-000-801-A VACUUM PUMP - REMOVAL | U | Oct 30/15 |
| 21-31-06-400-801-A VACUUM PUMP - INSTALLATION | U | Oct 30/15 |
| 21-31-07/400 STATIC PORT - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-31-07-000-801-A STATIC PORT - REMOVAL | U | Oct 30/15 |
| 21-31-07-400-801-A STATIC PORT - INSTALLATION | U | Oct 30/15 |
| 21-31-08/200 AIR FILTER - MAINTENANCE PRACTICES | U | Oct 30/15 |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 21
Page 21 of 30
Rev 55 - Oct 29/18



AIRCRAFT
MAINTENANCE MANUAL


| PAGEBLOCK TASK | REVISION STATUS | REVISION DATE |
|--|--------------------|------------------|
| 21-31-08-960-801-A AIR FILTER ELEMENT - REPLACEMENT | U | Oct 30/15 |
| 21-31-09/400 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> VACUUM LINE - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-31-09-000-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> VACUUM LINE - REMOVAL | U | Oct 30/15 |
| 21-31-09-400-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> VACUUM LINE - INSTALLATION | U | Oct 30/15 |
| 21-31-09/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> VACUUM LINE - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-31-09-000-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> VACUUM LINE - REMOVAL | U | Oct 30/15 |
| 21-31-09-400-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> VACUUM LINE - INSTALLATION | U | Oct 30/15 |
| 21-31-10/400 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> REFERENCE PRESSURE LINE - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-31-10-000-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> REFERENCE PRESSURE LINE - REMOVAL | U | Oct 30/15 |
| 21-31-10-400-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> REFERENCE PRESSURE LINE - INSTALLATION | U | Oct 30/15 |
| 21-31-10/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> REFERENCE PRESSURE LINE - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-31-10-000-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> REFERENCE PRESSURE LINE - REMOVAL | U | Oct 30/15 |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 21
Page 22 of 30
Rev 55 - Oct 29/18



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


| PAGEBLOCK TASK | REVISION STATUS | REVISION DATE |
|---|--------------------|------------------|
| 21-31-10-400-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 REFERENCE PRESSURE LINE - INSTALLATION</i> | U | Oct 30/15 |
| 21-31-11/400 CHECK VALVE - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-31-11-000-801-A CHECK VALVE - REMOVAL | U | Oct 30/15 |
| 21-31-11-400-801-A CHECK VALVE - INSTALLATION | U | Oct 30/15 |
| 21-31-13/400 STATIC PORT LINES - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-31-13-000-801-A STATIC PORT LINES - REMOVAL | U | Oct 30/15 |
| 21-31-13-400-801-A STATIC PORT LINES - INSTALLATION | U | Oct 30/15 |
| 21-31-13/700 STATIC PORT LINES - CLEANING/PAINTING | U | Oct 30/15 |
| 21-31-13-100-801-A STATIC PORT LINES - CLEANING | U | Oct 30/15 |
| 21-32-01/400 CABIN PRESSURE ACQUISITION MODULE - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-32-01-000-801-A CABIN-PRESSURE ACQUISITION MODULE - REMOVAL | U | Oct 30/15 |
| 21-32-01-400-801-A CABIN-PRESSURE ACQUISITION MODULE - INSTALLATION | U | Oct 30/15 |
| 21-32-01-040-801-A CABIN PRESSURE ACQUISITION MODULE - DEACTIVATION PROCEDURES | U | Oct 30/15 |
| 21-32-01-440-801-A CABIN PRESSURE ACQUISITION MODULE - REACTIVATION PROCEDURES | U | Oct 30/15 |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 21
Page 23 of 30
Rev 55 - Oct 29/18



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


| PAGEBLOCK TASK | REVISION STATUS | REVISION DATE |
|--|--------------------|------------------|
| 21-32-01/500 CABIN PRESSURE ACQUISITION MODULE - ADJUSTMENT/TEST | U | Oct 30/15 |
| 21-32-01-700-801-A CABIN-PRESSURE ACQUISITION MODULE - FUNCTIONAL TEST | U | Oct 31/17 |
| 21-51-00/200 COOLING PACK SYSTEM - MAINTENANCE PRACTICES | U | Oct 31/17 |
| 21-51-00-200-801-A COOLING PACK SYSTEM - GENERAL INSPECTION | U | Apr 27/18 |
| 21-51-00/400 COOLING PACK SYSTEM - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-51-00-040-801-A COOLING PACK SYSTEM - DEACTIVATION PROCEDURE | U | Oct 30/15 |
| 21-51-00-440-801-A COOLING PACK SYSTEM - REACTIVATION PROCEDURES | U | Oct 30/15 |
| 21-51-00/500 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> COOLING PACK SYSTEM - ADJUSTMENT/TEST | U | Oct 30/15 |
| 21-51-00-700-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> ECS OFF SIGNAL - OPERATIONAL CHECK | U | Oct 30/15 |
| 21-51-00-700-802-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> COOLING PACK SYSTEM - OPERATIONAL TEST | U | Oct 30/15 |
| 21-51-00-700-803-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> COOLING PACK SYSTEM - FUNCTIONAL CHECK | U | Oct 30/15 |
| 21-51-00/500 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> COOLING PACK SYSTEM - ADJUSTMENT/TEST | U | Oct 30/15 |
| 21-51-00-700-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> COOLING PACK SYSTEM - OPERATIONAL TEST | U | Oct 30/15 |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC


Chapter 21
Page 24 of 30
Rev 55 - Oct 29/18



AIRCRAFT
MAINTENANCE MANUAL

| PAGEBLOCK TASK | REVISION STATUS | REVISION DATE |
|---|--------------------|------------------|
| 21-51-00-700-804-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 ECS OFF SIGNAL - OPERATIONAL CHECK</i> | U | Oct 30/15 |
| 21-51-00-700-805-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 COOLING PACK SYSTEM - FUNCTIONAL CHECK</i> | U | Oct 30/15 |
| | | |
| 21-51-01/400 PACK VALVE - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-51-01-000-801-A PACK VALVE - REMOVAL | U | Oct 30/15 |
| 21-51-01-400-801-A PACK VALVE - INSTALLATION | U | Oct 30/15 |
| 21-51-01-000-802-A FILTER - REMOVAL | U | Oct 30/15 |
| 21-51-01-400-802-A FILTER - INSTALLATION | U | Oct 30/15 |
| | | |
| 21-51-01/700 PACK VALVE - CLEANING/PAINTING | U | Oct 30/15 |
| 21-51-01-100-801-A PACK-VALVE AIR FILTER - CLEANING BY ULTRASONIC METHOD | U | Oct 30/15 |
| 21-51-01-100-802-A PACK-VALVE AIR FILTER - CLEANING BY AIR BLAST METHOD | U | Oct 30/15 |
| | | |
| 21-51-02/400 DUAL HEAT EXCHANGER - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-51-02-000-801-A DUAL HEAT EXCHANGER - REMOVAL | R | Oct 29/18 |
| 21-51-02-400-801-A DUAL HEAT EXCHANGER - INSTALLATION | R | Oct 29/18 |
| | | |
| 21-51-02/700 DUAL HEAT EXCHANGER - CLEANING/PAINTING | U | Oct 30/15 |
| 21-51-02-100-801-A DUAL HEAT EXCHANGER - CLEANING | U | Oct 30/15 |


Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



AIRCRAFT
MAINTENANCE MANUAL

| PAGEBLOCK TASK | REVISION STATUS | REVISION DATE |
|---|--------------------|------------------|
| 21-51-02-100-802-A DUAL HEAT EXCHANGER - ON AIRCRAFT CLEANING | U | Apr 27/18 |
| 21-51-03/400 AIR CYCLE MACHINE - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-51-03-000-801-A AIR CYCLE MACHINE (ACM) - REMOVAL | R | Oct 29/18 |
| 21-51-03-400-801-A AIR CYCLE MACHINE (ACM) - INSTALLATION | R | Oct 29/18 |
| 21-51-03/600 AIR CYCLE MACHINE - INSPECTION/CHECK | U | Oct 31/16 |
| 21-51-03-210-801-A AIR CYCLE MACHINE - ROTOR VISUAL INSPECTION | R | Oct 29/18 |
| 21-51-03-290-801-A AIR CYCLE MACHINES - ROTOR BORESCOPE INSPECTION | U | Oct 30/15 |
| 21-51-04/400 CONDENSER/MIXER - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-51-04-000-801-A CONDENSER/MIXER - REMOVAL | R | Oct 29/18 |
| 21-51-04-400-801-A CONDENSER/MIXER - INSTALLATION | R | Oct 29/18 |
| 21-51-05/400 WATER COLLECTOR - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-51-05-000-801-A WATER COLLECTOR - REMOVAL | U | Oct 30/15 |
| 21-51-05-400-801-A WATER COLLECTOR - INSTALLATION | U | Oct 30/15 |
| 21-51-06/400 PACK OVERPRESSURE SWITCH - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-51-06-000-801-A PACK OVERPRESSURE SWITCH - REMOVAL | U | Oct 30/15 |
| 21-51-06-400-801-A PACK OVERPRESSURE SWITCH - INSTALLATION | U | Oct 30/15 |


Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



AIRCRAFT
MAINTENANCE MANUAL

| PAGEBLOCK TASK | REVISION STATUS | REVISION DATE |
|--|--------------------|------------------|
| 21-51-07/400 PACK SETDOWN SWITCH - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-51-07-000-801-A PACK SETDOWN SWITCH - REMOVAL | U | Oct 30/15 |
| 21-51-07-400-801-A PACK SETDOWN SWITCH - INSTALLATION | U | Feb 16/16 |
| 21-51-08/400 PACK OVERTEMPERATURE SWITCH - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-51-08-000-801-A PACK OVERTEMPERATURE SWITCH - REMOVAL | U | Oct 30/15 |
| 21-51-08-400-801-A PACK OVERTEMPERATURE SWITCH - INSTALLATION | U | Oct 30/15 |
| 21-51-09/400 PACK DUCT OVERTEMPERATURE SWITCH - REMOVAL/INSTALLA- TION | U | Oct 30/15 |
| 21-51-09-000-801-A PACK DUCT OVERTEMPERATURE SWITCH - REMOVAL | U | Oct 30/15 |
| 21-51-09-400-801-A PACK DUCT OVERTEMPERATURE SWITCH - INSTALLATION | U | Oct 30/15 |
| 21-51-09/500 PACK DUCT OVERTEMPERATURE SWITCH - ADJUSTMENT/TEST | U | Oct 30/15 |
| 21-51-09-700-801-A COOLING-PACK DUCT OVERTEMPERATURE SWITCH - FUNCTION- AL CHECK | U | Oct 30/15 |
| 21-51-10/400 PACK LEAK SWITCH - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-51-10-000-801-A PACK LEAK SWITCH - REMOVAL | U | Oct 30/15 |
| 21-51-10-400-801-A PACK LEAK SWITCH - INSTALLATION | U | Oct 30/15 |
| 21-51-10/500 PACK LEAK SWITCH - ADJUSTMENT/TEST | U | Oct 30/15 |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


| PAGEBLOCK TASK | REVISION STATUS | REVISION DATE |
|--|--------------------|------------------|
| 21-51-10-700-801-A PACK LEAK SWITCH - OPERATIONAL CHECK | U | Oct 30/15 |
| 21-51-11/200 THERMAL INSULATION - MAINTENANCE PRACTICES | U | Oct 30/15 |
| 21-51-11-900-801-A <i>EFFECTIVITY: 004-169</i> THERMAL INSULATION OF COOLING PACK SYSTEM - REPAIR | U | Oct 30/15 |
| 21-51-11-960-801-A <i>EFFECTIVITY: 170 AND ON</i> THERMAL INSULATION OF COOLING PACK SYSTEM - REPLACE- MENT | U | Oct 30/15 |
| 21-51-13/400 WATER SPRAY NOZZLE - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-51-13-000-801-A <i>EFFECTIVITY: ONLY AIRCRAFT WITH SPRAY NOZZLE 145-25793</i> WATER SPRAY NOZZLE - REMOVAL | U | Oct 30/15 |
| 21-51-13-400-801-A <i>EFFECTIVITY: ONLY AIRCRAFT WITH SPRAY NOZZLE 145-25793</i> WATER SPRAY NOZZLE - INSTALLATION | U | Oct 30/15 |
| 21-51-13-000-802-A <i>EFFECTIVITY: ONLY AIRCRAFT WITH SPRAY NOZZLE 145-53171</i> WATER SPRAY NOZZLE - REMOVAL | U | Oct 30/15 |
| 21-51-13-400-802-A <i>EFFECTIVITY: ONLY AIRCRAFT WITH SPRAY NOZZLE 145-53171</i> WATER SPRAY NOZZLE - INSTALLATION | U | Oct 30/15 |
| 21-51-13/600 WATER SPRAY NOZZLE - INSPECTION/CHECK | U | Oct 30/15 |
| 21-51-13-200-801-A WATER SPRAY NOZZLES - INSPECTION | U | Oct 30/15 |
| 21-51-13/700 WATER SPRAY NOZZLE - CLEANING/PAINTING | U | Oct 30/15 |
| 21-51-13-100-801-A WATER SPRAY NOZZLE - CLEANING | U | Oct 30/15 |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 21
Page 28 of 30
Rev 55 - Oct 29/18




EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL

| PAGEBLOCK <u>TASK</u> | | <u>REVISION STATUS</u> | <u>REVISION DATE</u> |
|--------------------------|---|----------------------------|--------------------------|
| 21-51-14/600 | PACK DUCTS - INSPECTION/CHECK | U | Oct 30/15 |
| 21-51-14-200-801-A | PACK DUCTS - GENERAL VISUAL INSPECTION | U | Oct 30/15 |
| 21-60-00/500 | TEMPERATURE CONTROL - ADJUSTMENT/TEST | U | Oct 30/15 |
| 21-60-00-700-801-A | TEMPERATURE CONTROL SYSTEM - OPERATIONAL CHECK | R | Oct 29/18 |
| 21-60-01/400 | DUAL TEMPERATURE CONTROL VALVE - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-60-01-000-801-A | DUAL TEMPERATURE CONTROL VALVE - REMOVAL | U | Oct 30/15 |
| 21-60-01-400-801-A | DUAL TEMPERATURE CONTROL VALVE - INSTALLATION | U | Oct 30/15 |
| 21-60-02/400 | AMBIENT TEMPERATURE SENSOR - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-60-02-000-801-A | AMBIENT TEMPERATURE SENSORS - REMOVAL | U | Oct 30/15 |
| 21-60-02-400-801-A | AMBIENT TEMPERATURE SENSORS - INSTALLATION | U | Oct 30/15 |
| 21-60-02/700 | AMBIENT TEMPERATURE SENSOR - CLEANING/PAINTING | U | Oct 31/16 |
| 21-60-02-100-801-A | AMBIENT TEMPERATURE SENSORS - CLEANING | U | Oct 31/16 |
| 21-60-03/400 | DUCT TEMPERATURE SENSOR - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-60-03-000-801-A | DUCT TEMPERATURE SENSOR - REMOVAL | U | Oct 30/15 |
| 21-60-03-400-801-A | DUCT TEMPERATURE SENSOR - INSTALLATION | U | Oct 30/15 |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



AIRCRAFT
MAINTENANCE MANUAL

| PAGEBLOCK <u>TASK</u> | <u>REVISION STATUS</u> | <u>REVISION DATE</u> |
|--|----------------------------|--------------------------|
| 21-60-04/400 DIGITAL TEMPERATURE CONTROLLER - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-60-04-000-801-A DIGITAL TEMPERATURE CONTROLLER - REMOVAL | U | Oct 30/15 |
| 21-60-04-400-801-A DIGITAL TEMPERATURE CONTROLLER - INSTALLATION | U | Oct 30/15 |
| 21-60-05/400 TEMPERATURE CONTROL MODULE - REMOVAL/INSTALLATION | U | Oct 30/15 |
| 21-60-05-000-801-A TEMPERATURE CONTROL MODULE - REMOVAL | U | Oct 30/15 |
| 21-60-05-400-801-A TEMPERATURE CONTROL MODULE - INSTALLATION | U | Oct 30/15 |
| 21-60-08/200 <i>EFFECTIVITY: POST-MOD. S.B. 145-21-0039</i> TORQUE-MOTOR DUAL VALVE - MAINTENANCE PRACTICES | U | Oct 30/15 |
| 21-60-08-960-801-A <i>EFFECTIVITY: POST-MOD. S.B. 145-21-0039</i> TORQUE-MOTOR DUAL-VALVE FILTER - REPLACEMENT | U | Oct 31/17 |

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 21
Page 30 of 30
Rev 55 - Oct 29/18