



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL

COCKPIT - COMPONENT LOCATION

EFFECTIVITY: ALL

1. General

- A. This section gives the location of the placards and markings on the cockpit.
- B. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
11-31-00-930-801-A	COCKPIT - COMPONENT LOCATION	ALL



AIRCRAFT MAINTENANCE MANUAL

TASK 11-31-00-930-801-A

EFFECTIVITY: ALL

2. COCKPIT - COMPONENT LOCATION

A. General

(1) [Figure 101](#) shows the location of the cockpit placards and markings.

B. Zones and Accesses

Not Applicable

C. Tools and Equipment

Not Applicable

D. Auxiliary Items

Not Applicable

E. Consumable Materials

Not Applicable

F. Expandable Parts

Not Applicable


G. Persons Recommended

Not Applicable

EFFECTIVITY: ALL

Cockpit - Placards and Markings Location

Figure 101



145AMM110002.MCE

