



EMB145 - EMB135

AIRCRAFT  
MAINTENANCE MANUAL

PFD/MFD BEZEL - REMOVAL/INSTALLATION

EFFECTIVITY: ALL

1. General

- A. This section gives the procedures to remove and install the PFD/MFD BEZEL.
- B. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
34-22-02-000-801-A	PFD/MFD BEZEL - REMOVAL	ALL
34-22-02-400-801-A	PFD/MFD BEZEL - INSTALLATION	ALL



AIRCRAFT  
MAINTENANCE MANUAL

TASK 34-22-02-000-801-A

EFFECTIVITY: ALL

2. PFD/MFD BEZEL - REMOVAL

A. General

- (1) This procedure gives the instructions to remove the PFD/MFD BEZEL.

B. Zones and Accesses

Not Applicable

C. Tools and Equipment

Not Applicable

D. Auxiliary Items

Not Applicable

E. Consumable Materials

Not Applicable

F. Expandable Parts

Not Applicable

G. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	In the cockpit

H. Preparation



SUBTASK 841-002-A

- (1) On the circuit breaker panel, open the MFD/PFD circuit breaker and attach a DO-NOT-CLOSE tag to it.

I. Removal ([Figure 401](#))

SUBTASK 020-002-A

- (1) Remove the two screws (1).
- (2) Pull the PFD/MFD BEZEL (2), until it is disconnected from the connector.
- (3) Remove the PFD/MFD BEZEL (2).

**EFFECTIVITY: ALL**
**PFD/MFD BEZEL - Removal/Installation**
**Figure 401**




EMB145 – EMB135

AIRCRAFT  
MAINTENANCE MANUAL

TASK 34-22-02-400-801-A

EFFECTIVITY: ALL

3. PFD/MFD BEZEL - INSTALLATION

A. General

- (1) This procedure gives the instructions to install the PFD/MFD BEZEL.

B. References

REFERENCE	DESIGNATION
AMM TASK 34-22-00-700-801-A/500	ELECTRONIC FLIGHT INSTRUMENT SYSTEM - OPERATIONAL CHECK

C. Zones and Accesses

Not Applicable

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	In the cockpit

I. Installation (Figure 401)

SUBTASK 420-002-A

- (1) Install the PFD/MFD BEZEL (2).
- (2) Push the PFD/MFD BEZEL (2), until it is connected to the connector.
- (3) Install the two screws (1).

J. Follow-on

SUBTASK 842-002-A

- (1) On the circuit breaker panel, close the PFD/MFD circuit breaker and remove the DO-NOT-CLOSE tag from it.
- (2) Do the EFIS OPERATIONAL CHECK ( [AMM TASK 34-22-00-700-801-A/500](#) ).