


EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL

TABLE OF CONTENTS

<u>PAGEBLOCK TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
56-10-01/400 COCKPIT WINDSHIELD - REMOVAL/INSTALLATION	U	Feb 16/16
56-10-01-000-801-A <i>EFFECTIVITY: PRE-MOD. S.B. 145-56-0006</i> COCKPIT WINDSHIELD - REMOVAL	U	Apr 27/18
56-10-01-400-801-A <i>EFFECTIVITY: PRE-MOD. S.B. 145-56-0006</i> COCKPIT WINDSHIELD - INSTALLATION	U	Apr 28/17
56-10-01-000-802-A <i>EFFECTIVITY: POST-MOD. S.B. 145-56-0006</i> COCKPIT WINDSHIELD - REMOVAL	U	Apr 27/18
56-10-01-400-802-A <i>EFFECTIVITY: POST-MOD. S.B. 145-56-0006</i> COCKPIT WINDSHIELD - INSTALLATION	U	Oct 31/17
56-10-01-040-801-A WINDSHIELD HEATING SYSTEM - DEACTIVATION PROCEDURE	U	Oct 30/15
56-10-01-440-801-A WINDSHIELD HEATING SYSTEM - REACTIVATION PROCEDURE	U	Oct 30/15
56-10-01/500 COCKPIT WINDSHIELD - ADJUSTMENT/TEST	U	Oct 30/15
56-10-01-700-801-A <i>EFFECTIVITY: PRE-MOD. S.B. 145-56-0006</i> COCKPIT WINDSHIELD ATTACHMENTS - FUNCTIONAL CHECK	U	Oct 31/17
56-10-01-700-802-A <i>EFFECTIVITY: POST-MOD. S.B. 145-56-0006</i> COCKPIT WINDSHIELD ATTACHMENTS - FUNCTIONAL CHECK	R	Oct 29/18
56-10-01-700-803-A COCKPIT WINDSHIELD EXTERNAL STATIC CHARGE - FUNCTIONAL CHECK	U	Oct 31/16
56-10-01/600 COCKPIT WINDSHIELD - INSPECTION/CHECK	U	Oct 30/15
56-10-01-200-801-A COCKPIT WINDSHIELD - INSPECTION/CHECK	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted




EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL

PAGEBLOCK <u>TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
56-10-01/700 COCKPIT WINDSHIELD - CLEANING/PAINTING	U	Oct 30/15
56-10-01-100-801-A COCKPIT WINDSHIELD - CLEANING	U	Oct 30/15
56-10-01/800 COCKPIT WINDSHIELD - REPAIRS	U	Feb 16/16
56-10-01-300-801-A <i>EFFECTIVITY: AIRCRAFT WITH SIERRACIN-MADE WINDSHIELD</i> AERODYNAMIC HUMP SEAL - REPAIR	R	Oct 29/18
56-10-01-300-802-A <i>EFFECTIVITY: AIRCRAFT WITH PPG-MADE WINDSHIELD</i> AERODYNAMIC HUMP SEAL - REPAIR	U	Feb 16/16
56-10-02/400 RUBBER TRIM - REMOVAL/INSTALLATION	U	Oct 30/15
56-10-02-000-801-A RUBBER TRIM - REMOVAL	U	Oct 30/15
56-10-02-400-801-A RUBBER TRIM - INSTALLATION	U	Oct 30/15
56-10-02/800 <i>EFFECTIVITY: POST-MOD. S.B. 145-56-0006</i> RUBBER TRIM - REPAIR	U	Oct 30/15
56-10-02-300-801-A <i>EFFECTIVITY: POST-MOD. S.B. 145-56-0006</i> RUBBER TRIM - REPAIR	U	Oct 30/15
56-11-00/500 COCKPIT EMERGENCY EXIT - ADJUSTMENT/TEST	U	Oct 30/15
56-11-00-700-801-A COCKPIT ESCAPE HATCHES - OPERATIONAL CHECK	U	Oct 30/15
56-11-00-820-801-A COCKPIT EMERGENCY EXIT - ALIGNMENT	U	Apr 27/18
56-11-00-820-802-A COCKPIT EMERGENCY EXIT - ADJUSTMENT	U	Oct 30/15


Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



AIRCRAFT
MAINTENANCE MANUAL

PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
56-11-01/300 COCKPIT EMERGENCY EXIT - SERVICING	U	Oct 30/15
56-11-01-600-801-A COCKPIT ESCAPE HATCH - LUBRICATION	U	Oct 30/15
56-11-01/400 COCKPIT EMERGENCY EXIT - REMOVAL/INSTALLATION	U	Apr 27/18
56-11-01-000-801-A COCKPIT EMERGENCY EXIT - REMOVAL	U	Oct 30/15
56-11-01-400-801-A COCKPIT EMERGENCY EXIT - INSTALLATION	U	Oct 30/15
56-11-01-000-802-A COCKPIT EMERGENCY EXIT TRANSPARENCY - REMOVAL	U	Apr 27/18
56-11-01-400-802-A COCKPIT EMERGENCY EXIT TRANSPARENCY - INSTALLATION	U	Apr 27/18
56-11-01/600 COCKPIT EMERGENCY EXIT - INSPECTION/CHECK	U	Oct 30/15
56-11-01-200-801-A COCKPIT EMERGENCY EXIT - INSPECTION/CHECK	U	Oct 30/15
56-11-02/400 COCKPIT EMERGENCY EXIT RUBBER TRIM SEAL - REMOVAL/ INSTALLATION	U	Oct 30/15
56-11-02-000-801-A COCKPIT EMERGENCY-EXIT RUBBER TRIM SEAL - REMOVAL	R	Oct 29/18
56-11-02-400-801-A COCKPIT EMERGENCY-EXIT RUBBER TRIM SEAL - INSTALLATION	U	Oct 30/15
56-11-03/400 COCKPIT EMERGENCY EXIT FRAME SEAL - REMOVAL/INSTALLA- TION	U	Oct 30/15
56-11-03-000-801-A <i>EFFECTIVITY: WITHOUT STRIP AND FILLER</i> COCKPIT EMERGENCY-EXIT FRAME SEAL - REMOVAL	U	Oct 30/15


Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



AIRCRAFT
MAINTENANCE MANUAL

PAGEBLOCK <u>TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
56-11-03-400-801-A <i>EFFECTIVITY: WITHOUT STRIP AND FILLER</i> COCKPIT EMERGENCY-EXIT FRAME SEAL - INSTALLATION	U	Oct 30/15
56-11-03-000-802-A <i>EFFECTIVITY: WITH STRIP AND FILLER</i> COCKPIT EMERGENCY-EXIT FRAME SEAL STRIP AND FRAME FILLER -REMOVAL	U	Oct 31/17
56-11-03-400-802-A <i>EFFECTIVITY: WITH STRIP AND FILLER</i> COCKPIT EMERGENCY-EXIT FRAME SEAL STRIP AND FRAME FILLER -INSTALLATION	U	Oct 30/15
56-11-03/800 COCKPIT EMERGENCY EXIT FRAME SEAL - REPAIR	U	Oct 30/15
56-11-03-300-801-A RUBBER TRIM SEAL - REPAIR	U	Oct 31/17
56-11-04/800 <i>EFFECTIVITY: THIS TASK IS APPLICABLE TO AIRCRAFT S/N UP TO 884</i> COCKPIT EMERGENCY EXIT FRAME SEALANT - REPAIR	U	Oct 30/15
56-11-04-300-801-A <i>EFFECTIVITY: THIS TASK IS APPLICABLE TO AIRCRAFT S/N UP TO 884</i> FUSELAGE FRAME SEALANT - REPAIR	U	Oct 30/15
56-20-01/400 PASSENGER CABIN WINDOWS - REMOVAL/INSTALLATION	U	Oct 30/15
56-20-01-000-801-A PASSENGER CABIN WINDOWS - REMOVAL	R	Oct 29/18
56-20-01-400-801-A PASSENGER CABIN WINDOWS - INSTALLATION	R	Oct 29/18
56-20-01/600 PASSENGER CABIN WINDOWS - INSPECTION/CHECK	U	Oct 30/15
56-20-01-200-801-A PASSENGER CABIN WINDOWS - INSPECTION/CHECK	U	Oct 30/15
56-20-01/700 PASSENGER CABIN WINDOWS - CLEANING/PAINTING	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



AIRCRAFT
MAINTENANCE MANUAL

PAGEBLOCK
TASK

REVISION
STATUS

REVISION
DATE

56-20-01-100-801-A

U

Oct 30/15

PASSENGER CABIN WINDOWS - CLEANING

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 56
Page 5 of 5
Rev 55 - Oct 29/18

