


TABLE OF CONTENTS

<u>PAGEBLOCK</u>	<u>TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
73-11-01/400	FUEL FILTER - REMOVAL/INSTALLATION	U	Oct 30/15
73-11-01-000-801-A	FUEL FILTER - REMOVAL	U	Oct 30/15
73-11-01-400-801-A	FUEL FILTER - INSTALLATION	U	Oct 30/15
73-11-01-040-801-A	FUEL FILTER - DEACTIVATION	U	Oct 30/15
73-11-01-440-801-A	FUEL FILTER - REACTIVATION	U	Oct 30/15
73-11-10/700	FUEL NOZZLES - CLEANING/PAINTING	U	Oct 30/15
73-11-10-100-801-A	FUEL NOZZLES - CLEANING	U	Oct 30/15
73-13-00/600	FUEL NOZZLE ASSEMBLY - INSPECTION/CHECK	U	Oct 30/15
73-13-00-200-801-A	PRIMARY FUEL SYSTEM PLUMBING - INSPECTION	U	Oct 30/15
73-13-01/400	FUEL NOZZLE - REMOVAL/INSTALLATION	U	Oct 30/15
73-13-01-000-801-A	FUEL NOZZLE - REMOVAL	U	Oct 30/15
73-13-01-400-801-A	FUEL NOZZLE - INSTALLATION	U	Oct 30/15
73-13-02/400	FUEL NOZZLE MANIFOLD ASSEMBLY - REMOVAL/INSTALLATION	U	Oct 30/15
73-13-02-000-801-A	FUEL NOZZLE MANIFOLD ASSEMBLY - REMOVAL	U	Oct 30/15
73-13-02-400-801-A	FUEL NOZZLE MANIFOLD ASSEMBLY - INSTALLATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


PAGEBLOCK <u>TASK</u>		<u>REVISION STATUS</u>	<u>REVISION DATE</u>
73-21-00/600	FPMU ASSEMBLY - INSPECTION/CHECK	U	Oct 30/15
73-21-00-200-801-A	FUEL PUMP AND METERING UNIT - INSPECTION	U	Oct 30/15
73-21-01/400	FUEL PUMP&METERING UNIT (FPMU) - REMOVAL/INSTALLATION	U	Oct 30/15
73-21-01-000-801-A	FPMU - REMOVAL	U	Oct 30/15
73-21-01-400-801-A	FPMU - INSTALLATION	U	Oct 30/15
73-21-06/500	FUEL FILTER IMPENDING BY-PASS SYSTEM - ADJUSTMENT/TEST	U	Oct 30/15
73-21-06-700-801-A	FUEL FILTER IMPENDING BYPASS - FUNCTIONAL CHECK	U	Oct 30/15
73-22-01/400	FADEC - REMOVAL/INSTALLATION	U	Oct 30/15
73-22-01-000-801-A	FADEC - REMOVAL	U	Oct 30/15
73-22-01-400-801-A	FADEC - INSTALLATION	U	Feb 16/16
73-22-01/500	FADEC - ADJUSTMENT/TEST	U	Oct 30/15
73-22-01-700-801-A	FADEC DISCRETE LABELS - INSPECTION	U	Feb 16/16
73-22-01-700-802-A	FADEC MAINTENANCE MESSAGES - INSPECTION	U	Oct 30/15
73-22-01-700-803-A	MFD ENG () LT FAULT AND ENG () SCHED MAINT REPAIR MAIN- TENANCE MESSAGES - INSPECTION	U	Oct 30/15
73-22-02/400 CONFIG-1		U	Oct 30/15
<i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i>			
RESISTOR MODULE - REMOVAL/INSTALLATION			

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC


Chapter 73
Page 2 of 4
Rev 55 - Oct 29/18



AIRCRAFT
MAINTENANCE MANUAL

PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
73-22-02-000-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 RESISTOR MODULE - REMOVAL</i>	U	Oct 30/15
73-22-02-400-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 RESISTOR MODULE - INSTALLATION</i>	U	Oct 30/15
73-22-02/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 RESISTOR MODULE - REMOVAL/INSTALLATION</i>	U	Oct 30/15
73-22-02-000-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 RESISTOR MODULE - REMOVAL</i>	U	Oct 30/15
73-22-02-400-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 RESISTOR MODULE - INSTALLATION</i>	U	Oct 30/15
73-22-03/400 FADEC HARNESS - REMOVAL/INSTALLATION	U	Oct 30/15
73-22-03-000-801-A FADEC HARNESS - REMOVAL	U	Oct 30/15
73-22-03-400-801-A FADEC HARNESS - INSTALLATION	U	Oct 30/15
73-25-01/400 P0 SENSOR - REMOVAL/INSTALLATION	U	Oct 30/15
73-25-01-000-801-A P0 SENSOR - REMOVAL	U	Oct 30/15
73-25-01-400-801-A P0 SENSOR - INSTALLATION	U	Oct 30/15
73-30-04/600 FADEC MOUNTS - INSPECTION/CHECK	U	Oct 31/16
73-30-04-200-801-A FADEC ANTIVIBRATION MOUNTS - DETAILED INSPECTION	U	Apr 27/18
73-31-01/400 FUEL FLOWMETER - REMOVAL/INSTALLATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



AIRCRAFT
MAINTENANCE MANUAL

PAGEBLOCK <u>TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
73-31-01-000-801-A FUEL FLOWMETER - REMOVAL	U	Oct 30/15
73-31-01-400-801-A FUEL FLOWMETER - INSTALLATION	U	Oct 30/15
73-32-01/400 FUEL TEMPERATURE SENSOR - REMOVAL/INSTALLATION	U	Oct 30/15
73-32-01-000-801-A FUEL TEMPERATURE SENSOR - REMOVAL	U	Oct 30/15
73-32-01-400-801-A FUEL TEMPERATURE SENSOR - INSTALLATION	U	Oct 30/15
73-33-01/400 FUEL FILTER IMPEDING BY-PASS SWITCH - REMOVAL/INSTALLATION	U	Oct 30/15
73-33-01-000-801-A FUEL-FILTER IMPENDING BY-PASS SWITCH - REMOVAL	U	Oct 30/15
73-33-01-400-801-A FUEL-FILTER IMPENDING BY-PASS SWITCH - INSTALLATION	U	Oct 30/15
73-33-01-040-801-A FUEL-FILTER IMPENDING BY-PASS SWITCH - DEACTIVATION	U	Oct 30/15
73-33-01-440-801-A FUEL-FILTER IMPENDING BY-PASS SWITCH - REACTIVATION	U	Oct 30/15
73-33-02/400 FUEL FILTER ACTUAL BY-PASS VISUAL INDICATOR - REMOVAL/INSTALLATION	U	Oct 30/15
73-33-02-000-801-A FUEL FILTER ACTUAL BY-PASS VISUAL INDICATOR - REMOVAL	U	Oct 30/15
73-33-02-400-801-A FUEL FILTER ACTUAL BY-PASS VISUAL INDICATOR - INSTALLATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted