



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL

PORTRABLE FIRE EXTINGUISHERS - MAINTENANCE PRACTICES

EFFECTIVITY: ALL

1. General

- A. This section gives the procedures to discard the portable fire extinguishers.
- B. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

| TASK NUMBER | DESCRIPTION | EFFECTIVITY |
|----------------------|---|-------------|
| 26-24-01-960-801-A ♦ | PORTABLE FIRE EXTINGUISHERS - DIS- ALL CARD | |



EMB145 – EMB135

AIRCRAFT
MAINTENANCE MANUAL

TASK 26-24-01-960-801-A

EFFECTIVITY: ALL

2. PORTABLE FIRE EXTINGUISHERS - DISCARD

A. General

- (1) To discard the portable fire extinguisher, obey these instructions.

B. References

| REFERENCE | DESIGNATION |
|---------------------------------|--|
| AMM TASK 26-24-01-000-802-A/400 | PORTABLE FIRE EXTINGUISHERS - REMOVAL |
| AMM TASK 26-24-01-400-802-A/400 | PORTABLE FIRE EXTINGUISHERS - INSTALLATION |

C. Zones and Accesses

Not Applicable

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

| QTY | FUNCTION | PLACE |
|-----|---------------|--------------------------------|
| 1 | Does the task | Mission crew cabin and cockpit |

I. Portable Fire Extinguisher Bottle - Discard

SUBTASK 960-002-A

- (1) Remove the portable fire extinguisher and send it to the manufacturer's facilities or to an authorized workshop ([AMM TASK 26-24-01-000-802-A/400](#)).

J. Follow-on

SUBTASK 842-002-A

- (1) Install a new portable-fire-extinguisher ([AMM TASK 26-24-01-400-802-A/400](#)).