


TABLE OF CONTENTS

<u>PAGEBLOCK</u> <u>TASK</u>	<u>REVISION</u> <u>STATUS</u>	<u>REVISION</u> <u>DATE</u>
25-00-00/200 CONFIG-1 <i>EFFECTIVITY: QUICK CHANGE CONFIGURATION</i> EQUIPMENT/FURNISHINGS - MAINTENANCE PRACTICES	U	Oct 30/15
25-00-00-860-801-A CONFIG-1 <i>EFFECTIVITY: QUICK CHANGE CONFIGURATION</i> QUICK CHANGE CONFIGURATION - OPERATION	U	Oct 31/17
25-00-00/700 EQUIPMENT/FURNISHINGS - CLEANING/PAINTING	U	Oct 30/15
25-00-00-100-801-A EQUIPMENT/FURNISHINGS - CLEANING	U	Oct 30/15
25-00-00/800 EQUIPMENT/FURNISHINGS - REPAIR	U	Oct 30/15
25-00-00-300-801-A FILLING AND FAIRING PROCESS - REPAIR	U	Oct 30/15
25-00-00-300-802-A DECORATIVE MATERIALS - REPAIR	U	Oct 30/15
25-00-00-300-804-A EDGE FILL AND EDGE CAST PROCESSES - REPAIR	U	Oct 30/15
25-00-00-300-805-A SEALING OF JOINTS - REPAIR	U	Oct 30/15
25-00-00-300-806-A GENERAL BONDING AND SEALING - REPAIR	U	Oct 30/15
25-00-00-300-807-A NUTPLATES AND RIVNUTS - REWORK	U	Oct 30/15
25-00-00-300-808-A PAINTING AND PRIMING OF COMPOSITE MATERIAL PARTS	U	Oct 30/15
25-00-00-300-809-A COMPOSITE MATERIAL - REPAIR	U	Oct 30/15
25-00-00-300-810-A METAL - FACED LAMINATE REPAIRS	U	Oct 30/15
25-00-00-300-811-A INSERT - REWORK	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
25-00-00-300-812-A FINISHING SOLID-LAMINATE PARTS - REPAIR	U	Oct 30/15
25-10-01/400 <i>EFFECTIVITY: AIRCRAFT WITH LATERAL SUNSHADES</i> LATERAL SUNSHADE - REMOVAL/INSTALLATION	U	Oct 30/15
25-10-01-000-801-A <i>EFFECTIVITY: AIRCRAFT WITH LATERAL SUNSHADES</i> LATERAL SUNSHADES - REMOVAL	U	Oct 30/15
25-10-01-400-801-A <i>EFFECTIVITY: AIRCRAFT WITH LATERAL SUNSHADES</i> LATERAL SUNSHADES - INSTALLATION	U	Oct 30/15
25-11-00/500 COCKPIT SEATS - ADJUSTMENT/TEST	U	Oct 31/17
25-11-00-700-801-A INERTIAL SEAT BELTS - TESTING	U	Apr 28/17
25-11-01/400 PILOT SEATS - REMOVAL/INSTALLATION	U	Oct 30/15
25-11-01-000-801-A PILOT SEAT - REMOVAL	U	Oct 30/15
25-11-01-400-801-A PILOT SEAT - INSTALLATION	U	Oct 30/15
25-11-01-040-801-A PILOT SEAT - DEACTIVATION	U	Oct 30/15
25-11-01-440-801-A PILOT SEAT - REACTIVATION	U	Oct 30/15
25-11-01/600 PILOT SEATS - INSPECTION/CHECK	U	Oct 31/16
25-11-01-200-801-A COCKPIT SEATS - DETAILED INSPECTION	U	Oct 31/17
25-11-01-200-802-A COCKPIT SEAT - INSPECTION	U	Oct 30/15
25-11-01/700 PILOT SEATS - CLEANING/PAINTING	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC


Chapter 25
Page 2 of 35
Rev 55 - Oct 29/18



AIRCRAFT
MAINTENANCE MANUAL

PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
25-11-01-100-801-A LOCKING PINS - CLEANING	U	Oct 30/15
25-11-02/400 OBSERVER SEAT - REMOVAL/INSTALLATION	U	Oct 30/15
25-11-02-000-801-A OBSERVER SEAT - REMOVAL	U	Oct 30/15
25-11-02-400-801-A OBSERVER SEAT - INSTALLATION	U	Oct 30/15
25-12-01/400 CEILING LINING - REMOVAL/INSTALLATION	U	Oct 30/15
25-12-01-000-801-A COCKPIT LINING - REMOVAL	U	Oct 30/15
25-12-01-400-801-A COCKPIT LINING - INSTALLATION	U	Oct 30/15
25-12-03/400 PROCTECTOR OVERHEAD PANEL - REMOVAL/INSTALLATION	U	Oct 30/15
25-12-03-000-801-A OVERHEAD-PANEL ASSEMBLY PROTECTOR - REMOVAL	U	Oct 30/15
25-12-03-400-801-A OVERHEAD-PANEL ASSEMBLY PROTECTOR - INSTALLATION	U	Oct 30/15
25-12-04/400 RH AFT CONSOLE - REMOVAL/INSTALLATION	U	Oct 30/15
25-12-04-000-801-A RH AFT CONSOLE - REMOVAL	U	Oct 30/15
25-12-04-400-801-A RH AFT CONSOLE - INSTALLATION	U	Oct 30/15
25-12-05/400 LH AFT CONSOLE - REMOVAL/INSTALLATION	U	Oct 30/15
25-12-05-000-801-A LH AFT CONSOLE - REMOVAL	U	Oct 30/15
25-12-05-400-801-A LH AFT CONSOLE - INSTALLATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 – EMB135

AIRCRAFT
MAINTENANCE MANUAL


PAGEBLOCK <u>TASK</u>		<u>REVISION STATUS</u>	<u>REVISION DATE</u>
25-12-06/400	PEDAL ASSEMBLY LINING - REMOVAL/INSTALLATION	U	Oct 30/15
25-12-06-000-801-A	PEDAL ASSEMBLY LINING - REMOVAL	U	Oct 30/15
25-12-06-400-801-A	PEDAL ASSEMBLY LINING - INSTALLATION	U	Oct 30/15
25-12-07/400	GLARESHIELD COVERAGE - REMOVAL/INSTALLATION	U	Oct 30/15
25-12-07-000-801-A	GLARESHIELD COVERAGE - REMOVAL	U	Oct 30/15
25-12-07-400-801-A	GLARESHIELD COVERAGE - INSTALLATION	U	Oct 30/15
25-12-08/400 CONFIG-1	<i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> LH/RH COMPLEMENT CONSOLE - REMOVAL/INSTALLATION	U	Oct 30/15
25-12-08-000-801-A CONFIG-1	<i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> LH/RH COMPLEMENT CONSOLE - REMOVAL	U	Oct 30/15
25-12-08-400-801-A CONFIG-1	<i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> LH/RH COMPLEMENT CONSOLE - INSTALLATION	U	Oct 30/15
25-12-08-000-802-A CONFIG-1	<i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> LH/RH COMPLEMENT CONSOLE - REMOVAL	U	Oct 30/15
25-12-08-400-802-A CONFIG-1	<i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> LH/RH COMPLEMENT CONSOLE - INSTALLATION	U	Oct 30/15
25-12-08/400 CONFIG-2	<i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> LH/RH COMPLEMENT CONSOLE - REMOVAL/INSTALLATION	U	Oct 30/15
25-12-08-000-801-A CONFIG-2	<i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> LH/RH COMPLEMENT CONSOLE - REMOVAL	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 25
Page 4 of 35
Rev 55 - Oct 29/18



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
25-12-08-400-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> LH/RH COMPLEMENT CONSOLE - INSTALLATION	U	Oct 30/15
25-12-09/400 LH/RH COCKPIT LINING - REMOVAL/INSTALLATION	U	Oct 30/15
25-12-09-000-801-A LH/RH COCKPIT LINING - REMOVAL	U	Oct 30/15
25-12-09-400-801-A LH/RH COCKPIT LINING - INSTALLATION	U	Oct 30/15
25-12-10/400 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> LH/RH LATERAL CONSOLES - REMOVAL/INSTALLATION	U	Oct 30/15
25-12-10-000-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> COCKPIT LH/RH LATERAL CONSOLES - REMOVAL	U	Oct 30/15
25-12-10-400-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> COCKPIT LH/RH LATERAL CONSOLES - INSTALLATION	U	Oct 30/15
25-12-10/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> LH/RH LATERAL CONSOLES - REMOVAL/INSTALLATION	U	Oct 30/15
25-12-10-000-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> COCKPIT LH/RH LATERAL CONSOLES - REMOVAL	U	Oct 30/15
25-12-10-400-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> COCKPIT LH/RH LATERAL CONSOLES - INSTALLATION	U	Oct 30/15
25-12-11/400 CHART HOLDER ASSEMBLY - REMOVAL/INSTALLATION	U	Oct 30/15
25-12-11-000-801-A CHART HOLDER ASSEMBLY - REMOVAL	U	Oct 30/15
25-12-11-400-801-A CHART HOLDER ASSEMBLY - INSTALLATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 25
Page 5 of 35
Rev 55 - Oct 29/18



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


PAGEBLOCK <u>TASK</u>		<u>REVISION STATUS</u>	<u>REVISION DATE</u>
25-12-13/400	STORM WINDOW MOLDING - REMOVAL/INSTALLATION	U	Oct 30/15
25-12-13-000-801-A	LH/RH STORM WINDOW FAIRING - REMOVAL	U	Oct 30/15
25-12-13-400-801-A	LH/RH STORM WINDOW FAIRING - INSTALLATION	U	Oct 30/15
25-12-14/400	CONTROL COLUMN LININGS - REMOVAL/INSTALLATION	U	Oct 30/15
25-12-14-000-801-A	CONTROL COLUMN LINING - REMOVAL	U	Oct 30/15
25-12-14-400-801-A	CONTROL COLUMN LINING - INSTALLATION	U	Oct 30/15
25-12-14/800	CONTROL COLUMN LININGS - REPAIR	U	Oct 30/15
25-12-14-300-801-A	CONTROL COLUMN BOOT- REPAIR	U	Oct 30/15
25-13-00/800	COCKPIT FINISHING PARTS - REPAIR	U	Oct 30/15
25-13-00-300-801-A	COCKPIT FINISHING SOLID-LAMINATE PARTS - REPAIR	U	Apr 28/17
25-13-00-300-802-A	COCKPIT FINISHING HONEYCOMB-CORE PARTS - REPAIR	U	Oct 30/15
25-13-00-300-803-A	COCKPIT FINISHING POLYCARBONATE PARTS - REPAIR	U	Apr 28/17
25-21-01/400 CONFIG-1	EFFECTIVITY: ACFT MODEL(S) EMB-145 PASSENGER SEATS - REMOVAL/INSTALLATION	U	Oct 31/17
25-21-01-000-801-A CONFIG-1	EFFECTIVITY: ACFT MODEL(S) EMB-145 PASSENGER SEAT ASSEMBLIES - REMOVAL	U	Oct 31/17
25-21-01-400-801-A CONFIG-1	EFFECTIVITY: ACFT MODEL(S) EMB-145 PASSENGER SEAT ASSEMBLIES - INSTALLATION	U	Oct 31/17

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 25
Page 6 of 35
Rev 55 - Oct 29/18



EMB145 – EMB135

AIRCRAFT
MAINTENANCE MANUAL


PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
25-21-01-000-803-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 PASSENGER SEAT ARMREST - REMOVAL</i>	U	Oct 31/17
25-21-01-000-804-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 PASSENGER SEAT FOOD TRAY TABLE - REMOVAL</i>	U	Oct 31/17
25-21-01-000-805-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 PASSENGER SEAT HYDRAULIC LOCK - REMOVAL</i>	U	Oct 31/17
25-21-01-400-803-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 PASSENGER SEAT ARMREST - INSTALLATION</i>	U	Oct 31/17
25-21-01-400-804-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 PASSENGER SEAT FOODTRAY TABLE - INSTALLATION</i>	U	Oct 31/17
25-21-01-400-805-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 PASSENGER SEAT HYDRAULIC LOCK - INSTALLATION</i>	U	Oct 31/17
25-21-01/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 PASSENGER SEATS - REMOVAL/INSTALLATION</i>	U	Oct 31/17
25-21-01-000-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 PASSENGER SEAT ASSEMBLIES - REMOVAL</i>	U	Oct 31/17
25-21-01-400-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 PASSENGER SEAT ASSEMBLIES - INSTALLATION</i>	U	Oct 31/17
25-21-01/500 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 PASSENGER SEATS - ADJUSTMENT/TEST</i>	U	Oct 31/17
25-21-01-800-802-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 PASSENGER SEAT BACK RECLINE - ADJUSTING</i>	U	Oct 31/17
25-21-01-800-803-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 PASSENGER SEAT FOODTRAY TABLE - ADJUSTMENT</i>	U	Oct 31/17

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 25
Page 7 of 35
Rev 55 - Oct 29/18



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
25-21-01-800-804-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 PASSENGER SEATS RECLINE CABLE - ADJUSTMENT</i>	U	Oct 31/17
25-21-01/500 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 PASSENGER SEATS - ADJUSTMENT/TEST</i>	U	Oct 31/17
25-21-01-800-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 PASSENGER SEAT BACK RECLINE - ADJUSTING</i>	U	Oct 31/17
25-21-01/600 PASSENGER SEATS - INSPECTION/CHECK	U	Oct 31/16
25-21-01-200-801-A PASSENGER CABIN SEATS - INSPECTION	U	Oct 30/15
25-21-01-200-802-A PASSENGER CABIN SEATS - DETAILED VISUAL INSPECTION	U	Oct 31/16
25-21-01/800 <i>EFFECTIVITY: AIRCRAFT WITH HYBRID PASSENGER SEATS PASSENGER SEATS - REPAIR</i>	U	Oct 30/15
25-21-01-300-801-A <i>EFFECTIVITY: AIRCRAFT WITH HYBRID PASSENGER SEATS PASSENGER-SEAT FOOD TRAY- REPAIR</i>	U	Oct 30/15
25-21-02/400 FLIGHT ATTENDANT SEAT - REMOVAL/INSTALLATION	U	Feb 16/16
25-21-02-000-801-A FLIGHT ATTENDANT SEAT - REMOVAL	U	Feb 16/16
25-21-02-400-801-A FLIGHT ATTENDANT SEAT - INSTALLATION	U	Feb 16/16
25-21-02-040-801-A FLIGHT ATTENDANT SEAT - DEACTIVATION	U	Feb 16/16
25-21-02-440-801-A FLIGHT ATTENDANT SEAT - REACTIVATION	U	Feb 16/16
25-21-02/600 FLIGHT ATTENDANT SEAT - INSPECTION/CHECK	U	Feb 16/16

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC


Chapter 25
Page 8 of 35
Rev 55 - Oct 29/18



AIRCRAFT
MAINTENANCE MANUAL

PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
25-21-02-200-801-A FLIGHT ATTENDANT SEAT - INSPECTION	U	Feb 16/16
25-21-03/400 <i>EFFECTIVITY: AIRCRAFT WITH OPTIONAL ATTENDANT SEAT</i> OPTIONAL FLIGHT ATTENDANT SEAT - REMOVAL/INSTALLATION	U	Oct 30/15
25-21-03-000-801-A <i>EFFECTIVITY: AIRCRAFT WITH OPTIONAL ATTENDANT SEAT</i> OPTIONAL FLIGHT ATTENDANT SEAT - REMOVAL	U	Oct 31/17
25-21-03-400-801-A <i>EFFECTIVITY: AIRCRAFT WITH OPTIONAL ATTENDANT SEAT</i> OPTIONAL FLIGHT ATTENDANT SEAT - INSTALLATION	U	Oct 31/17
25-21-03-040-801-A <i>EFFECTIVITY: AIRCRAFT WITH OPTIONAL ATTENDANT SEAT</i> OPTIONAL FLIGHT ATTENDANT SEAT - DEACTIVATION	U	Oct 30/15
25-21-03-440-801-A <i>EFFECTIVITY: AIRCRAFT WITH OPTIONAL ATTENDANT SEAT</i> OPTIONAL FLIGHT ATTENDANT SEAT - REACTIVATION	U	Oct 30/15
25-21-03/600 OPTIONAL FLIGHT ATTENDANT SEAT - INSPECTION/CHECK	U	Oct 30/15
25-21-03-200-801-A OPTIONAL FLIGHT ATTENDANT SEAT - INSPECTION	U	Oct 30/15
25-22-01/400 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> LH SERVICE UNIT SUPPORTING STRUCTURE - REMOVAL/INSTALLA-TION	U	Oct 30/15
25-22-01-000-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> PSU STRUCTURE - REMOVAL	U	Oct 31/17
25-22-01-400-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> PSU STRUCTURE - INSTALLATION	U	Oct 31/17
25-22-01/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> LH SERVICE UNIT SUPPORTING STRUCTURE - REMOVAL/INSTALLA-TION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 – EMB135

AIRCRAFT
MAINTENANCE MANUAL


PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
25-22-01-000-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> PSU STRUCTURE - REMOVAL	U	Oct 30/15
25-22-01-400-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> PSU STRUCTURE - INSTALLATION	U	Oct 30/15
25-22-02/400 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> RH SERVICE UNIT SUPPORTING STRUCTURE - REMOVAL/INSTALLATION	U	Oct 30/15
25-22-02-000-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> PSU STRUCTURE - REMOVAL	U	Oct 31/17
25-22-02-400-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> PSU STRUCTURE - INSTALLATION	U	Oct 31/17
25-22-02/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> RH SERVICE UNIT SUPPORTING STRUCTURE - REMOVAL/INSTALLATION	U	Oct 30/15
25-22-02-000-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> PSU STRUCTURE - REMOVAL	U	Oct 30/15
25-22-02-400-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> PSU STRUCTURE - INSTALLATION	U	Oct 30/15
25-22-03/400 OVERHEAD BIN - REMOVAL/INSTALLATION	U	Oct 30/15
25-22-03-000-801-A OVERHEAD BIN - REMOVAL	U	Oct 30/15
25-22-03-400-801-A OVERHEAD BIN - INSTALLATION	U	Oct 30/15
25-22-03-040-801-A OVERHEAD BIN - DEACTIVATION	U	Oct 30/15
25-22-03-440-801-A OVERHEAD BIN - REACTIVATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC


Chapter 25
Page 10 of 35
Rev 55 - Oct 29/18



AIRCRAFT MAINTENANCE MANUAL

<u>PAGEBLOCK TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
25-22-03/500 OVERHEAD BIN - ADJUSTMENT/TEST	U	Oct 30/15
25-22-03-800-801-A CEILING PANEL/OVERHEAD BIN DOOR- ADJUSTMENT	U	Oct 30/15
25-22-04/400 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> HEADLINER - REMOVAL/INSTALLATION	U	Oct 30/15
25-22-04-000-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> HEADLINER - REMOVAL	U	Oct 30/15
25-22-04-400-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> HEADLINER - INSTALLATION	U	Oct 30/15
25-22-04/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> HEADLINER - REMOVAL/INSTALLATION	U	Oct 30/15
25-22-04-000-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> HEADLINER - REMOVAL	U	Oct 30/15
25-22-04-400-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> HEADLINER - INSTALLATION	U	Oct 30/15
25-22-04/500 HEADLINER - ADJUSTMENT/TEST	U	Oct 30/15
25-22-04-800-801-A SERVICE-DOOR REGION CEILING BRACKETRY - ADJUSTMENT	U	Oct 30/15
25-22-05/400 PASSENGER SERVICE UNIT - REMOVAL/INSTALLATION	U	Oct 30/15
25-22-05-000-801-A PSUS - REMOVAL	U	Oct 30/15
25-22-05-400-801-A PSUS - INSTALLATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 – EMB135

AIRCRAFT
MAINTENANCE MANUAL


PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
25-22-07/400 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> BIN&PSU STRUCTURE - REMOVAL/INSTALLATION	U	Oct 30/15
25-22-07-000-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> BIN AND PSU STRUCTURE TUBES - REMOVAL	U	Oct 30/15
25-22-07-400-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> BIN AND PSU STRUCTURE TUBES - INSTALLATION	U	Oct 30/15
25-22-07/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> BIN&PSU STRUCTURE - REMOVAL/INSTALLATION	U	Oct 30/15
25-22-07-000-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> BIN AND PSU STRUCTURE TUBES - REMOVAL	U	Oct 30/15
25-22-07-400-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> BIN AND PSU STRUCTURE TUBES - INSTALLATION	U	Oct 30/15
25-22-07/600 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> BIN&PSU STRUCTURE - INSPECTION/CHECK	U	Oct 30/15
25-22-07-200-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> BIN AND PSU TUBES - INSPECTION/CHECK	U	Oct 30/15
25-22-07/600 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> BIN&PSU STRUCTURE - INSPECTION/CHECK	U	Oct 30/15
25-22-07-200-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> BIN AND PSU TUBES - INSPECTION/CHECK	U	Oct 30/15
25-23-01/400 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> SIDEWALL LINING PANELS - REMOVAL/INSTALLATION	U	Oct 30/15
25-23-01-000-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> SIDEWALL LINING PANELS - REMOVAL	U	Oct 31/17

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 25
Page 12 of 35
Rev 55 - Oct 29/18



AIRCRAFT
MAINTENANCE MANUAL


PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
25-23-01-400-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 SIDEWALL LINING PANELS - INSTALLATION</i>	U	Oct 31/17
25-23-01/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 SIDEWALL LINING PANELS - REMOVAL/INSTALLATION</i>	U	Oct 30/15
25-23-01-000-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 SIDEWALL LINING PANELS - REMOVAL</i>	U	Oct 31/17
25-23-01-400-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 SIDEWALL LINING PANELS - INSTALLATION</i>	U	Oct 31/17
25-23-02/400 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 SKIRTING LINING PANELS - REMOVAL/INSTALLATION</i>	U	Oct 30/15
25-23-02-000-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 SKIRTING LINING PANELS - REMOVAL</i>	U	Oct 31/17
25-23-02-400-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 SKIRTING LINING PANELS - INSTALLATION</i>	U	Oct 31/17
25-23-02/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 SKIRTING LINING PANELS - REMOVAL/INSTALLATION</i>	U	Oct 30/15
25-23-02-000-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 SKIRTING LINING PANELS - REMOVAL</i>	U	Oct 31/17
25-23-02-400-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 SKIRTING LINING PANELS - INSTALLATION</i>	U	Oct 31/17
25-23-03/400 <i>PASSENGER-CABIN ESCAPE-HATCH LINING - REMOVAL/INSTALLA-TION</i>	U	Oct 30/15
25-23-03-000-801-A <i>PASSENGER-CABIN ESCAPE-HATCH LINING - REMOVAL</i>	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 25
Page 13 of 35
Rev 55 - Oct 29/18




EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL

PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
25-23-03-400-801-A PASSENGER-CABIN ESCAPE-HATCH LINING - INSTALLATION	U	Oct 30/15
25-23-04/400 MAIN-DOOR LINING PANELS - REMOVAL/INSTALLATION	U	Oct 30/15
25-23-04-000-801-A MAIN-DOOR LINING PANEL - REMOVAL	R	Oct 29/18
25-23-04-400-801-A MAIN-DOOR LINING PANEL - INSTALLATION	R	Oct 29/18
25-23-05/400 SERVICE DOOR LINING PANELS - REMOVAL/INSTALLATION	U	Oct 30/15
25-23-05-000-801-A SERVICE DOOR LINING PANELS - REMOVAL	U	Oct 30/15
25-23-05-400-801-A SERVICE DOOR LINING PANELS - INSTALLATION	U	Oct 30/15
25-23-06/400 MAIN-DOOR TRIM SHROUD ASSEMBLY - REMOVAL/INSTALLATION	U	Oct 30/15
25-23-06-000-801-A MAIN-DOOR TRIM SHROUD ASSEMBLY - REMOVAL	U	Oct 30/15
25-23-06-400-801-A MAIN-DOOR TRIM SHROUD ASSEMBLY - INSTALLATION	U	Oct 30/15
25-23-07/400 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> SERVICE-DOOR TRIM SHROUD ASSEMBLY - REMOVAL/INSTALLA- TION	U	Oct 30/15
25-23-07-000-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> SERVICE-DOOR TRIM SHROUD ASSEMBLY - REMOVAL	U	Oct 30/15
25-23-07-400-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> SERVICE-DOOR TRIM SHROUD ASSEMBLY - INSTALLATION	U	Oct 30/15
25-23-07/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> SERVICE-DOOR TRIM SHROUD ASSEMBLY - REMOVAL/INSTALLA- TION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted




EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL

PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
25-23-07-000-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> SERVICE-DOOR TRIM SHROUD ASSEMBLY - REMOVAL	U	Oct 30/15
25-23-07-400-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> SERVICE-DOOR TRIM SHROUD ASSEMBLY - INSTALLATION	U	Oct 30/15
25-23-08/400 ESCAPE-HATCH TRIM SHROUD ASSEMBLY - REMOVAL/INSTALLA- TION	U	Oct 30/15
25-23-08-000-801-A ESCAPE-HATCH TRIM SHROUD - REMOVAL	U	Oct 31/17
25-23-08-400-801-A ESCAPE-HATCH TRIM SHROUD - INSTALLATION	U	Oct 31/17
25-23-09/400 WINDOW REVEAL ASSEMBLY - REMOVAL/INSTALLATION	U	Oct 30/15
25-23-09-000-801-A WINDOW REVEAL ASSEMBLY - REMOVAL	U	Oct 30/15
25-23-09-400-801-A WINDOW REVEAL ASSEMBLY - INSTALLATION	U	Oct 30/15
25-24-01/400 PASSENGER-CABIN FLOOR LINING - REMOVAL/INSTALLATION	U	Oct 31/16
25-24-01-000-801-A PASSENGER-CABIN FLOOR LINING - REMOVAL	U	Oct 30/15
25-24-01-400-801-A PASSENGER-CABIN FLOOR LINING - INSTALLATION	U	Oct 30/15
25-26-02/400 CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH RH WARDROBE</i> RH WARDROBE - REMOVAL/INSTALLATION	U	Oct 30/15
25-26-02-000-801-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH RH WARDROBE</i> RH WARDROBE - REMOVAL	U	Oct 30/15
25-26-02-400-801-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH RH WARDROBE</i> RH WARDROBE - INSTALLATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
25-26-02/400 CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH RH WARDROBE</i> RH WARDROBE - REMOVAL/INSTALLATION	U	Oct 30/15
25-26-02-000-802-A CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH RH WARDROBE</i> RH WARDROBE - REMOVAL	U	Oct 30/15
25-26-02-400-802-A CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH RH WARDROBE</i> RH WARDROBE - INSTALLATION	U	Oct 30/15
25-26-03/400 CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH EMERGENCY EQUIPMENT STOWAGE</i> UNIT EMERGENCY EQUIPMENT STOWAGE UNIT - REMOVAL/INSTALLA- TION	U	Oct 30/15
25-26-03-000-801-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH EMERGENCY EQUIPMENT STOWAGE</i> UNIT EMERGENCY EQUIPMENT STOWAGE UNIT - REMOVAL	U	Oct 30/15
25-26-03-400-801-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH EMERGENCY EQUIPMENT STOWAGE</i> UNIT EMERGENCY EQUIPMENT STOWAGE UNIT - INSTALLATION	U	Oct 30/15
25-26-04/400 CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH LH WARDROBE</i> LH WARDROBE - REMOVAL/INSTALLATION	U	Oct 30/15
25-26-04-000-801-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH LH WARDROBE</i> LH WARDROBE - REMOVAL	U	Oct 30/15
25-26-04-400-801-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH LH WARDROBE</i> LH WARDROBE - INSTALLATION	U	Oct 30/15
25-26-04/400 CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH LH WARDROBE</i> LH WARDROBE - REMOVAL/INSTALLATION	U	Oct 30/15
25-26-04-000-803-A CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH LH WARDROBE OPTION 1</i> LH WARDROBE OPTION 1 - REMOVAL	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 25
Page 16 of 35
Rev 55 - Oct 29/18




EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL

PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
25-26-04-400-803-A CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH LH WARDROBE OPTION 1</i> LH WARDROBE OPTION 1 - INSTALLATION	U	Oct 30/15
25-26-04-000-804-A CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH LH WARDROBE OPTION 2</i> LH WARDROBE OPTION 2 - REMOVAL	U	Oct 30/15
25-26-04-400-804-A CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH LH WARDROBE OPTION 2</i> LH WARDROBE OPTION 2 - INSTALLATION	U	Oct 30/15
25-26-07/400 CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH TROLLEY STOWAGE UNIT</i> TROLLEY STOWAGE UNIT - REMOVAL/INSTALLATION	U	Oct 30/15
25-26-07-000-801-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH TROLLEY STOWAGE UNIT</i> TROLLEY STOWAGE UNIT - REMOVAL	U	Oct 30/15
25-26-07-400-801-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH TROLLEY STOWAGE UNIT</i> TROLLEY STOWAGE UNIT - INSTALLATION	U	Oct 30/15
25-26-17/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> LH FORWARD STOWAGE - REMOVAL/INSTALLATION	U	Oct 31/17
25-26-17-000-801-A CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH LH FORWARD STOWAGE OR POST-MOD SB 145-00-0036</i> LH FORWARD STOWAGE - REMOVAL	U	Oct 31/17
25-26-17-400-801-A CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH LH FORWARD STOWAGE OR POST-MOD SB 145-00-0036</i> LH FORWARD STOWAGE - INSTALLATION	U	Oct 31/17
25-27-01/400 COCKPIT/PASSENGER CABIN PARTITION - REMOVAL/INSTALLATION	U	Oct 30/15
25-27-01-000-801-A COCKPIT/PASSENGER CABIN PARTITION - REMOVAL	U	Feb 16/16
25-27-01-400-801-A COCKPIT/PASSENGER CABIN PARTITION - INSTALLATION	U	Feb 16/16

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
25-27-02/400 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> FORWARD BAGGAGE COMPARTMENT PARTITION - REMOVAL/ INSTALLATION	U	Oct 30/15
25-27-02-000-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> FORWARD BAGGAGE-COMPARTMENT PARTITION - REMOVAL	U	Oct 30/15
25-27-02-400-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> FORWARD BAGGAGE-COMPARTMENT PARTITION - INSTALLATION	U	Oct 30/15
25-27-02/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> FORWARD BAGGAGE COMPARTMENT PARTITION - REMOVAL/ INSTALLATION	U	Oct 30/15
25-27-02-000-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> FORWARD BAGGAGE-COMPARTMENT PARTITION - REMOVAL	U	Oct 30/15
25-27-02-400-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> FORWARD BAGGAGE-COMPARTMENT PARTITION - INSTALLATION	U	Oct 30/15
25-27-02/800 FORWARD BAGGAGE COMPARTMENT PARTITION - REPAIR	U	Oct 30/15
25-27-02-300-801-A FORWARD BAGGAGE COMPARTMENT PARTITION - PATCH RE- PAIR	U	Oct 30/15
25-27-02-300-802-A FORWARD BAGGAGE COMPARTMENT PARTITION - RIGID PATCH REPAIR	U	Oct 30/15
25-27-02-300-803-A FORWARD BAGGAGE COMPARTMENT PARTITION - FIREBLOCK BLANKET REWORK	U	Oct 30/15
25-27-03/400 TOILET PARTITION - REMOVAL/INSTALLATION	U	Oct 30/15
25-27-03-000-801-A TOILET PARTITION - REMOVAL	U	Oct 31/17

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 25
Page 18 of 35
Rev 55 - Oct 29/18



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL

PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
25-27-03-400-801-A TOILET PARTITION - INSTALLATION	U	Oct 31/17
25-27-04/400 CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH WINDSCREEN</i> LH WINDSCREEN - REMOVAL/INSTALLATION	U	Oct 30/15
25-27-04-000-801-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH WINDSCREEN</i> WINDSCREEN - REMOVAL	U	Oct 30/15
25-27-04-400-801-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH WINDSCREEN</i> WINDSCREEN - INSTALLATION	U	Oct 30/15
25-27-05/400 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> MAIN DOOR CURTAIN - REMOVAL/INSTALLATION	U	Oct 30/15
25-27-05-000-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> CURTAIN - REMOVAL	U	Oct 30/15
25-27-05-400-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> CURTAIN - INSTALLATION	U	Oct 30/15
25-27-05/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> MAIN DOOR CURTAIN - REMOVAL/INSTALLATION	U	Oct 30/15
25-27-05-000-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> CURTAIN - REMOVAL	U	Oct 30/15
25-27-05-400-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> CURTAIN - INSTALLATION	U	Oct 30/15
25-27-07/400 GALLEY CURTAIN - REMOVAL/INSTALLATION	U	Oct 30/15
25-27-07-000-801-A GALLEY CURTAIN - REMOVAL	U	Oct 30/15
25-27-07-400-801-A GALLEY CURTAIN - INSTALLATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC


Chapter 25
Page 19 of 35
Rev 55 - Oct 29/18



AIRCRAFT MAINTENANCE MANUAL

<u>PAGEBLOCK TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
25-27-08/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> RH WINDSCREEN - REMOVAL/INSTALLATION	U	Oct 30/15
25-27-08-000-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> RH WINDSCREEN - REMOVAL	U	Oct 30/15
25-27-08-400-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> RH WINDSCREEN - INSTALLATION	U	Oct 30/15
25-27-09/400 ATTENDANT CONTROL PANEL - REMOVAL/INSTALLATION	U	Oct 30/15
25-27-09-000-801-A ATTENDANT CONTROL PANEL - REMOVAL	U	Oct 30/15
25-27-09-400-801-A ATTENDANT CONTROL PANEL - INSTALLATION	U	Oct 30/15
25-27-11/400 <i>EFFECTIVITY: AIRCRAFT WITH VENTILATION BOX</i> VENTILATION BOX - REMOVAL/INSTALLATION	U	Oct 30/15
25-27-11-000-801-A <i>EFFECTIVITY: AIRCRAFT WITH VENTILATION BOX</i> VENTILATION BOX ASSEMBLY - REMOVAL	U	Oct 31/17
25-27-11-400-801-A <i>EFFECTIVITY: AIRCRAFT WITH VENTILATION BOX</i> VENTILATION BOX ASSEMBLY - INSTALLATION	U	Oct 31/17
25-27-16/400 CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH VIP-A AND VIP-B CONFIGURATION</i> CLASS PARTITION - REMOVAL/INSTALLATION	U	Oct 30/15
25-27-16-000-801-A CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH VIP-A AND VIP-B CONFIGURATION</i> CLASS PARTITION - REMOVAL	U	Oct 30/15
25-27-16-400-801-A CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH VIP-A AND VIP-B CONFIGURATION</i> CLASS PARTITION - INSTALLATION	U	Oct 30/15
25-27-17/400 COCKPIT DOOR LATCH - REMOVAL/INSTALLATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
25-27-17-000-801-A COCKPIT DOOR LATCH ASSEMBLY - REMOVAL	U	Oct 30/15
25-27-17-400-801-A COCKPIT DOOR LATCH ASSEMBLY - INSTALLATION	U	Oct 30/15
25-27-19/400 CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH VIP-A AND VIP-B CONFIGURATION</i> CLASS CURTAIN - REMOVAL/INSTALLATION	U	Oct 30/15
25-27-19-000-801-A CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH VIP-A AND VIP-B CONFIGURATION</i> CLASS CURTAIN - REMOVAL	U	Oct 30/15
25-27-19-400-801-A CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH VIP-A AND VIP-B CONFIGURATION</i> CLASS CURTAIN - INSTALLATION	U	Oct 30/15
25-28-04/600 CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH MEDEVAC CONFIGURATION</i> BASEPLATE - INSPECTION/CHECK	U	Oct 30/15
25-28-04-200-801-A CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH MEDEVAC CONFIGURATION</i> TRACKS - INSPECTION	U	Oct 30/15
25-28-61/400 CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH MEDEVAC CONFIGURATION</i> BASEPLATE - REMOVAL/INSTALLATION	U	Oct 30/15
25-28-61-000-801-A CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH MEDEVAC CONFIGURATION</i> BASEPLATE - REMOVAL	U	Oct 30/15
25-28-61-400-801-A CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH MEDEVAC CONFIGURATION</i> BASEPLATE - INSTALLATION	U	Oct 30/15
25-28-62/400 CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH MEDEVAC CONFIGURATION</i> CABINET BASEPLATE - REMOVAL/INSTALLATION	U	Oct 30/15
25-28-62-000-801-A CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH MEDEVAC CONFIGURATION</i> CABINET BASEPLATE - REMOVAL	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 25
Page 21 of 35
Rev 55 - Oct 29/18



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
25-28-62-400-801-A CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH MEDEVAC CONFIGURATION CABINET BASEPLATE - INSTALLATION</i>	U	Oct 30/15
25-28-63/400 CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH MEDEVAC CONFIGURATION CABINET KICKGUARD - REMOVAL/INSTALLATION</i>	U	Oct 30/15
25-28-63-000-801-A CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH MEDEVAC CONFIGURATION KICKGUARD - REMOVAL</i>	U	Oct 30/15
25-28-63-400-801-A CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH MEDEVAC CONFIGURATION KICKGUARD - INSTALLATION</i>	U	Oct 30/15
25-30-01/400 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 FORWARD GALLEY ASSEMBLY - REMOVAL/INSTALLATION</i>	U	Oct 30/15
25-30-01-000-801-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH FORWARD GALLEY WITH TWO TROL- LEY'S FORWARD GALLEY WITH TWO TROLLEYS - REMOVAL</i>	U	Oct 30/15
25-30-01-400-801-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH FORWARD GALLEY WITH TWO TROL- LEY'S FORWARD GALLEY WITH TWO TROLLEYS - INSTALLATION</i>	U	Oct 30/15
25-30-01-000-802-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH FORWARD GALLEY WITH ONE TROL- LEY FORWARD GALLEY WITH ONE TROLLEY - REMOVAL</i>	U	Oct 30/15
25-30-01-400-802-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH FORWARD GALLEY WITH ONE TROL- LEY FORWARD GALLEY WITH ONE TROLLEY - INSTALLATION</i>	U	Oct 30/15
25-30-01-000-803-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH FORWARD GALLEY WITHOUT TROL- LEY FORWARD GALLEY WITHOUT TROLLEY - REMOVAL</i>	U	Oct 30/15
25-30-01-400-803-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH FORWARD GALLEY WITHOUT TROL- LEY FORWARD GALLEY WITHOUT TROLLEY - INSTALLATION</i>	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 25
Page 22 of 35
Rev 55 - Oct 29/18



EMB145 – EMB135

AIRCRAFT
MAINTENANCE MANUAL


PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
25-30-01-000-805-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 FORWARD GALLEY WITHOUT TROLLEY - REMOVAL</i>	U	Oct 30/15
25-30-01-400-805-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH FORWARD GALLEY WITHOUT TROLLEY FORWARD GALLEY WITHOUT TROLLEY - INSTALLATION</i>	U	Oct 30/15
25-30-01-040-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 FORWARD GALLEY - DEACTIVATION</i>	U	Oct 30/15
25-30-01-440-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 FORWARD GALLEY- REACTIVATION</i>	U	Oct 30/15
25-30-01/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 FORWARD GALLEY ASSEMBLY - REMOVAL/INSTALLATION</i>	U	Oct 30/15
25-30-01-000-804-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 FORWARD GALLEY - REMOVAL</i>	U	Oct 30/15
25-30-01-400-804-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 FORWARD GALLEY - INSTALLATION</i>	U	Oct 30/15
25-30-01-040-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 FORWARD GALLEY - DEACTIVATION</i>	U	Oct 30/15
25-30-01-440-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 FORWARD GALLEY- REACTIVATION</i>	U	Oct 30/15
25-30-02/400 CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH AFT GALLEY AFT GALLEY ASSEMBLY - REMOVAL/INSTALLATION</i>	U	Oct 30/15
25-30-02-000-801-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH AFT GALLEY AFT GALLEY - REMOVAL</i>	U	Oct 30/15
25-30-02-400-801-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH AFT GALLEY AFT GALLEY - INSTALLATION</i>	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 25
Page 23 of 35
Rev 55 - Oct 29/18



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
25-30-02-040-801-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH AFT GALLEY AFT GALLEY - DEACTIVATION</i>	U	Oct 30/15
25-30-02-440-801-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH AFT GALLEY AFT GALLEY- REACTIVATION</i>	U	Oct 30/15
25-30-05/400 <i>EFFECTIVITY: AIRCRAFT WITH OUTBOARD GALLEY OUTBOARD GALLEY ASSEMBLY - REMOVAL/INSTALLATION</i>	U	Oct 30/15
25-30-05-000-802-A <i>EFFECTIVITY: AIRCRAFT WITH OUTBOARD GALLEY OUTBOARD GALLEY - REMOVAL</i>	U	Oct 30/15
25-30-05-400-802-A <i>EFFECTIVITY: AIRCRAFT WITH OUTBOARD GALLEY OUTBOARD GALLEY - INSTALLATION</i>	U	Oct 30/15
25-30-05-040-801-A <i>EFFECTIVITY: AIRCRAFT WITH OUTBOARD GALLEY OUTBOARD GALLEY - DEACTIVATION</i>	U	Oct 30/15
25-30-05-440-801-A <i>EFFECTIVITY: AIRCRAFT WITH OUTBOARD GALLEY OUTBOARD GALLEY - REACTIVATION</i>	U	Oct 30/15
25-30-07/400 CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH LH GALLEY LH GALLEY - REMOVAL/INSTALLATION</i>	U	Oct 31/17
25-30-07-000-801-A CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH LH GALLEY OR PRE-MOD SB 145-00-0036 LH GALLEY - REMOVAL</i>	U	Oct 31/17
25-30-07-400-801-A CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WITH LH GALLEY OR PRE-MOD SB 145-00-0036 LH GALLEY - INSTALLATION</i>	U	Oct 31/17
25-31-03/200 <i>EFFECTIVITY: QUICK CHANGE OF THE OUTBOARD GALLEY CONFIGU- RATION OVENS - MAINTENANCE PRACTICES</i>	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 25
Page 24 of 35
Rev 55 - Oct 29/18



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
25-31-03-860-801-A <i>EFFECTIVITY: QUICK CHANGE CONFIGURATION QUICK CHANGE CONFIGURATION - OPERATION</i>	U	Oct 30/15
25-31-03/400 <i>EFFECTIVITY: AIRCRAFT WITH OVEN OVENS - REMOVAL/INSTALLATION</i>	U	Oct 30/15
25-31-03-000-801-A <i>EFFECTIVITY: AIRCRAFT WITH OVEN OVENS AND OVEN CONTROLLERS - REMOVAL</i>	U	Oct 30/15
25-31-03-400-801-A <i>EFFECTIVITY: AIRCRAFT WITH OVEN OVENS AND OVEN CONTROLLERS - INSTALLATION</i>	U	Oct 30/15
25-31-03/500 <i>EFFECTIVITY: AIRCRAFT WITH OVEN OVENS - ADJUSTMENT/TEST</i>	U	Oct 30/15
25-31-03-700-801-A <i>EFFECTIVITY: AIRCRAFT WITH OVEN OVEN - TEST</i>	U	Oct 30/15
25-31-03-700-802-A <i>EFFECTIVITY: AIRCRAFT WITH OVEN OVERHEAT THERMOSTAT RESET</i>	U	Oct 30/15
25-31-06/400 CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH HOT JUGS INVERTERS HOT JUG INVERTERS - REMOVAL/INSTALLATION</i>	U	Oct 30/15
25-31-06-000-801-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH HOT JUGS INVERTERS HOT JUG INVERTERS - REMOVAL</i>	U	Oct 30/15
25-31-06-400-801-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH HOT JUGS INVERTERS HOT JUG INVERTERS - INSTALLATION</i>	U	Oct 30/15
25-40-01/400 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 LAVATORY - REMOVAL/INSTALLATION</i>	U	Oct 30/15
25-40-01-000-801-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WHOSE FILL/OVERFLOW LINES ARE ATTACHED TO THE FORWARD BAGGAGE COMPARTMENT PARTITION LAVATORY - REMOVAL</i>	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 25
Page 25 of 35
Rev 55 - Oct 29/18



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
25-40-01-400-801-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WHOSE FILL/OVERFLOW LINES ARE ATTACHED TO THE FORWARD BAGGAGE COMPARTMENT PARTITION LAVATORY - INSTALLATION</i>	U	Oct 30/15
25-40-01-000-802-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WHOSE FILL/OVERFLOW LINES GO BELOW THE FLOOR LAVATORY - REMOVAL</i>	U	Oct 30/15
25-40-01-400-802-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WHOSE FILL/OVERFLOW LINES GO BELOW THE FLOOR LAVATORY - INSTALLATION</i>	U	Oct 30/15
25-40-01-000-803-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 LAVATORY ACCESS PANEL - REMOVAL</i>	U	Oct 30/15
25-40-01-400-803-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145 LAVATORY ACCESS PANEL - INSTALLATION</i>	U	Oct 30/15
25-40-01/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 LAVATORY - REMOVAL/INSTALLATION</i>	U	Oct 30/15
25-40-01-000-801-A CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WHOSE FILL/OVERFLOW LINES ARE ATTACHED TO THE FORWARD BAGGAGE COMPARTMENT PARTITION LAVATORY - REMOVAL</i>	U	Oct 30/15
25-40-01-400-801-A CONFIG-2 <i>EFFECTIVITY: AIRCRAFT WHOSE FILL/OVERFLOW LINES ARE ATTACHED TO THE FORWARD BAGGAGE COMPARTMENT PARTITION LAVATORY - INSTALLATION</i>	U	Oct 30/15
25-40-01-000-803-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 LAVATORY ACCESS PANEL - REMOVAL</i>	U	Oct 30/15
25-40-01-400-803-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135 LAVATORY ACCESS PANEL - INSTALLATION</i>	U	Oct 30/15
25-40-01-600 <i>LAVATORY - INSPECTION/CHECK</i>	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC


Chapter 25
Page 26 of 35
Rev 55 - Oct 29/18



AIRCRAFT
MAINTENANCE MANUAL

PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
25-40-01-200-801-A LAVATORY WASTE DISPOSAL DOOR - INSPECTION	U	Oct 30/15
25-40-02/300 LAVATORY DOOR LOCK - SERVICING	U	Oct 30/15
25-40-02-600-801-A LAVATORY DOOR- LUBRICATION	U	Oct 30/15
25-40-02/400 LAVATORY DOOR LOCK - REMOVAL/INSTALLATION	U	Oct 30/15
25-40-02-000-801-A LAVATORY DOOR LOCK - REMOVAL	U	Oct 30/15
25-40-02-400-801-A LAVATORY DOOR LOCK - INSTALLATION	U	Oct 30/15
25-40-02/500 LAVATORY DOOR LOCK - ADJUSTMENT/TEST	U	Oct 30/15
25-40-02-700-801-A LAVATORY DOOR INDICATOR LATCH - TEST	U	Oct 30/15
25-40-03/500 LAVATORY DOOR - ADJUSTMENT/TEST	U	Oct 30/15
25-40-03-700-801-A LAVATORY DOOR - FUNCTIONAL CHECK	U	Oct 30/15
25-40-03/700 LAVATORY DOOR - CLEANING/PAINTING	U	Oct 30/15
25-40-03-100-801-A LAVATORY DOOR PARTS - CLEANING	U	Oct 30/15
25-40-04/400 TOILET SHROUD ASSEMBLY - REMOVAL/INSTALLATION	U	Oct 30/15
25-40-04-000-801-A TOILET SHROUD ASSEMBLY - REMOVAL	U	Oct 30/15
25-40-04-400-801-A TOILET SHROUD ASSEMBLY - INSTALLATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


PAGEBLOCK <u>TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
25-40-07/400 LAVATORY SOAP DISPENSER - REMOVAL/INSTALLATION	U	Oct 30/15
25-40-07-000-801-A LAVATORY SOAP DISPENSER- REMOVAL	U	Oct 30/15
25-40-07-400-801-A LAVATORY SOAP DISPENSER - INSTALLATION	U	Oct 30/15
25-44-01/400 LAVATORY DOOR - REMOVAL/INSTALLATION	U	Oct 30/15
25-44-01-000-801-A LAVATORY SLIDE DOOR - REMOVAL	U	Oct 30/15
25-44-01-400-801-A LAVATORY SLIDE DOOR - INSTALLATION	U	Oct 30/15
25-44-01-000-802-A LAVATORY BI-FOLD DOOR - REMOVAL	U	Oct 30/15
25-44-01-400-802-A LAVATORY BI-FOLD DOOR - INSTALLATION	U	Oct 30/15
25-50-01/400 ANTI-BLOCKAGE BARRIER - REMOVAL/INSTALLATION	U	Oct 30/15
25-50-01-000-801-A BAGGAGE-COMPARTMENT ANTI-BLOCKAGE BARRIER - REMOVAL	U	Oct 30/15
25-50-01-400-801-A BAGGAGE-COMPARTMENT ANTI-BLOCKAGE BARRIER - INSTALLA- TION	U	Oct 30/15
25-50-01/800 ANTI-BLOCKAGE BARRIER - REPAIR	U	Oct 30/15
25-50-01-300-801-A ANTI-BLOCKAGE BARRIER (OVERLAP) - REPAIR	U	Oct 30/15
25-50-01-300-802-A ANTI-BLOCKAGE BARRIER (SPLICING AND ATTACHMENTS) - REPAIR	U	Oct 30/15
25-50-02/400 CARGO NET - REMOVAL/INSTALLATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 25
Page 28 of 35
Rev 55 - Oct 29/18




EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL

PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
25-50-02-000-801-A CARGO NET ASSEMBLY - REMOVAL	U	Oct 30/15
25-50-02-400-801-A CARGO NET ASSEMBLY - INSTALLATION	U	Oct 30/15
25-50-02/600 CARGO NET - INSPECTION/CHECK	U	Oct 30/15
25-50-02-200-801-A CARGO NET - INSPECTION	U	Oct 30/15
25-50-03/400 CARGO LOADING/UNLOADING RAMP - REMOVAL/INSTALLATION	U	Oct 30/15
25-50-03-000-802-A CARGO LOADING/UNLOADING RAMP - REMOVAL	U	Oct 30/15
25-50-03-400-802-A CARGO LOADING/UNLOADING RAMP - INSTALLATION	U	Oct 30/15
25-50-04/400 CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH RAMP ASSEMBLY</i> RAMP ASSEMBLY - REMOVAL/INSTALLATION	U	Oct 30/15
25-50-04-000-802-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH RAMP ASSEMBLY</i> RAMP ASSEMBLY - REMOVAL	U	Oct 30/15
25-50-04-400-802-A CONFIG-1 <i>EFFECTIVITY: AIRCRAFT WITH RAMP ASSEMBLY</i> RAMP ASSEMBLY - INSTALLATION	U	Oct 30/15
25-51-01/400 BAGGAGE COMPARTMENT LINING - REMOVAL/INSTALLATION	U	Oct 30/15
25-51-01-000-801-A BAGGAGE COMPARTMENT LINING - REMOVAL	U	Oct 30/15
25-51-01-400-801-A BAGGAGE COMPARTMENT LINING - INSTALLATION	U	Oct 30/15
25-51-01/600 BAGGAGE COMPARTMENT LINING - INSPECTION/CHECK	U	Oct 30/15
25-51-01-200-801-A BAGGAGE COMPARTMENT LINING - VISUAL INSPECTION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


PAGEBLOCK <u>TASK</u>		<u>REVISION STATUS</u>	<u>REVISION DATE</u>
25-51-01/800	BAGGAGE COMPARTMENT LINING - REPAIR	U	Oct 30/15
25-51-01-300-801-A	BAGGAGE COMPARTMENT LINING - PATCH REPAIR	U	Oct 30/15
25-51-01-300-802-A	BAGGAGE COMPARTMENT LINING - OLD LINER REPAIR	U	Oct 30/15
25-51-01-300-803-A	BAGGAGE COMPARTMENT LINING - WET LAY-UP REPAIR	U	Oct 30/15
25-51-01-300-804-A	BAGGAGE COMPARTMENT LINING - WET LAY-UP WITH DOUBLER PLATES AND REPAIR-TAPE REPAIR	U	Oct 30/15
25-51-01-300-805-A	BAGGAGE COMPARTMENT LINING - REINFORCEMENT	U	Oct 30/15
25-51-02/400	BAGGAGE DOOR LINING - REMOVAL/INSTALLATION	U	Oct 30/15
25-51-02-000-801-A	BAGGAGE DOOR LINING - REMOVAL	U	Oct 30/15
25-51-02-400-801-A	BAGGAGE DOOR LINING - INSTALLATION	U	Oct 30/15
25-51-03/400	AFT PRESSURE BULKHEAD - REMOVAL/INSTALLATION	U	Oct 30/15
25-51-03-000-801-A	AFT PRESSURE BULKHEAD - REMOVAL	U	Oct 30/15
25-51-03-400-801-A	AFT PRESSURE BULKHEAD - INSTALLATION	U	Oct 30/15
25-51-03/800	AFT PRESSURE BULKHEAD - REPAIR	U	Oct 30/15
25-51-03-300-801-A	AFT PRESSURE BULKHEAD - PATCH REPAIR	U	Oct 30/15
25-51-03-300-802-A	AFT PRESSURE BULKHEAD - WET LAY-UP REPAIR	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC


Chapter 25
Page 30 of 35
Rev 55 - Oct 29/18



AIRCRAFT MAINTENANCE MANUAL

<u>PAGEBLOCK TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
25-51-04/400 BAGGAGE COMPARTMENT FLOOR LINING - REMOVAL/INSTALLATION	U	Oct 30/15
25-51-04-000-801-A BAGGAGE-COMPARTMENT FLOOR LINING - REMOVAL	U	Oct 30/15
25-51-04-400-801-A BAGGAGE-COMPARTMENT FLOOR LINING - INSTALLATION	U	Oct 30/15
25-60-01/600 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> FIRST AID KIT&MEDICAL KIT - INSPECTION/CHECK	U	Oct 30/15
25-60-01-200-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> FIRST-AID KIT AND MEDICAL KIT - INSPECTION	U	Oct 30/15
25-60-01/600 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> FIRST AID KIT&MEDICAL KIT - INSPECTION/CHECK	U	Apr 28/17
25-60-01-200-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> FIRST-AID KIT AND MEDICAL KIT - INSPECTION	U	Oct 30/15
25-60-02/200 FLOTATION VEST - MAINTENANCE PRACTICES	U	Oct 30/15
25-60-02-900-801-A FLOTATION VEST - RESTORE	U	Oct 30/15
25-60-04/200 MEGAPHONE - MAINTENANCE PRACTICES	U	Apr 28/17
25-60-04-960-801-A MEGAPHONE BATTERY - DISCARD	U	Oct 30/15
25-60-04/500 MEGAPHONE - ADJUSTMENT/TEST	U	Oct 30/15
25-60-04-710-801-A MEGAPHONE - OPERATIONAL CHECK	U	Oct 30/15
25-60-07/400 ESCAPE ROPE - REMOVAL/INSTALLATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
25-60-07-000-801-A ESCAPE ROPE - REMOVAL	U	Oct 30/15
25-60-07-400-801-A ESCAPE ROPE - INSTALLATION	U	Oct 30/15
25-60-07/600 ESCAPE ROPE - INSPECTION/CHECK	U	Oct 31/17
25-60-07-200-801-A ESCAPE ROPE - INSPECTION	U	Oct 30/15
25-61-00/200 EMERGENCY LOCATOR TRANSMITTER SYSTEM - MAINTENANCE PRACTICES	U	Oct 30/15
25-61-00-400-801-A EMERGENCY LOCATOR TRANSMITTER SYSTEM (ELT SATORI) - PROGRAMMING	U	Oct 30/15
25-61-00-400-802-A EMERGENCY LOCATOR TRANSMITTER SYSTEM (ARTEX C406-2) - PROGRAMMING	U	Apr 29/16
25-61-00/500 EMERGENCY LOCATOR TRANSMITTER SYSTEM - ADJUSTMENT/ TEST	U	Oct 30/15
25-61-00-700-801-A EMERGENCY LOCATOR TRANSMITTER SYSTEM (ELT 110-4) - OP- ERATIONAL CHECK	U	Oct 30/15
25-61-00-700-802-A EMERGENCY-LOCATOR-TRANSMITTER SYSTEM (ELT SATORI) - OPERATIONAL CHECK	U	Oct 30/15
25-61-00-700-803-A EMERGENCY LOCATOR TRANSMITTER SYSTEM (ELT C406-2) - OPERATIONAL CHECK	U	Apr 29/16
25-61-00/600 EMERGENCY LOCATOR TRANSMITTER SYSTEM - INSPECTION/ CHECK	U	Oct 30/15
25-61-00-200-801-A EMERGENCY LOCATOR TRANSMITTER - INSPECTION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 25
Page 32 of 35
Rev 55 - Oct 29/18



AIRCRAFT
MAINTENANCE MANUAL

PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
25-61-01/400 EMERGENCY LOCATOR TRANSMITTER - REMOVAL/INSTALLATION	U	Oct 30/15
25-61-01-000-801-A EMERGENCY LOCATOR TRANSMITTER (ELT 110-4) - REMOVAL	U	Oct 30/15
25-61-01-400-801-A EMERGENCY LOCATOR TRANSMITTER (ELT 110-4) - INSTALLA- TION	U	Oct 30/15
25-61-01-000-802-A EMERGENCY LOCATOR TRANSMITTER (ELT SATORI) - REMOVAL	U	Oct 30/15
25-61-01-400-802-A EMERGENCY LOCATOR TRANSMITTER (ELT SATORI) - INSTALLA- TION	U	Oct 30/15
25-61-01-000-803-A EMERGENCY LOCATOR TRANSMITTER (ELT C406-2) - REMOVAL	U	Oct 30/15
25-61-01-400-803-A EMERGENCY LOCATOR TRANSMITTER (ELT C406-2) - INSTALLA- TION	U	Oct 30/15
25-61-01-040-801-A EMERGENCY LOCATOR TRANSMITTER - DEACTIVATION	U	Oct 30/15
25-61-01-440-801-A EMERGENCY LOCATOR TRANSMITTER - REACTIVATION	U	Oct 30/15
25-61-02/400 ELT REMOTE SWITCH PANEL - REMOVAL/INSTALLATION	U	Oct 30/15
25-61-02-000-801-A ELT REMOTE SWITCH PANEL (ELT ARTEX) - REMOVAL	U	Oct 30/15
25-61-02-400-801-A ELT REMOTE SWITCH PANEL (ELT ARTEX) - INSTALLATION	U	Oct 30/15
25-61-02-000-802-A ELT REMOTE SWITCH PANEL (ELT SATORI) - REMOVAL	U	Oct 30/15
25-61-02-400-802-A ELT REMOTE SWITCH PANEL (ELT SATORI) - INSTALLATION	U	Oct 30/15
25-61-03/400 ELT ANTENNA - REMOVAL/INSTALLATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
25-61-03-000-801-A ELT ANTENNA - REMOVAL	U	Oct 30/15
25-61-03-400-801-A ELT ANTENNA - INSTALLATION	U	Oct 30/15
25-61-04/200 TRANSMITTER BATTERY - MAINTENANCE PRACTICES	U	Oct 30/15
25-61-04-900-801-A ELT BATTERY - REPLACEMENT	U	Oct 30/15
25-61-04/600 TRANSMITTER BATTERY - INSPECTION/CHECK	U	Oct 30/15
25-61-04-200-801-A ELT BATTERY EXPIRATION DATE - GENERAL VISUAL INSPECTION	U	Oct 30/15
25-81-01/200 THERMOACOUSTIC INSULATION - MAINTENANCE PRACTICES	U	Oct 30/15
25-81-01-800-801-A THERMOACOUSTIC INSULATION - DISPLACEMENT	U	Oct 30/15
25-81-01/400 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> THERMOACOUSTIC INSULATION - REMOVAL/INSTALLATION	U	Oct 30/15
25-81-01-000-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> THERMOACOUSTIC INSULATION - REMOVAL	U	Oct 30/15
25-81-01-400-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> THERMOACOUSTIC INSULATION - INSTALLATION	U	Oct 30/15
25-81-01/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> THERMOACOUSTIC INSULATION - REMOVAL/INSTALLATION	U	Oct 30/15
25-81-01-000-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> THERMOACOUSTIC INSULATION - REMOVAL	U	Oct 30/15
25-81-01-400-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> THERMOACOUSTIC INSULATION - INSTALLATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 25
Page 34 of 35
Rev 55 - Oct 29/18



AIRCRAFT
MAINTENANCE MANUAL

<u>PAGEBLOCK TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
25-81-01/800 THERMOACOUSTIC INSULATION - REPAIR	U	Oct 30/15
25-81-01-300-801-A THERMOACOUSTIC INSULATION PADS - REPAIR	U	Oct 30/15
25-81-02/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> SOUND-PROOFING BLANKET - REMOVAL/INSTALLATION	U	Oct 30/15
25-81-02-000-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> SOUND-PROOFING BLANKET - REMOVAL	U	Oct 31/17
25-81-02-400-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> SOUND-PROOFING BLANKET - INSTALLATION	U	Oct 31/17

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 25
Page 35 of 35
Rev 55 - Oct 29/18

