



AIRCRAFT MAINTENANCE MANUAL

EXHAUST HOSES - REMOVAL/INSTALLATION

EFFECTIVITY: ALL

1. General

- A. The two exhaust hoses are installed at the forward electronic-compartment air exhaustion system (between frames 5 and 6). The removal/installation procedures are applicable to the two exhaust hoses.
- B. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
21-26-08-000-801-A	EXHAUST HOSES - REMOVAL	ALL
21-26-08-400-801-A	EXHAUST HOSES - INSTALLATION	ALL



EMB145 – EMB135

AIRCRAFT
MAINTENANCE MANUAL

TASK 21-26-08-000-801-A

EFFECTIVITY: ALL

2. EXHAUST HOSES - REMOVAL

A. General

- (1) This task gives the procedures to remove the exhaust hoses.

B. References

REFERENCE	DESIGNATION
AMM MPP 06-41-01/100	-
SB145-21-0013	-

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
113	113CZ	Nose-landing-gear compartment

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Forward electronic compartment

I. Preparation

SUBTASK 841-002-A

- (1) On the overhead circuit breaker panel, open the EXHAUST 1 and EXHAUST 2 circuit breakers and attach DO-NOT-CLOSE tags to them.
- (2) Open access panel 113CZ (AMM MPP 06-41-01/100).

J. Removal ([Figure 401](#))

SUBTASK 020-002-A

- (1) Loosen the clamps (2) which attach the exhaust hose (1) (on aircraft PRE-MOD [SB145-21-0013](#)) or the reinforced exhaust hose (5) (on aircraft POST-MOD SB 145-21-0013) to the check valve (3) and to the duct (4).






AIRCRAFT
MAINTENANCE MANUAL

-
- (2) Remove the exhaust hose (1) (on aircraft PRE-MOD [SB145-21-0013](#)) or the reinforced exhaust hose (5) (on aircraft POST-MOD SB 145-21-0013).

EFFECTIVITY: ALL

Exhaust Hoses - Removal/Installation

Figure 401



1 PRE-MOD SB 145-21-0013

2 POST-MOD SB 145-21-0013

3 TORQUE: 1.69–2.25 Nm (15–20 lb.in) (POST-MOD ONLY)

EM145AMM211248A.DGN



AIRCRAFT MAINTENANCE MANUAL

TASK 21-26-08-400-801-A

EFFECTIVITY: ALL

3. EXHAUST HOSES - INSTALLATION

A. General

- (1) This task gives the procedures to install the exhaust hoses.

B. References

REFERENCE	DESIGNATION
AMM MPP 06-41-01/100	-
AMM TASK 21-26-00-700-801-A/500	ELECTRONIC COMPARTMENT VENTILATION SYSTEM - OPERATIONAL CHECK
SB145-21-0013	-

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
113	113CZ	Nose-landing-gear compartment

D. Tools and Equipment

ITEM	DESCRIPTION	PURPOSE	QTY
Commercially available	Torque wrench	To tighten the clamps	

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Forward electronic compartment

I. Installation (Figure 401)

SUBTASK 420-002-A

- (1) Put the exhaust hose (1) (on aircraft PRE-MOD SB145-21-0013) or the reinforced exhaust hose (5) (on aircraft POST-MOD SB 145-21-0013) in the installation position.
- (2) On aircraft PRE-MOD SB145-21-0013, tighten the clamps (2) which attach the exhaust hose (1) to the check valve (3) and to the duct (4).



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL

- (3) On aircraft POST-MOD [SB145-21-0013](#), tighten the clamps (2) which attach the reinforced exhaust hose (5) to the check valve (3) and to the duct (4) with a torque of 1.69-2.25 N.m (15-20 lb.in).

J. Follow-on

SUBTASK 842-002-A

- (1) Close access panel 113CZ (AMM MPP 06-41-01/100).
- (2) On the overhead circuit breaker panel, remove the DO-NOT-CLOSE tags from the EXHAUST 1 and EXHAUST 2 circuit breakers and close them.
- (3) Do [AMM TASK 21-26-00-700-801-A/500](#).