



AIRCRAFT  
MAINTENANCE MANUAL

LAVATORY - INSPECTION/CHECK

EFFECTIVITY: ALL

1. General

- A. This section gives the procedures to inspect the lavatory waste disposal door.
- B. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
25-40-01-200-801-A ♦	LAVATORY WASTE DISPOSAL DOOR - INSPECTION	ALL



EMB145 – EMB135

AIRCRAFT  
MAINTENANCE MANUAL

TASK 25-40-01-200-801-A

EFFECTIVITY: ALL

2. LAVATORY WASTE DISPOSAL DOOR - INSPECTION

A. General

- (1) The function of this inspection is to make sure that the lavatory waste disposal door operates correctly.

B. References

REFERENCE	DESIGNATION
IPC 25-40-01	LAVATORY

C. Zones and Accesses

Not Applicable

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Lavatory

I. Preparation

SUBTASK 841-002-A


- (1) To do the detailed inspection of the lavatory waste disposal door, have a direct source of good lighting to make the lighting conditions in the lavatory better.

J. Inspection (Detailed Inspection) of the Lavatory Waste Disposal Door

SUBTASK 220-002-A

- (1) Do a detailed inspection of the attaching parts which attach the lavatory waste disposal door as follows ([Figure 601](#)):

- (a) Examine the lavatory waste disposal door for general condition, easily seen degradation, crack, corrosion, damage and failure.
- (b) Examine the springs, waste deflectors and flap attachments for general conditions, easily seen degradation, crack, corrosion, damage and failure.



EMB145 - EMB135


AIRCRAFT  
MAINTENANCE MANUAL

- (c) Close and open the lavatory waste disposal door two or three times to make sure that it operates correctly.
  - (d) Make sure that the springs permit the correct closing and opening operation of the lavatory waste disposal door.
- (2) Replace the defective parts (IPC 25-40-01).

**EFFECTIVITY: ALL**

Lavatory Waste Disposal door - Inspection

Figure 601



145AMM250766.MCE