



## AIRCRAFT MAINTENANCE MANUAL

### FLIGHT ATTENDANT SEAT - INSPECTION/CHECK

EFFECTIVITY: ALL

#### 1. General

- A. This section gives the procedures to inspect/check the flight attendant seat.
- B. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
25-21-02-200-801-A ♦	FLIGHT ATTENDANT SEAT - INSPEC-TION	ALL



EMB145 – EMB135

AIRCRAFT  
MAINTENANCE MANUAL

TASK 25-21-02-200-801-A

EFFECTIVITY: ALL

2. FLIGHT ATTENDANT SEAT - INSPECTION

A. General

- (1) The function of this inspection is to make sure that the flight attendant seat operate correctly.

B. Zones and Accesses

Not Applicable

C. Tools and Equipment

Not Applicable

D. Auxiliary Items

Not Applicable

E. Consumable Materials

Not Applicable

F. Expandable Parts

Not Applicable

G. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Passenger cabin

H. Preparation

*SUBTASK 841-002-A*

- (1) To do the detailed inspection of the flight attendant seat, have a direct source of good lighting to make the lighting conditions in the cabin better.


I. Inspect (Detailed Inspection) Flight Attendant Seat harness,Inertial Reel for Condition and the Seat Bottom for Freedom of Movementand Returning Back to Upright Position

*SUBTASK 220-002-A*

- (1) Do a detailed inspection of the flight attendant seat as follows ([Figure 601](#)):

- (a) Examine the seat harness for general conditions, easily seen degradation, damage and failure.
- (b) Examine the harness adjustments.
- (c) Close and open the seat belt two or three times to make sure that it operates correctly.
- (d) Fold out the seat bottom and release it to make sure that it moves freely and goes back to its upright position.

**EFFECTIVITY: ALL**  
 Flight Attendant Seat - Inspection  
 Figure 601



145AMM250054.MCE

