



AIRCRAFT
MAINTENANCE MANUAL

SERVICE DOOR - EXTERNAL - INSPECTION/CHECK

EFFECTIVITY: ALL

1. General

- A. This section gives SMRD Zonal Task 52-Z821-213-001-A00.
- B. Zone: 821.
- C. Zone Boundaries: STA X = 4514.0 thru STA X = 5292.0.
- D. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
05-30-09-200-801-A ♦	SERVICE DOOR - EXTERNAL GENERAL VISUAL INSPECTION	ALL



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL

TASK 05-30-09-200-801-A

EFFECTIVITY: ALL

2. SERVICE DOOR - EXTERNAL GENERAL VISUAL INSPECTION

A. General

- (1) This task gives instructions to done Zonal Task 52-Z821-213-001-A00.
- (2) The external general visual inspection (GVI) of zone 821 must be done within a touching distance of the items examined.
- (3) It is a GVI to find damage, failure, or irregular conditions that can be seen easily.

B. Zones and Accesses

Not Applicable

C. Tools and Equipment

Not Applicable

D. Auxiliary Items

Not Applicable

E. Consumable Materials

Not Applicable

F. Expandable Parts

Not Applicable

G. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Service door

H. Preparation

SUBTASK 841-002-A

- (1) Open the service door.

I. Service Door - External General Visual Inspection ([Figure 601](#))

SUBTASK 212-002-A


- (1) Examine the service door zone for loose rivets, screws, nicks, cracks, dents, erosion, corrosion, deteriorated protective treatment, or deformation ([Figure 601](#)).
- (2) Examine the service door folding flap structure for condition.
- (3) Examine the service door folding flap/rod mechanical linkage.

J. Follow-on

SUBTASK 842-002-A

- (1) Close the service door.

EFFECTIVITY: ALL

 Service Door - External General Visual Inspection
 Figure 601


145AMM050061.MCE A

