



## AIRCRAFT MAINTENANCE MANUAL

### RH WINDSCREEN - REMOVAL/INSTALLATION

EFFECTIVITY: ACFT MODEL(S) EMB-135

#### 1. General

- A. This section gives the procedures to remove/install the RH windscreens assembly.
- B. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
25-27-08-000-801-A	RH WINDSCREEN - REMOVAL	ACFT MODEL(S) EMB-135
25-27-08-400-801-A	RH WINDSCREEN - INSTALLATION	ACFT MODEL(S) EMB-135

**TASK 25-27-08-000-801-A**
**EFFECTIVITY: ACFT MODEL(S) EMB-135**
**2. RH WINDSCREEN - REMOVAL**
**A. General**

- (1) This task gives the procedure to remove the RH windscreens assembly.
- (2) The RH windscreens are installed in the passenger cabin, at zone 232.

**B. References**

<i>REFERENCE</i>	<i>DESIGNATION</i>
AMM TASK 23-13-04-000-801-A/400	-
AMM TASK 23-35-06-000-803-A/400	-
AMM TASK 25-22-04-000-802-A/400	-
<b>AMM TASK 25-27-07-000-801-A/400</b>	GALLEY CURTAIN - REMOVAL

**C. Zones and Accesses**

Not Applicable

**D. Tools and Equipment**

Not Applicable

**E. Auxiliary Items**

Not Applicable

**F. Consumable Materials**

Not Applicable

**G. Expandable Parts**

Not Applicable

**H. Persons Recommended**

<i>QTY</i>	<i>FUNCTION</i>	<i>PLACE</i>
1	Does the task	Passenger cabin

**I. Preparation**
**SUBTASK 841-006-A**

- (1) Make sure that the aircraft is safe for maintenance.
- (2) On the circuit breaker panel, open the following circuit breakers and attach a DO-NOT-CLOSE tag to them.
  - (a) PASS SIGNS (Location Tip: DC BUS 1/LIGHTS/PASS SIGNS).
  - (b) SMOKE DET (Location Tip: DC BUS 1/LAVATORY/SMOKE DET).
  - (c) EMERG (Location Tip: ESSENTIAL DC BUS 2/LIGHTS/EMERG).

- (3) On the overhead panel, set the EMERG LT switch to the OFF position and attach a DO-NOT-MOVE-FROM-OFF tag to it.
- (4) Remove the galley curtain ([AMM TASK 25-27-07-000-801-A/400](#)).
- (5) Remove the service-door region ceiling panel (AMM TASK 25-22-04-000-802-A/400).
- (6) Remove the sealant from the forward portion of the RH windscreens.
- (7) For RH windscreens with handset and cradle, remove them (AMM TASK 23-13-04-000-801-A/400).
- (8) For RH windscreens with video monitor, remove it (AMM TASK 23-35-06-000-803-A/400).

**J. Removal ([Figure 401](#)) ([Figure 402](#))**


**SUBTASK 020-006-A**

- (1) Remove the screws (3) and washers (4) that attach the upper attach bracket (2).
- (2) Remove the screw (6) and washer (7) that attach the RH windscreens (1).
- (3) Remove the screws (5) that attach the RH windscreens (1).
- (4) Remove the RH windscreens (1).

**EFFECTIVITY: RH WINDSCREEN WITHOUT HANDSET AND CRADLE**

RH Windscreen - Removal/Installation

Figure 401




145AMM250270.MCE

**EFFECTIVITY: RH WINDSCREEN WITH HANDSET AND CRADLE**

RH Windscreen - Removal/Installation

Figure 402



145AMM251388.MCE



EMB145 – EMB135

AIRCRAFT  
MAINTENANCE MANUAL

TASK 25-27-08-400-801-A

EFFECTIVITY: ACFT MODEL(S) EMB-135

3. RH WINDSCREEN - INSTALLATION

A. General

- (1) This task gives the procedure to install the RH windscreens assembly.
- (2) The RH windscreens are installed in the passenger cabin, at zone 232.

B. References

REFERENCE	DESIGNATION
AMM TASK 23-13-00-700-801-A/500	-
AMM TASK 23-13-04-400-801-A/400	-
AMM TASK 23-35-06-400-803-A/400	-
AMM TASK 25-22-04-400-802-A/400	-
<b>AMM TASK 25-27-07-400-801-A/400</b>	GALLEY CURTAIN - INSTALLATION
SRM 51-20-01	-

C. Zones and Accesses

Not Applicable

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

SPECIFICATION (BRAND)	DESCRIPTION	QTY
RTV 780 (black)	Sealant	AR

G. Expandable Parts

Not Applicable


H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Passenger cabin

I. Installation (Figure 401) (Figure 402)

**SUBTASK 420-006-A**

- (1) Remove the sealant residues (SRM 51-20-01) from the related area.
- (2) Put the RH windscreens (1) in its installation position.



EMB145 – EMB135

AIRCRAFT  
MAINTENANCE MANUAL

- (3) Install the screws (5) that attach the RH windscreens (1).
- (4) Install the screws (3) and washers (4) that attach the upper attach bracket (2). Make sure that the upper attach bracket (2) is put into the tube hole.
- (5) Install the screw (6) and washer (7) that attach the RH windscreen (1).

J. Follow-on

SUBTASK 842-006-A

- (1) If you remove the handset and the cradle, install them again (AMM TASK 23-13-04-400-801-A/400).
- (2) If you remove the video monitor, install it again (AMM TASK 23-35-06-400-803-A/400).
- (3) Install the service-door region ceiling panel (AMM TASK 25-22-04-400-802-A/400).
- (4) Apply the sealant in the forward portion of the RH windscreens (1) (SRM 51-20-01).
- (5) Install the galley curtain ( [AMM TASK 25-27-07-400-801-A/400](#) ).
- (6) On the circuit breaker panel, close the following circuit breakers and remove the DO-NOT-CLOSE tag from them:
  - (a) PASS SIGNS (Location Tip: DC BUS 1/LIGHTS/PASS SIGNS).
  - (b) SMOKE DET (Location Tip: DC BUS 1/LAVATORY/SMOKE DET).
  - (c) EMERG (Location Tip: ESSENTIAL DC BUS 2/LIGHTS/EMERG).
- (7) On the overhead panel, set the EMERG LT switch to the ARM position and remove the DO-NOT-MOVE-FROM-OFF tag from it.
- (8) For RH wardrobe with handset and cradle, do an operational test on the telephone system (AMM TASK 23-13-00-700-801-A/500).

