



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL

MUFFLER - INSPECTION/CHECK

EFFECTIVITY: ALL

1. General

- A. This section gives the procedures for the inspection/check of the muffler assembly.
- B. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

<i>TASK NUMBER</i>	<i>DESCRIPTION</i>	<i>EFFECTIVITY</i>
38-33-03-200-801-A	MUFFLER ASSEMBLY - INSPECTION	ALL



EMB145 – EMB135

AIRCRAFT
MAINTENANCE MANUAL

TASK 38-33-03-200-801-A

EFFECTIVITY: ALL

2. MUFFLER ASSEMBLY - INSPECTION

A. General

- (1) The function of this inspection is to make sure that there is no damage in the muffler assembly.
- (2) The muffler assembly is installed in the lavatory and is part of the wash-basin drain system.

B. Zones and Accesses

Not Applicable

C. Tools and Equipment

Not Applicable

D. Auxiliary Items

Not Applicable

E. Consumable Materials

Not Applicable

F. Expandable Parts

Not Applicable

G. Persons Recommended




QTY	FUNCTION	PLACE
1	Does the task	Passenger cabin

H. Inspection - Muffler Assembly ([Figure 601](#))

SUBTASK 220-002-A

- (1) To do the inspection of the muffler assembly, have a direct source of good lighting.
Examine the muffler assembly vents for easily seen cracks, damage, and/or blockage of airflow.

EFFECTIVITY: ALL
Muffler Assembly
Figure 601



DET. B

145AMM380035.MCE

