



AIRCRAFT
MAINTENANCE MANUAL

PROTECTIVE BREATHING EQUIPMENT - MAINTENANCE PRACTICES

EFFECTIVITY: ALL

1. General

- A. This section gives the maintenance practices for the PBE (Protective Breathing Equipment).
- B. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

<i>TASK NUMBER</i>	<i>DESCRIPTION</i>	<i>EFFECTIVITY</i>
35-30-03-960-801-A ♦	PROTECTIVE BREATHING EQUIPMENT (PBE) - DISCARD	ALL



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL

TASK 35-30-03-960-801-A

EFFECTIVITY: ALL

2. PROTECTIVE BREATHING EQUIPMENT (PBE) - DISCARD

A. General

- (1) This task gives the maintenance practices for the PBE.

B. Zones and Accesses

Not Applicable

C. Tools and Equipment

Not Applicable

D. Auxiliary Items

Not Applicable

E. Consumable Materials

Not Applicable

F. Expandable Parts

Not Applicable

G. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	In the cockpit and passenger cabin

H. Discard Protective Breathing Equipment (PBE) ([Figure 201](#))

SUBTASK 960-002-A

- (1) Remove the PBE.
- (2) See the manufacture date on the identification plate.
- (3) Discard the PBE, if applicable.
- (4) Install a serviceable PBE.

I. Check/Inspect Protective Breathing Equipment (PBE)



SUBTASK 210-002-A

- (1) Examine the surfaces of the PBE for nicks, cracks, dents, chafed areas, deformation, and the lifetime.
- (2) (For PBE with "Good Indicator"): See the "good indicator" and make sure that it is green.


EFFECTIVITY: ALL

PBE - Discard

Figure 201



DET. A



DET. A

-  FOR PBE WITH "GOOD INDICATOR"
-  FOR PBE WITHOUT "GOOD INDICATOR"
-  ONLY REFER TO THE PBE LOCATION
APPLICABLE TO YOUR CONFIGURATION.

EM145AMM350415A.DGN

