



AIRCRAFT
MAINTENANCE MANUAL

GASEOUS OXYGEN CYLINDER - MAINTENANCE PRACTICES

EFFECTIVITY: ALL

1. General

- A. This section gives the procedure to discard the oxygen generator.
- B. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
35-20-18-960-801-A	GASEOUS OXYGEN CYLINDER - DIS-CARD	POST-MOD SB 145-35-0008



AIRCRAFT
MAINTENANCE MANUAL

TASK 35-20-18-960-801-A

EFFECTIVITY: POST-MOD SB 145-35-0008

2. GASEOUS OXYGEN CYLINDER - DISCARD

A. General

- (1) The function of this procedure is to discard the gaseous oxygen cylinder.

B. References

REFERENCE	DESIGNATION
AMM TASK 35-20-18-000-801-A/400	GASEOUS OXYGEN CYLINDER - REMOVAL
AMM TASK 35-20-18-400-801-A/400	GASEOUS OXYGEN CYLINDER - INSTALLATION

C. Zones and Accesses

Not Applicable

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Dispensing units installed in the lavatory.

I. Discard Gaseous Oxygen Cylinder ([Figure 201](#))

- WARNING:**
- **ALWAYS BE CAREFUL NOT TO ACCIDENTALLY PULL THE LANYARDS OR FIRING PIN OF A OXYGEN CYLINDER NOT USED. THE REMOVAL OF THE FIRING PIN FROM THE OXYGEN CYLINDER WILL START THE FLOW OF OXYGEN AND YOU CANNOT STOP IT UNTIL THE CYLINDER IS EMPTY.**
 - **DO NOT USE OIL AND OTHER PETROLEUM-BASE LUBRICANTS ON THE OXYGEN EQUIPMENT. THIS COULD CAUSE A DANGEROUS FIRE AND BAD INJURY TO PERSONS.**
 - **KEEP ALL SOURCES OF IGNITION (HOT EXHAUST, SPARKS, FLAMES, SMOKING) AWAY FROM THE OXYGEN SERVICING AREA.**

SUBTASK 960-002-A

NOTE: Prepare a clean area and work surface before you start the maintenance procedures.



AIRCRAFT
MAINTENANCE MANUAL


- (1) Get access to the gaseous oxygen cylinder.
- (2) Remove the gaseous oxygen cylinder ([AMM TASK 35-20-18-000-801-A/400](#)).
- (3) Discard the gaseous oxygen cylinder removed in the previous step.
- (4) Install a new gaseous oxygen cylinder ([AMM TASK 35-20-18-400-801-A/400](#)).

NOTE: • Make sure that the safety plug indicator cap is green and that the firing pin is in place for the gaseous oxygen cylinder.
• Make sure that the lifetime date is satisfactory.


EFFECTIVITY: POST-MOD SB 145-35-0008

Discard - Gaseous Oxygen Cylinder

Figure 201



DET. A
TYPICAL



DET. B

EM145AMM350444A.DGN