



**BAGGAGE-COMPARTMENT FIRE EXTINGUISHER SYSTEM TWO-WAY CHECK TEE VALVE -  
ADJUSTMENT/TEST**

*EFFECTIVITY: CLASS-C BAGGAGE COMPARTMENT*

1. General

- A. This section gives the procedures to do the check of the two-way check tee valve.
- B. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
26-23-04-700-801-A ♦	TWO-WAY CHECK TEE VALVE - FUNCTIONAL CHECK	CLASS-C BAGGAGE COMPARTMENT



EMB145 - EMB135

AIRCRAFT  
MAINTENANCE MANUAL

TASK 26-23-04-700-801-A

EFFECTIVITY: CLASS-C BAGGAGE COMPARTMENT

2. TWO-WAY CHECK TEE VALVE - FUNCTIONAL CHECK

A. General

- (1) To do the check, it is necessary to remove the two-way check tee valve.
- (2) To do the task, refer to the instructions in Pacific Scientific Abbreviated CMM.

B. References

REFERENCE	DESIGNATION
AMM MPP 06-41-01/100	-
<a href="#">AMM TASK 26-23-04-000-801-A/400</a>	TWO-WAY CHECK TEE VALVE - REMOVAL
<a href="#">AMM TASK 26-23-04-400-801-A/400</a>	TWO-WAY CHECK TEE VALVE - INSTALLATION
Pacific Scientific Abbreviated CMM ATA 26-21-34	-

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
272	272DR	Electronic compartment

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

ITEM	DESCRIPTION	PURPOSE	QTY
Commercially available	Ladder	To get access to the electronic compartment	1

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Electronic compartment

I. Preparation

SUBTASK 841-002-A

- (1) On the circuit breaker panel, open the BAGGAGE FIRE EXTG circuit breaker and attach a DO-NOT-CLOSE tag to it.
- (2) Put the ladder in the work area.



AIRCRAFT  
MAINTENANCE MANUAL

(3) Open access door 272DR (AMM MPP 06-41-01/100) to get access to the electronic compartment.

(4) Remove the two-way check tee valve ([AMM TASK 26-23-04-000-801-A/400](#)).

J. Functionally Check Two Way Check "Tee" Valve

SUBTASK 720-002-A

(1) Do a check on the two-way check tee valve. Refer to the last revision of the Pacific Scientific Abbreviated CMM ATA 26-21-34.

K. Follow-on

SUBTASK 842-002-A

(1) Install the two-way check tee valve ([AMM TASK 26-23-04-400-801-A/400](#)).

(2) Close access door 272DR (AMM MPP 06-41-01/100).

(3) On the circuit breaker panel, close the BAGGAGE FIRE EXTG circuit breaker and remove the DO-NOT-CLOSE tag from it.

(4) Remove the ladder from the work area.

