

## AIRCRAFT MAINTENANCE MANUAL

### PEDAL ASSEMBLY LINING - REMOVAL/INSTALLATION

EFFECTIVITY: ALL

#### 1. General

- A. This section gives the procedures to remove/install the pedal assembly lining.
- B. The pedal assembly is lined with two equal shrouds. They are attached with camloc fasteners and protected with four lateral strips.
- C. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
25-12-06-000-801-A	PEDAL ASSEMBLY LINING - REMOVAL	ALL
25-12-06-400-801-A	PEDAL ASSEMBLY LINING - INSTALLATION	ALL



EMB145 - EMB135

AIRCRAFT  
MAINTENANCE MANUAL

TASK 25-12-06-000-801-A

EFFECTIVITY: ALL

2. PEDAL ASSEMBLY LINING - REMOVAL

A. General

- (1) This task gives the procedures to remove the pedal assembly lining.

B. Zones and Accesses

Not Applicable

C. Tools and Equipment

Not Applicable

D. Auxiliary Items

Not Applicable

E. Consumable Materials

Not Applicable

F. Expandable Parts

Not Applicable

G. Persons Recommended



QTY	FUNCTION	PLACE
1	Does the task	Cockpit RH/Cockpit LH

H. Removal ([Figure 401](#))

SUBTASK 020-002-A

- (1) Remove the screws (1) that attach the box assembly (2).
- (2) Loosen the camloc fasteners (3) that attach the pedal assembly shroud (4).
- (3) Lift and pull the forward pedal assembly shroud to remove the aft pedal assembly shroud (4).

**EFFECTIVITY: ALL**

 Pedal Assembly Lining - Removal/Installation  
 Figure 401

**DET. B**

145AMM250006.MCE B



AIRCRAFT  
MAINTENANCE MANUAL

TASK 25-12-06-400-801-A

EFFECTIVITY: ALL

3. PEDAL ASSEMBLY LINING - INSTALLATION

A. General

- (1) This task gives the procedures to install the pedal assembly lining.

B. Zones and Accesses

Not Applicable

C. Tools and Equipment

Not Applicable

D. Auxiliary Items

Not Applicable

E. Consumable Materials

Not Applicable

F. Expandable Parts

Not Applicable

G. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Cockpit RH/Cockpit LH

H. Installation (Figure 401)

SUBTASK 420-002-A

- (1) Fit the aft pedal assembly shroud (4) into the floor panel and make sure that the camloc fasteners (3) are in the correct position for installation.
- (2) Attach the box assembly (2) with the screws (1).