



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL

COCKPIT AIR CONDITIONING OUTLETS - INSPECTION/CHECK

EFFECTIVITY: ALL

1. General

- A. This section gives the procedures to inspect the conditioned air outlets in the cockpit.
- B. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

<i>TASK NUMBER</i>	<i>DESCRIPTION</i>	<i>EFFECTIVITY</i>
21-21-02-200-801-A	COCKPIT CONDITIONED AIR OUTLETS - ALL GENERAL VISUAL INSPECTION	



EMB145 – EMB135

AIRCRAFT
MAINTENANCE MANUAL

TASK 21-21-02-200-801-A

EFFECTIVITY: ALL

2. COCKPIT CONDITIONED AIR OUTLETS - GENERAL VISUAL INSPECTION

A. General

- (1) The conditioned air outlets of the cockpit are installed on the sidewall lining and on the ceiling.

B. Zones and Accesses

Not Applicable

C. Tools and Equipment

Not Applicable

D. Auxiliary Items

Not Applicable

E. Consumable Materials

Not Applicable

F. Expandable Parts

Not Applicable

G. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Cockpit

H. General Visual Inspection of Conditioned Air Outlets ([Figure 601](#))



SUBTASK 212-002-A

- (1) Do a visual inspection of the conditioned air outlets in the cockpit for blockage.

EFFECTIVITY: ALL

Cockpit Conditioned Air Outlets - Location

Figure 601



145AMM210068.MCE A

