



AIRCRAFT MAINTENANCE MANUAL

EWIS COMPONENTS IN THE CENTER FUSELAGE III (WING STUB AREA) - INSPECTION/CHECK

EFFECTIVITY: FOR ACFT EMB-145LR/LU/MR/MP/MK/XR AND EMB-135LR/KE/KL MODELS

1. General

- A. This section gives the procedures to do a detailed visual inspection on the EWIS components at center fuselage III (wing stub area), for general conditions.
- B. Zones: 155/156/157/531/541/631/641.
- C. Zone Boundaries (AMM MPP 06-41-01/100 and [AMM MPP 06-44-00/100](#)).
- D. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
05-40-16-200-801-A	EWIS COMPONENTS IN THE CENTER FUSELAGE III (WING TANK UNIT HARNESS) - DETAILED VISUAL INSPECTION	FOR ACFT EMB-145LR/LU/MR/MP/ MK/XR AND EMB-135LR/KE/KL MODELS

TASK 05-40-16-200-801-A

EFFECTIVITY: FOR ACFT EMB-145LR/LU/MR/MP/MK/XR AND EMB-135LR/KE/KL MODELS

2. EWIS COMPONENTS IN THE CENTER FUSELAGE III (WING TANK UNIT HARNESS) - DETAILED VISUAL INSPECTION

A. General

- (1) [AMM TASK 28-41-03-200-801-A/600](#) gives the procedures to do a detailed visual inspection on the EWIS components of the wing tank unit harness, in center fuselage III and wing LH/RH, for general condition.
- (2) The content that formerly was in this task has been moved to [AMM TASK 28-41-03-200-801-A/600](#).

B. References

<i>REFERENCE</i>	<i>DESIGNATION</i>
AMM TASK 28-41-03-200-801-A/600	TANK-UNIT HARNESS ASSEMBLY - INSPECTION

C. Zones and Accesses

Not Applicable

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

Not Applicable

I. Preparation

SUBTASK 841-002-A

- (1) Refer to [AMM TASK 28-41-03-200-801-A/600](#).

J. EWIS Components in the Center Fuselage III (Wing Tank Unit Harness) - Detailed Visual Inspection

SUBTASK 212-002-A

- (1) Refer to [AMM TASK 28-41-03-200-801-A/600](#).

K. Follow-on

SUBTASK 842-002-A

- (1) Refer to [AMM TASK 28-41-03-200-801-A/600](#).