


TABLE OF CONTENTS

<u>PAGEBLOCK</u>	<u>REVISION</u>	<u>REVISION</u>
<u>TASK</u>	<u>STATUS</u>	<u>DATE</u>
53-00-01/400 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> FUSELAGE DRAIN VALVES - REMOVAL/INSTALLATION	U	Oct 30/15
53-00-01-000-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> FUSELAGE DRAIN VALVES - REMOVAL	U	Oct 30/15
53-00-01-400-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> DRAIN VALVES - INSTALLATION	U	Oct 30/15
53-00-01/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> FUSELAGE DRAIN VALVES - REMOVAL/INSTALLATION	U	Oct 30/15
53-00-01-000-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> FUSELAGE DRAIN VALVES - REMOVAL	U	Oct 30/15
53-00-01-400-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> DRAIN VALVES - INSTALLATION	U	Oct 30/15
53-00-01/600 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> FUSELAGE DRAIN VALVES - INSPECTION/CHECK	U	Oct 30/15
53-00-01-200-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> FUSELAGE DRAIN VALVES - INSPECTION	U	Oct 30/15
53-00-01/600 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> FUSELAGE DRAIN VALVES - INSPECTION/CHECK	U	Apr 28/17
53-00-01-200-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> FUSELAGE DRAIN VALVES - INSPECTION	U	Oct 30/15
53-00-02/700 RVSM CRITICAL REGION - CLEANING/PAINTING	U	Oct 30/15
53-00-02-100-801-A RVSM CRITICAL REGION - PAINTING REPAIR PROCESS	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted




EMB145 – EMB135

AIRCRAFT
MAINTENANCE MANUAL

PAGEBLOCK <u>TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
53-01-01/400 COCKPIT FLOOR PANELS - REMOVAL/INSTALLATION	U	Oct 30/15
53-01-01-000-801-A COCKPIT FLOOR PANELS - REMOVAL	U	Oct 30/15
53-01-01-400-801-A COCKPIT FLOOR PANELS - INSTALLATION	U	Oct 30/15
53-01-02/400 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> PASSENGER-CABIN FLOOR PANELS - REMOVAL/INSTALLATION	U	Oct 30/15
53-01-02-000-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> PASSENGER-CABIN FLOOR PANELS - REMOVAL	U	Oct 31/17
53-01-02-400-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> PASSENGER-CABIN FLOOR PANELS - INSTALLATION	U	Oct 31/17
53-01-02/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> PASSENGER-CABIN FLOOR PANELS - REMOVAL/INSTALLATION	U	Oct 30/15
53-01-02-000-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> PASSENGER-CABIN FLOOR PANELS - REMOVAL	U	Oct 31/17
53-01-02-400-802-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> PASSENGER-CABIN FLOOR PANELS - INSTALLATION	U	Oct 31/17
53-01-03/400 BAGGAGE-COMPARTMENT FLOOR PANELS - REMOVAL/INSTALLA-TION	U	Oct 30/15
53-01-03-000-801-A BAGGAGE-COMPARTMENT FLOOR PANELS - REMOVAL	U	Oct 30/15
53-01-03-400-801-A BAGGAGE-COMPARTMENT FLOOR PANELS - INSTALLATION	U	Oct 30/15
53-01-04/400 REAR ELECTRONIC-COMPARTMENT FLOOR PANELS - REMOVAL/INSTALLATION	U	Oct 30/15


Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



AIRCRAFT
MAINTENANCE MANUAL

PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
53-01-04-000-801-A REAR ELECTRONIC-COMPARTMENT FLOOR PANELS - REMOVAL	U	Oct 30/15
53-01-04-400-801-A REAR ELECTRONIC-COMPARTMENT FLOOR PANELS - INSTALLA-TION	U	Oct 30/15
53-01-05/400 COCKPIT SEAT TRACKS - REMOVAL/INSTALLATION	U	Oct 30/15
53-01-05-000-801-A COCKPIT SEAT TRACKS - REMOVAL	U	Oct 30/15
53-01-05-400-801-A COCKPIT SEAT TRACKS - INSTALLATION	U	Oct 30/15
53-01-05/700 COCKPIT SEAT TRACKS - CLEANING/PAINTING	U	Oct 30/15
53-01-05-100-801-A COCKPIT SEAT TRACKS - CLEANING	U	Oct 30/15
53-01-06/400 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> PASSENGER SEAT TRACKS - REMOVAL/INSTALLATION	U	Oct 30/15
53-01-06-000-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> PASSENGER SEAT TRACKS - REMOVAL	U	Oct 31/17
53-01-06-400-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> PASSENGER SEAT TRACKS - INSTALLATION	U	Oct 31/17
53-01-06/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> PASSENGER SEAT TRACKS - REMOVAL/INSTALLATION	U	Oct 30/15
53-01-06-000-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> PASSENGER SEAT TRACKS - REMOVAL	U	Oct 31/17
53-01-06-400-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> PASSENGER SEAT TRACKS - INSTALLATION	U	Oct 31/17

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


PAGEBLOCK <u>TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
53-04-01/200 FORWARD WING-TO-FUSELAGE FAIRING - MAINTENANCE PRACTICES	U	Oct 30/15
53-04-01-960-801-A COVER ASSEMBLY OF ECU-COMPARTMENT ACCESS DOOR ASSEMBLY - REPLACEMENT	U	Oct 30/15
53-04-01/400 FORWARD WING-TO-FUSELAGE FAIRING - REMOVAL/INSTALLATION	U	Oct 30/15
53-04-01-000-801-A FORWARD WING-TO-FUSELAGE FAIRING - REMOVAL	U	Oct 30/15
53-04-01-400-801-A FWD WING-TO-FUSELAGE FAIRING - INSTALLATION	U	Oct 30/15
53-04-02/400 NACA-AIR-INTAKE POLYURETHANE FILM AT THE FORWARD WING-TO-FUSELAGE FAIRING - REMOVAL/INSTALLATION	U	Oct 30/15
53-04-02-000-801-A NACA-AIR-INTAKE POLYURETHANE FILM AT THE FORWARD WING-TO-FUSELAGE FAIRING- REMOVAL	U	Oct 30/15
53-04-02-400-801-A NACA-AIR-INTAKE POLYURETHANE FILM AT THE FORWARD WING-TO-FUSELAGE FAIRING- INSTALLATION	U	Oct 30/15
53-04-02/600 NACA-AIR-INTAKE POLYURETHANE FILM AT THE FORWARD WING-TO-FUSELAGE FAIRING - INSPECTION/CHECK	U	Oct 30/15
53-04-02-200-801-A NACA-AIR-INTAKE POLYURETHANE FILM AT THE FORWARD WING-TO-FUSELAGE FAIRING - INSPECTION/CHECK	U	Oct 30/15
53-04-10/400 CENTER WING-TO-FUSELAGE FAIRING - REMOVAL/INSTALLATION	U	Oct 30/15
53-04-10-000-801-A CENTER WING-TO-FUSELAGE FAIRING - REMOVAL	U	Oct 30/15
53-04-10-400-801-A CENTER WING-TO-FUSELAGE FAIRING - INSTALLATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 53
Page 4 of 13
Rev 55 - Oct 29/18




EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL

PAGEBLOCK <u>TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
53-04-11/400 AERODYNAMIC SEALING BRUSH - REMOVAL/INSTALLATION	U	Oct 30/15
53-04-11-000-801-A AERODYNAMIC SEALING BRUSHES - REMOVAL	U	Oct 30/15
53-04-11-400-801-A AERODYNAMIC SEALING BRUSHES - INSTALLATION	U	Oct 30/15
53-04-20/400 LATERAL WING-TO-FUSELAGE FAIRING - REMOVAL/INSTALLATION	U	Oct 30/15
53-04-20-000-801-A LATERAL WING-TO-FUSELAGE FAIRING - REMOVAL	U	Oct 30/15
53-04-20-400-801-A LATERAL WING-TO-FUSELAGE FAIRING - INSTALLATION	U	Oct 30/15
53-04-30/400 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> REAR WING-TO-FUSELAGE FAIRING - REMOVAL/INSTALLATION	U	Oct 30/15
53-04-30-000-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> REAR WING-TO-FUSELAGE FAIRING - REMOVAL	U	Oct 30/15
53-04-30-400-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> REAR WING-TO-FUSELAGE FAIRING - INSTALLATION	U	Oct 30/15
53-04-30/400 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> REAR WING-TO-FUSELAGE FAIRING - REMOVAL/INSTALLATION	U	Oct 30/15
53-04-30-000-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> REAR WING-TO-FUSELAGE FAIRING - REMOVAL	U	Oct 30/15
53-04-30-400-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> REAR WING-TO-FUSELAGE FAIRING - INSTALLATION	U	Oct 30/15
53-11-01/400 RADOME - REMOVAL/INSTALLATION	U	Oct 30/15
53-11-01-000-801-A RADOME - REMOVAL	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
53-11-01-400-801-A RADOME - INSTALLATION	U	Oct 30/15
53-11-01/500 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> RADOME - ADJUSTMENT/TEST	U	Oct 30/15
53-11-01-820-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> RADOME - ADJUSTMENT	U	Oct 30/15
53-11-01/500 CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> RADOME - ADJUSTMENT/TEST	U	Oct 30/15
53-11-01-820-801-A CONFIG-2 <i>EFFECTIVITY: ACFT MODEL(S) EMB-135</i> RADOME - ADJUSTMENT	U	Oct 30/15
53-11-01/600 RADOME - INSPECTION/CHECK	U	Oct 30/15
53-11-01-200-801-A RADOME MOISTURE - INSPECTION/CHECK	U	Oct 30/15
53-11-02/400 RADOME RUBBER SEAL - REMOVAL/INSTALLATION	U	Oct 30/15
53-11-02-000-801-A RADOME RUBBER SEAL - REMOVAL	U	Oct 30/15
53-11-02-400-801-A RADOME RUBBER SEAL - INSTALLATION	U	Oct 30/15
53-11-03/400 ELECTRONIC-COMPARTMENT ACCESS-DOOR RUBBER SEAL - RE- MOVAL/INSTALLATION	U	Oct 30/15
53-11-03-000-801-A ELECTRONIC-COMPARTMENT ACCESS-DOOR RUBBER SEAL - RE- MOVAL	U	Oct 30/15
53-11-03-400-801-A ELECTRONIC-COMPARTMENT ACCESS-DOOR RUBBER SEAL - IN- STALLATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC


Chapter 53
Page 6 of 13
Rev 55 - Oct 29/18



AIRCRAFT
MAINTENANCE MANUAL

PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
53-11-04/400 ELECTRONIC-COMPARTMENT ACCESS-PANEL RUBBER SEAL - REMOVAL/INSTALLATION	U	Oct 30/15
53-11-04-000-801-A ELECTRONIC-COMPARTMENT ACCESS-PANEL RUBBER SEAL - REMOVAL	U	Oct 30/15
53-11-04-400-801-A ELECTRONIC-COMPARTMENT ACCESS-PANEL RUBBER SEAL - INSTALLATION	U	Oct 30/15
53-11-05/400 RADOME POLYURETHANE FILM - REMOVAL/INSTALLATION	U	Oct 30/15
53-11-05-000-801-A POLYURETHANE FILM - REMOVAL	U	Oct 30/15
53-11-05-400-801-A POLYURETHANE FILM - APPLICATION	U	Oct 30/15
53-11-05-000-802-A <i>EFFECTIVITY: ADDITIONAL POLYURETHANE FILM</i> ADDITIONAL POLYURETHANE FILM - REMOVAL	U	Oct 30/15
53-11-05-400-802-A <i>EFFECTIVITY: ADDITIONAL POLYURETHANE FILM</i> ADDITIONAL POLYURETHANE FILM - APPLICATION	U	Oct 30/15
53-11-05/600 RADOME POLYURETHANE FILM - INSPECTION/CHECK	U	Oct 30/15
53-11-05-200-801-A RADOME POLYURETHANE FILM - INSPECTION/CHECK	U	Oct 30/15
53-11-06/400 CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> NACA-AIR-INTAKE POLYURETHANE FILM AT FORWARD FUSELAGE I - REMOVAL/INSTALLATION	U	Oct 30/15
53-11-06-000-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> NACA-AIR-INTAKE POLYURETHANE FILM AT FORWARD FUSELAGE I - REMOVAL	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
53-11-06-400-801-A CONFIG-1 <i>EFFECTIVITY: ACFT MODEL(S) EMB-145</i> NACA-AIR-INTAKE POLYURETHANE FILM AT FORWARD FUSELAGE I - INSTALLATION	U	Oct 30/15
53-11-06/600 NACA-AIR-INTAKE POLYURETHANE FILM AT FORWARD FUSELAGE I - INSPECTION/CHECK	U	Oct 30/15
53-11-06-200-801-A NACA-AIR-INTAKE POLYURETHANE FILM AT FORWARD FUSELAGE I - INSPECTION/CHECK	U	Oct 30/15
53-11-07/400 ELECTRONIC COMPARTMENT PROTECTIVE DEVICES - REMOVAL/INSTALLATION	U	Oct 30/15
53-11-07-000-801-A ELECTRONIC-COMPARTMENT PROTECTIVE DEVICES - REMOVAL	U	Oct 30/15
53-11-07-400-801-A ELECTRONIC-COMPARTMENT PROTECTIVE DEVICES - INSTALLATION	U	Oct 30/15
53-12-01/400 WINDSHIELD CENTER POST - REMOVAL/INSTALLATION	U	Oct 30/15
53-12-01-000-801-A WINDSHIELD CENTER POST - REMOVAL	R	Oct 29/18
53-12-01-400-801-A WINDSHIELD CENTER POST - INSTALLATION	R	Oct 29/18
53-12-02/400 UPPER AND LOWER SUPPORTS - REMOVAL/INSTALLATION	U	Oct 30/15
53-12-02-000-801-A UPPER AND LOWER SUPPORTS - REMOVAL	R	Oct 29/18
53-12-02-400-801-A UPPER AND LOWER SUPPORTS - INSTALLATION	R	Oct 29/18
53-21-01/200 MAIN-DOOR FRAME RUBBER SEAL - MAINTENANCE PRACTICES	U	Oct 30/15
53-21-01-960-801-A MAIN-DOOR FRAME RUBBER SEAL - REPLACEMENT	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 53
Page 8 of 13
Rev 55 - Oct 29/18




EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL

PAGEBLOCK <u>TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
53-21-01/400 MAIN-DOOR FRAME RUBBER SEAL - REMOVAL/INSTALLATION	U	Oct 30/15
53-21-01-000-801-A MAIN-DOOR FRAME RUBBER SEAL - REMOVAL	U	Oct 30/15
53-21-01-400-801-A MAIN-DOOR FRAME RUBBER SEAL - INSTALLATION	U	Oct 30/15
53-21-01/600 MAIN-DOOR FRAME RUBBER SEAL - INSPECTION/CHECK	U	Oct 31/16
53-21-01-200-801-A FRAME RUBBER SEAL - INSPECTION	U	Oct 30/15
53-21-01/800 MAIN-DOOR FRAME RUBBER SEAL - REPAIR	U	Oct 30/15
53-21-01-300-801-A RUBBER TRIM SEAL - REPAIR	U	Oct 30/15
53-21-02/300 MAIN-DOOR FRAME ROLLERS - SERVICING	U	Oct 30/15
53-21-02-600-801-A MAIN-DOOR FRAME ROLLERS - LUBRICATION	U	Oct 30/15
53-21-02/400 MAIN-DOOR FRAME ROLLERS - REMOVAL/INSTALLATION	U	Oct 30/15
53-21-02-000-801-A MAIN-DOOR FRAME ROLLER SUPPORT - REMOVAL	U	Oct 30/15
53-21-02-400-801-A MAIN-DOOR FRAME ROLLER SUPPORT - INSTALLATION	U	Oct 30/15
53-21-02-000-802-A MAIN-DOOR FRAME ROLLER - REMOVAL	U	Oct 30/15
53-21-02-400-802-A MAIN-DOOR FRAME ROLLER - INSTALLATION	U	Oct 30/15
53-21-02/700 MAIN-DOOR FRAME ROLLERS - CLEANING/PAINTING	U	Oct 30/15
53-21-02-100-801-A MAIN-DOOR FRAME ROLLERS - CLEANING	U	Apr 28/17

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
53-21-03/400 MAIN-DOOR FRAME STOP AND HANDRAIL SUPPORT - REMOVAL/ INSTALLATION	U	Oct 30/15
53-21-03-000-801-A MAIN-DOOR FRAME STOP AND HANDRAIL SUPPORT - REMOVAL	U	Feb 16/16
53-21-03-400-801-A MAIN-DOOR FRAME STOP AND HANDRAIL SUPPORT - INSTALLA- TION	U	Feb 16/16
53-21-04/400 SERVICE-DOOR FRAME STOP - REMOVAL/INSTALLATION	U	Oct 30/15
53-21-04-000-801-A REMOVAL	U	Oct 30/15
53-21-04-400-801-A INSTALLATION	U	Oct 30/15
53-21-05/400 <i>EFFECTIVITY: AIRCRAFT WITH AIRSTAIRS MAIN DOOR</i> AIRSTAIRS MAIN DOOR GUIDES - REMOVAL/INSTALLATION	U	Oct 30/15
53-21-05-000-801-A <i>EFFECTIVITY: AIRCRAFT WITH AIRSTAIRS MAIN DOOR</i> AIRSTAIRS MAIN DOOR GUIDES - REMOVAL	U	Apr 28/17
53-21-05-400-801-A <i>EFFECTIVITY: AIRCRAFT WITH AIRSTAIRS MAIN DOOR</i> AIRSTAIRS MAIN DOOR GUIDES - INSTALLATION	U	Apr 28/17
53-21-06/400 <i>EFFECTIVITY: AIRCRAFT WITH SIDE-HINGED MAIN DOOR</i> SIDE-HINGED MAIN DOOR GUIDES - REMOVAL/INSTALLATION	U	Oct 30/15
53-21-06-000-801-A <i>EFFECTIVITY: AIRCRAFT WITH SIDE-HINGED MAIN DOOR</i> SIDE-HINGED MAIN DOOR GUIDES - REMOVAL	U	Apr 28/17
53-21-06-400-801-A <i>EFFECTIVITY: AIRCRAFT WITH SIDE-HINGED MAIN DOOR</i> SIDE-HINGED MAIN DOOR GUIDES - INSTALLATION	U	Apr 28/17
53-21-07/400 SERVICE DOOR GUIDES - REMOVAL/INSTALLATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC


Chapter 53
Page 10 of 13
Rev 55 - Oct 29/18



AIRCRAFT
MAINTENANCE MANUAL

PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
53-21-07-000-801-A SERVICE DOOR GUIDES - REMOVAL	U	Apr 28/17
53-21-07-400-801-A SERVICE DOOR GUIDES - INSTALLATION	U	Apr 28/17
53-21-11/400 SERVICE DOOR FRAME TRIM RUBBER SEAL - REMOVAL/INSTALLA-TION	U	Oct 30/15
53-21-11-000-801-A SERVICE-DOOR FRAME RUBBER SEAL - REMOVAL	U	Oct 30/15
53-21-11-400-801-A SERVICE-DOOR FRAME RUBBER SEAL - INSTALLATION	U	Oct 30/15
53-21-12/300 SERVICE DOOR FRAME ROLLERS - SERVICING	U	Oct 30/15
53-21-12-600-801-A SERVICE-DOOR FRAME ROLLERS - LUBRICATION	U	Oct 30/15
53-21-12/400 SERVICE DOOR FRAME ROLLERS - REMOVAL/INSTALLATION	U	Oct 30/15
53-21-12-000-801-A SERVICE-DOOR FRAME ROLLER SUPPORT - REMOVAL	U	Oct 30/15
53-21-12-400-801-A SERVICE-DOOR FRAME ROLLER SUPPORT - INSTALLATION	U	Oct 30/15
53-21-12/700 SERVICE DOOR FRAME ROLLERS - CLEANING/PAINTING	U	Oct 30/15
53-21-12-100-801-A SERVICE-DOOR FRAME ROLLERS - CLEANING	U	Oct 30/15
53-21-13/400 <i>EFFECTIVITY: FOR AIRCRAFT WITH PROTECTIVE PLATE INSTALLED</i> SERVICE-DOOR PROTECTIVE PLATE - REMOVAL/INSTALLATION	U	Oct 30/15
53-21-13-000-801-A <i>EFFECTIVITY: FOR AIRCRAFT WITH PROTECTIVE PLATE INSTALLED</i> SERVICE-DOOR PROTECTIVE PLATE - REMOVAL	U	Oct 30/15


Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



AIRCRAFT MAINTENANCE MANUAL

PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
53-21-13-400-801-A <i>EFFECTIVITY: FOR AIRCRAFT WITH PROTECTIVE PLATE INSTALLED SERVICE-DOOR PROTECTIVE PLATE - INSTALLATION</i>	U	Oct 30/15
53-23-03/400 PASSENGER-CABIN ESCAPE HATCH STOP - REMOVAL/INSTALLA- TION	U	Oct 30/15
53-23-03-000-801-A ESCAPE HATCH STOP - REMOVAL	U	Oct 30/15
53-23-03-400-801-A ESCAPE HATCH STOP - INSTALLATION	U	Oct 30/15
53-31-01/400 <i>EFFECTIVITY: FOR AIRCRAFT WITH PROTECTIVE PLATE INSTALLED BAGGAGE-DOOR PROTECTIVE PLATE - REMOVAL/INSTALLATION</i>	U	Oct 30/15
53-31-01-000-801-A <i>EFFECTIVITY: FOR AIRCRAFT WITH PROTECTIVE PLATE INSTALLED BAGGAGE-DOOR PROTECTIVE PLATE - REMOVAL</i>	U	Oct 30/15
53-31-01-400-801-A <i>EFFECTIVITY: FOR AIRCRAFT WITH PROTECTIVE PLATE INSTALLED BAGGAGE-DOOR PROTECTIVE PLATE - INSTALLATION</i>	U	Oct 30/15
53-31-09/400 BAGGAGE DOOR PROTECTOR STRIP - REMOVAL/INSTALLATION	U	Oct 30/15
53-31-09-000-801-A BAGGAGE DOOR PROTECTOR STRIP - REMOVAL	U	Oct 30/15
53-31-09-400-801-A BAGGAGE DOOR PROTECTOR STRIP - INSTALLATION	U	Oct 30/15
53-32-00/400 TAIL CONE - REMOVAL/INSTALLATION	U	Oct 30/15
53-32-00-000-801-A TAIL CONE - REMOVAL	U	Oct 30/15
53-32-00-400-801-A TAIL CONE - INSTALLATION	U	Oct 30/15
53-32-01/800 APU FIREWALL VIBRATION REDUCER - REPAIR	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



AIRCRAFT
MAINTENANCE MANUAL

PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
53-32-01-300-801-A APU FIREWALL VIBRATION REDUCER - REPAIR	U	Oct 30/15
53-32-10/600 RESONATOR - INSPECTION/CHECK	U	Oct 30/15
53-32-10-200-801-A <i>EFFECTIVITY: AIRCRAFT WITH APU EXHAUST SILENCER</i> PERMITTED LIMITS FOR DAMAGE TO RESONATOR - INSPECTION/ CHECK	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 53
Page 13 of 13
Rev 55 - Oct 29/18

