



AIRCRAFT MAINTENANCE MANUAL

ENGINE FIRE EXTINGUISHING BOTTLE CARTRIDGE - MAINTENANCE PRACTICES

EFFECTIVITY: ALL

1. General

- A. This section gives the procedures to replace/discard the cartridges of the engine fire extinguishing bottle.
- B. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
26-21-04-960-801-A ♦	ENGINE-FIRE EXTINGUISHING BOTTLE CARTRIDGES - REPLACEMENT/ DISCARD	ALL



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL

TASK 26-21-04-960-801-A

EFFECTIVITY: ALL

2. ENGINE-FIRE EXTINGUISHING BOTTLE CARTRIDGES - REPLACEMENT/DISCARD

A. General

- (1) To do the task, refer to the instructions in Pacific Scientific CMM 26-20-202.

B. References

REFERENCE	DESIGNATION
AMM TASK 26-21-02-000-801-A/400	ENGINE FIRE-EXTINGUISHING BOTTLE - REMOVAL
AMM TASK 26-21-02-400-801-A/400	ENGINE FIRE-EXTINGUISHING BOTTLE - INSTALLATION
Pacific Scientific CMM 26-20-202	-

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
312	312AR	Tail cone compartment

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

ITEM	DESCRIPTION	PURPOSE	QTY
Commercially available	Ladder	To get access to the tail cone	1

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Tail cone compartment

I. Preparation

SUBTASK 841-002-A

- (1) Remove the engine fire-extinguishing bottle ([AMM TASK 26-21-02-000-801-A/400](#)).



AIRCRAFT
MAINTENANCE MANUAL

J. Discard Engine Fire Extinguishing Bottle Cartridges

SUBTASK 960-002-A

WARNING: THE CARTRIDGES ARE EXPLOSIVE DEVICES. ACCIDENTAL DETONATION OF A CARTRIDGE CAN CAUSE INJURY. DURING THE TASK, OBEY ALL SAFETY PRECAUTIONS GIVEN IN THE PACIFIC SCIENTIFIC CMM.

- (1) Remove and discard the cartridges. Refer to the last revision of Pacific Scientific CMM 26-20-202.
- (2) Install the new cartridges. Refer to the last revision of Pacific Scientific CMM 26-20-202.

K. Follow-on

SUBTASK 842-002-A

- (1) Install the engine fire-extinguishing bottle ([AMM TASK 26-21-02-400-801-A/400](#)).

