



AIRCRAFT MAINTENANCE MANUAL

RADIO MANAGEMENT UNIT - MAINTENANCE PRACTICES

EFFECTIVITY: AIRCRAFT WITH TCAS 2000 AND RMU-965 INSTALLED

1. General

- A. This section gives the procedures to configure the Radio Management Units (RMUs) to permit the operation of TCAS 2000 in a 80/120 NM range.
- B. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

| TASK NUMBER | DESCRIPTION | EFFECTIVITY |
|--------------------|---------------------|---|
| 23-81-01-400-801-A | RMU - CONFIGURATION | AIRCRAFT WITH TCAS 2000 AND RMU-965 INSTALLED |



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL

TASK 23-81-01-400-801-A

EFFECTIVITY: AIRCRAFT WITH TCAS 2000 AND RMU-965 INSTALLED

2. RMU - CONFIGURATION

A. General

- (1) This task gives the procedures to configure RMUs 1 and 2 to operate TCAS 2000 in a 80/120 NM range.

B. References

| REFERENCE | DESIGNATION |
|---------------------------------|--|
| AMM SDS 23-81-00/1 | |
| AMM SDS 34-43-00/1 | |
| AMM TASK 20-40-01-860-801-A/200 | ENERGIZATION OF THE AIRCRAFT WITH AN EXTERNAL POWER SOURCE |

C. Zones and Accesses

| ZONE | PANEL/DOOR | LOCATION |
|---------|------------|----------|
| 223/224 | | Cockpit |

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable


H. Persons Recommended

| QTY | FUNCTION | PLACE |
|-----|---------------|---------|
| 1 | Does the task | Cockpit |

I. Preparation

SUBTASK 841-002-A

- (1) Energize the aircraft with the External DC Power Supply ([AMM TASK 20-40-01-860-801-A/200](#)).
- (2) Make sure that the systems below are operative and on:
- Radio Management System ([AMM SDS 23-81-00/1](#)).
 - TCAS ([AMM SDS 34-43-00/1](#)).



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL

J. RMU - Configuration Procedures ([Figure 201](#))

SUBTASK 220-002-A

- (1) Configure the RMUs to permit TCAS 2000 to operate in the 80/120 NM range as follows:

- (a) On RMU 1, push the PGE function key.

Result:

- 1 The RMU display changes to the System 1 Page Menu.

- (b) Push the line select key adjacent to the MAINTENANCE prompt.

Result:

- 1 The RMU display changes to the Maintenance Data System 1 page.

- (c) Push the line select key adjacent to the SETUP prompt.

Result:

- 1 The RMU display changes to the Setup System 1 page.

NOTE: The TCAS RANGE 80/120 prompt shows "ENABLED", if TCAS 2000 is configured for 80/120 NM range operation, or "DISABLED", if it is not.

- (d) If the TCAS RANGE 80/120 prompt shows " ENABLED", goes to step (f).

- (e) If the TCAS RANGE 80/120 prompt shows " DISABLED", push the line select key adjacent to it.

Result:

- 1 The TCAS RANGE 80/120 shows "ENABLED".

- (f) Push the line select key adjacent to the RETURN prompt.

Result:

- 1 The RMU display changes to the Radio page.



- (2) Do the procedures given above again to configure RMU 2.

K. Follow-on

SUBTASK 842-002-A

- (1) Deenergize the aircraft ([AMM TASK 20-40-01-860-801-A/200](#)).

EFFECTIVITY: AIRCRAFT WITH TCAS 2000 AND RMU-965
 RMU Configuration for TCAS 2000 80/120 NM Range Operation
 Figure 201



1 AIRCRAFT WITH RMU INSTALLED ON CONTROL PEDESTAL

2 AIRCRAFT WITH RMU INSTALLED ON MAIN INSTRUMENT PANEL

145AMM230208.MCE A