



AIRCRAFT MAINTENANCE MANUAL

ENTRANCE PANEL ASSEMBLY - REMOVAL/INSTALLATION

EFFECTIVITY: ALL

1. General

- A. This section gives the procedures for the removal/installation of the entrance panel.
- B. The entrance panel is installed on the cockpit/passenger partition.
- C. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
33-26-01-000-801-A	ENTRANCE PANEL - REMOVAL	ALL
33-26-01-400-801-A	ENTRANCE PANEL - INSTALLATION	ALL



EMB145 – EMB135

AIRCRAFT
MAINTENANCE MANUAL

TASK 33-26-01-000-801-A

EFFECTIVITY: ALL

2. ENTRANCE PANEL - REMOVAL

A. General

- (1) This task gives the procedures for the removal of the entrance panel.

B. Zones and Accesses

Not Applicable

C. Tools and Equipment

Not Applicable

D. Auxiliary Items

Not Applicable

E. Consumable Materials

Not Applicable

F. Expandable Parts

Not Applicable

G. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Passenger Cabin

H. Preparation

SUBTASK 841-002-A


- (1) Make sure that the aircraft is deenergized and that the GPU is not connected to the GPU receptacle.
- (2) On the circuit breaker panel, open the COURTESY LIGHT 1 circuit breaker and attach a DO-NOT-CLOSE tag to it.

I. Removal of the Entrance Panel

SUBTASK 020-002-A

- (1) Remove the two screws (2) which attach the entrance panel (3).
- (2) Pull the entrance panel (3) to get access to the electrical connector (1).
- (3) Disconnect the electrical connector (1).
- (4) Remove the entrance panel (3).

EFFECTIVITY: ALL
Entrance Panel
Figure 401



145AMM330192.MCE



AIRCRAFT
MAINTENANCE MANUAL

TASK 33-26-01-400-801-A

EFFECTIVITY: ALL

3. ENTRANCE PANEL - INSTALLATION

A. General

- (1) This task gives the procedures for the installation of the entrance panel.

B. Zones and Accesses

Not Applicable

C. Tools and Equipment

Not Applicable

D. Auxiliary Items

Not Applicable

E. Consumable Materials

Not Applicable

F. Expandable Parts

Not Applicable

G. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Passenger Cabin

H. Installation of the Entrance Panel

SUBTASK 420-002-A

- (1) Connect the electrical connector (1).
- (2) Put the entrance panel (3) in its installation position.
- (3) Tighten the two screws (2) which attach the entrance panel (3).

I. Follow-on

SUBTASK 842-002-A

- (1) On the circuit breaker panel, close the COURTESY LIGHT 1 circuit breaker and remove the DO-NOT-CLOSE tag from it.