



AIRCRAFT  
MAINTENANCE MANUAL

SERVICE DOOR ELEVATION CAM - SERVICING

EFFECTIVITY: ALL

1. General

- A. The procedure to lubricate the Service Door Elevation Cam is given in [AMM TASK 52-43-00-600-801-A/300](#).

