



AIRCRAFT  
MAINTENANCE MANUAL

**EMERGENCY/PARKING BRAKE HANDLE AND VALVE - SERVICING**

EFFECTIVITY: ALL

1. General

- A. The procedure for the lubrication on the Emergency/Parking Brake Handle and Roller of Emergency/Parking Brake Valve is given in [AMM TASK 32-44-10-600-801-A/300](#).

