



AIRCRAFT MAINTENANCE MANUAL

LAVATORY OCCUPIED SIGN - REMOVAL/INSTALLATION

EFFECTIVITY: ALL

1. General

- A. This section gives the procedures for the removal/installation of the lavatory occupied sign.
- B. The lavatory occupied sign are located in the lavatory, zones 271 and 272.
- C. Attention must be given to safety precautions presented below, when working on the lavatory occupied sign.
 - Disconnect electrical power.
 - Always use insulated tools when working on or near electrical circuits.
- D. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
33-23-07-000-801-A	LAVATORY OCCUPIED SIGN - REMOVAL	ALL
33-23-07-400-801-A	LAVATORY OCCUPIED SIGN - INSTALLA- TION	ALL



AIRCRAFT
MAINTENANCE MANUAL

TASK 33-23-07-000-801-A

EFFECTIVITY: ALL

2. LAVATORY OCCUPIED SIGN - REMOVAL

A. General

- (1) This section gives the procedures for the removal of the lavatory occupied sign.

B. Zones and Accesses

Not Applicable

C. Tools and Equipment

Not Applicable

D. Auxiliary Items

Not Applicable

E. Consumable Materials

Not Applicable

F. Expandable Parts

Not Applicable

G. Persons Recommended

QTY	FUNCTION	PLACE
1	Performs the Task	Passenger Cabin


H. Removal of the Lavatory Occupied Sign ([Figure 401](#))

SUBTASK 020-002-A

- (1) Remove the lens assembly (1) from the housing assembly (3).
- (2) Remove the lamp (2).

EFFECTIVITY: ALL

Lavatory Occupied Sign - Removal/Installation
Figure 401



EM145AMM331023A.DGN



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL

TASK 33-23-07-400-801-A

EFFECTIVITY: ALL

3. LAVATORY OCCUPIED SIGN - INSTALLATION

A. General

- (1) This section gives the procedures for the installation of the lavatory occupied sign.

B. Zones and Accesses

Not Applicable

C. Tools and Equipment

Not Applicable

D. Auxiliary Items

Not Applicable

E. Consumable Materials

Not Applicable

F. Expandable Parts

Not Applicable

G. Persons Recommended

QTY	FUNCTION	PLACE
1	Performs the Task	Passenger Cabin

H. Installation of the Lavatory Occupied Sign (Figure 401)

SUBTASK 420-002-A

- (1) Install the lamp (2).

- (2) Install the lens assembly (1) on the housing assembly (3).