



AIRCRAFT
MAINTENANCE MANUAL

FPMU ASSEMBLY - INSPECTION/CHECK

EFFECTIVITY: ALL

1. General

- A. This section gives the procedure to inspect the Fuel Pump and Metering Unit (FPMU).
- B. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
73-21-00-200-801-A ♦	FUEL PUMP AND METERING UNIT - IN-SPECTION	ALL



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL

TASK 73-21-00-200-801-A

EFFECTIVITY: ALL

2. FUEL PUMP AND METERING UNIT - INSPECTION

A. General

- (1) To do the visual inspection procedure, obey the instructions contained in Rolls-Royce MM CSP 34022.

B. References

REFERENCE	DESIGNATION
AMM MPP 71-00-00/200	- MAINTENANCE PRACTICES
AMM TASK 71-12-01-000-801-A/400	ENGINE LOWER COWLING - OPENING
AMM TASK 71-12-01-400-801-A/400	ENGINE LOWER COWLING - CLOSING
Rolls-Royce MM CSP 34022	-

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
413		LH Engine Lower Cowling
423		RH Engine Lower Cowling

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

ITEM	DESCRIPTION	PURPOSE	QTY
Commercially available	Workstand	To give access to the engine	01

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Engine

I. Preparation

SUBTASK 841-002-A

WARNING: BEFORE YOU DO THE TASK, OBEY THE SAFETY PRECAUTIONS GIVEN IN (AMM MPP 71-00-00/200) TO PREVENT INJURY TO THE PERSONS AND DAMAGE TO THE MATERIAL.



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL

- (1) On the circuit breaker panel, open these circuit breakers and attach a DO-NOT-CLOSE tag to them:
 - START 1/2.
 - PUMPS 1A/1B/1C.
 - PUMPS 2A/2B/2C.
- (2) Put the workstand in the work area.
- (3) Open the lower cowling ([AMM TASK 71-12-01-000-801-A/400](#)) to get access to the engine.

J. Visually Check Fuel Pump and Metering Unit for Fuel Leakage

SUBTASK 211-002-A

- (1) Visually inspect the FPMU for fuel leakage. Refer to the latest revision of Rolls-Royce MM CSP 34022.

K. Follow-on

SUBTASK 842-002-A

- (1) On the circuit breaker panel, close these circuit breakers and remove the DO-NOT-CLOSE tag from them:
 - START 1/2.
 - PUMPS 1A/1B/1C.
 - PUMPS 2A/2B/2C.
- (2) Close the lower cowling ([AMM TASK 71-12-01-400-801-A/400](#)).
- (3) Remove the workstand from work area.

