


TABLE OF CONTENTS

<u>PAGEBLOCK</u>	<u>TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
29-00-01/200	HYDRAULIC FLUID - MAINTENANCE PRACTICES	U	Oct 30/15
29-00-01-910-801-A	HYDRAULIC FLUID - DECONTAMINATION	U	Oct 30/15
29-10-00/200	MAIN HYDRAULIC SYSTEM - MAINTENANCE PRACTICES	U	Oct 30/15
29-10-00-860-801-A	HYDRAULIC SYSTEM - PRESSURIZATION WITH HTS	U	Oct 30/15
29-10-00-860-802-A	HYDRAULIC SYSTEM - PRESSURIZATION WITH EMDP	U	Oct 30/15
29-10-00-860-803-A	HYDRAULIC SYSTEM - BLEED OF AIR	U	Oct 30/15
29-10-00/500	MAIN HYDRAULIC SYSTEM - ADJUSTMENT/TEST	U	Oct 30/15
29-10-00-700-801-A	INTERNAL LEAKAGE OF HYDRAULIC SYSTEM - FUNCTIONAL CHECK	U	Oct 30/15
29-10-00-700-804-A	ELECTRIC MOTOR-DRIVEN PUMP INPUT SIGNALS - OPERATIONAL CHECK	U	Oct 30/15
29-10-00/600	MAIN HYDRAULIC SYSTEM - INSPECTION/CHECK	U	Oct 30/15
29-10-00-200-803-A	HYDRAULIC FLUID - ANALYSIS	U	Oct 30/15
29-10-01/400	SHUTOFF VALVE - REMOVAL/INSTALLATION	U	Oct 30/15
29-10-01-000-801-A	SHUTOFF VALVE - REMOVAL	U	Oct 30/15
29-10-01-400-801-A	SHUTOFF VALVE - INSTALLATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


PAGEBLOCK <u>TASK</u>		<u>REVISION STATUS</u>	<u>REVISION DATE</u>
29-10-01/500	SHUTOFF VALVE - ADJUSTMENT/TEST	U	Oct 30/15
29-10-01-700-801-A	SHUTOFF VALVE - OPERATIONAL CHECK	U	Feb 16/16
29-10-02/400	GSE EXTERNAL COUPLING (PRESSURE SUCTION) - REMOVAL/ INSTALLATION	U	Oct 30/15
29-10-02-000-801-A	GSE EXTERNAL COUPLINGS (PRESSURE/SUCTION) - REMOVAL	U	Oct 30/15
29-10-02-400-801-A	GSE EXTERNAL COUPLINGS (PRESSURE/SUCTION) - INSTALLA- TION	U	Oct 30/15
29-10-02-040-801-A	GSE EXTERNAL COUPLINGS (PRESSURE/SUCTION) - DEACTIVA- TION PROCEDURES	U	Oct 30/15
29-10-02-440-801-A	GSE EXTERNAL COUPLINGS (PRESSURE/SUCTION) - REACTIVA- TION PROCEDURES	U	Oct 30/15
29-10-03/400	ENGINE-DRIVEN PUMP - REMOVAL/INSTALLATION	U	Oct 30/15
29-10-03-000-801-A	EDP - REMOVAL	U	Oct 30/15
29-10-03-400-801-A	EDP - INSTALLATION	U	Oct 30/15
29-10-03/600	ENGINE-DRIVEN PUMP - INSPECTION/CHECK	U	Oct 30/15
29-10-03-200-801-A	EDP - INSPECTION	U	Oct 30/15
29-10-04/200	ELECTRIC MOTOR-DRIVEN PUMP - MAINTENANCE PRACTICES	U	Oct 30/15
29-10-04-900-801-A	ELECTRICAL MOTOR BRUSHES - REPLACE/DISCARD	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 29
Page 2 of 9
Rev 55 - Oct 29/18




AIRCRAFT
MAINTENANCE MANUAL

PAGEBLOCK <u>TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
29-10-04/400 ELECTRIC MOTOR-DRIVEN PUMP - REMOVAL/INSTALLATION	U	Oct 30/15
29-10-04-000-801-A EMDP - REMOVAL	U	Apr 27/18
29-10-04-400-801-A EMDP - INSTALLATION	U	Apr 27/18
29-10-04/500 ELECTRIC MOTOR-DRIVEN PUMP - ADJUSTMENT/TEST	U	Oct 30/15
29-10-04-700-801-A ELECTRIC MOTOR DRIVEN PUMP (EMDP) - OPERATIONAL CHECK	U	Oct 30/15
29-10-05/400 RESERVOIR ASSEMBLY - REMOVAL/INSTALLATION	U	Oct 30/15
29-10-05-000-801-A RESERVOIR ASSEMBLY - REMOVAL	U	Oct 30/15
29-10-05-400-801-A RESERVOIR ASSEMBLY - INSTALLATION	U	Oct 30/15
29-10-06/400 RESERVOIR RELIEF/BLEED VALVE - REMOVAL/INSTALLATION	U	Oct 30/15
29-10-06-000-801-A RESERVOIR RELIEF/BLEED VALVE - REMOVAL	U	Oct 30/15
29-10-06-400-801-A RESERVOIR RELIEF/BLEED VALVE - INSTALLATION	U	Oct 30/15
29-10-06/500 RESERVOIR RELIEF/BLEED VALVE - ADJUSTMENT/TEST	U	Oct 30/15
29-10-06-700-801-A RESERVOIR RELIEF/BLEED VALVE - OPERATIONAL CHECK	U	Oct 30/15
29-10-07/400 MANIFOLD ASSEMBLY - REMOVAL/INSTALLATION	U	Oct 30/15
29-10-07-000-801-A MANIFOLD ASSEMBLY - REMOVAL	U	Oct 30/15
29-10-07-400-801-A MANIFOLD ASSEMBLY - INSTALLATION	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

<u>PAGEBLOCK TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
29-10-08/400 FILTERING ELEMENT (PRESSURE RETURN CASE DRAIN) - REMOV- AL/INSTALLATION	U	Oct 30/15
29-10-08-000-801-A FILTERING ELEMENT - REMOVAL	U	Oct 30/15
29-10-08-400-801-A FILTERING ELEMENT - INSTALLATION	U	Oct 30/15
29-10-08/600 FILTERING ELEMENT (PRESSURE RETURN CASE DRAIN) - INSPEC- TION/CHECK	U	Oct 30/15
29-10-08-200-801-A DIFFERENTIAL PRESSURE INDICATOR - INSPECTION	U	Oct 30/15
29-10-08-210-801-A DIFFERENTIAL PRESSURE INDICATOR - IN-SERVICE - INSPECTION	U	Oct 30/15
29-10-09/400 MANIFOLD CHECK VALVES - REMOVAL/INSTALLATION	U	Oct 30/15
29-10-09-000-801-A MANIFOLD CHECK VALVES - REMOVAL	U	Oct 30/15
29-10-09-400-801-A MANIFOLD CHECK VALVES - INSTALLATION	U	Oct 30/15
29-10-10/400 RETURN FILTER BY-PASS VALVE - REMOVAL/INSTALLATION	U	Oct 30/15
29-10-10-000-801-A RETURN FILTER BY-PASS VALVE - REMOVAL	U	Oct 30/15
29-10-10-400-801-A RETURN-FILTER BY-PASS VALVE - INSTALLATION	U	Oct 30/15
29-10-10/500 RETURN FILTER BY-PASS VALVE - ADJUSTMENT/TEST	U	Oct 30/15
29-10-10-700-801-A RETURN-FILTER BY-PASS VALVE - FUNCTIONAL CHECK	U	Oct 30/15
29-10-11/400 SYSTEM RELIEF VALVE - REMOVAL/INSTALLATION	U	Oct 30/15


Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



AIRCRAFT
MAINTENANCE MANUAL

PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
29-10-11-000-801-A SYSTEM RELIEF VALVE - REMOVAL	U	Oct 30/15
29-10-11-400-801-A SYSTEM RELIEF VALVE - INSTALLATION	U	Oct 30/15
29-10-11/500 SYSTEM RELIEF VALVE - ADJUSTMENT/TEST	U	Oct 30/15
29-10-11-700-801-A SYSTEM RELIEF VALVE - OPERATIONAL CHECK	U	Oct 30/15
29-10-12/400 SAMPLING VALVE (PRESSURE RETURN) - REMOVAL/INSTALLATION	U	Oct 30/15
29-10-12-000-801-A SAMPLING VALVES - REMOVAL	U	Oct 30/15
29-10-12-400-801-A SAMPLING VALVES - INSTALLATION	U	Oct 30/15
29-10-13/400 PRIORITY VALVE - REMOVAL/INSTALLATION	U	Oct 30/15
29-10-13-000-801-A PRIORITY VALVE - REMOVAL	U	Oct 30/15
29-10-13-400-801-A PRIORITY VALVE - INSTALLATION	U	Oct 30/15
29-10-13/500 PRIORITY VALVE - ADJUSTMENT/TEST	U	Oct 30/15
29-10-13-700-801-A PRIORITY VALVE - FUNCTIONAL CHECK	U	Oct 31/16
29-10-14/400 RESERVOIR REFILL CHECK VALVE - REMOVAL/INSTALLATION	U	Oct 30/15
29-10-14-000-801-A RESERVOIR-REFILL CHECK VALVE - REMOVAL	U	Oct 30/15
29-10-14-400-801-A RESERVOIR-REFILL CHECK VALVE - INSTALLATION	U	Oct 30/15


Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



AIRCRAFT MAINTENANCE MANUAL

PAGEBLOCK <u>TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
29-10-14-040-801-A RESERVOIR-REFILL CHECK VALVE - DEACTIVATION PROCEDURES	U	Oct 30/15
29-10-14-440-801-A RESERVOIR-REFILL CHECK VALVE - REACTIVATION PROCEDURES	U	Oct 30/15
29-10-15/400 CASE DRAIN CHECK VALVE (EDP EMDP) - REMOVAL/INSTALLATION	U	Oct 30/15
29-10-15-000-801-A CASE-DRAIN CHECK VALVES (EDP/EMDP) - REMOVAL	U	Oct 30/15
29-10-15-400-801-A CASE-DRAIN CHECK VALVES (EDP/EMDP) - INSTALLATION	U	Oct 30/15
29-10-16/400 PRESSURE EXTERNAL COUPLING CHECK VALVE - REMOVAL/INSTALLATION	U	Oct 30/15
29-10-16-000-801-A CHECK VALVE OF PRESSURE EXTERNAL COUPLING - REMOVAL	U	Oct 30/15
29-10-16-400-801-A CHECK VALVE OF PRESSURE EXTERNAL COUPLING - INSTALLATION	U	Oct 30/15
29-10-16-040-801-A CHECK VALVE OF PRESSURE EXTERNAL COUPLING - DEACTIVATION PROCEDURES	U	Oct 30/15
29-10-16-440-801-A CHECK VALVE OF PRESSURE EXTERNAL COUPLING - REACTIVATION PROCEDURES	U	Oct 30/15
29-10-17/600 TUBING - INSPECTION/CHECK	U	Oct 30/15
29-10-17-200-801-A HYDRAULIC HOSE AND TUBE - INSPECTION	U	Oct 30/15
29-10-19/400 EDP PRESSURE SWITCH - REMOVAL/INSTALLATION	U	Oct 30/15
29-10-19-000-801-A EDP PRESSURE SWITCH - REMOVAL	U	Oct 30/15


Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



AIRCRAFT
MAINTENANCE MANUAL

PAGEBLOCK TASK	REVISION STATUS	REVISION DATE
29-10-19-400-801-A EDP PRESSURE SWITCH - INSTALLATION	U	Oct 30/15
29-10-19-040-801-A EDP PRESSURE SWITCH - DEACTIVATION PROCEDURES	U	Oct 31/16
29-10-19-440-801-A EDP PRESSURE SWITCH - REACTIVATION PROCEDURES	U	Oct 30/15
29-10-20/400 PRESSURE PULSATION DAMPENER - REMOVAL/INSTALLATION	U	Oct 30/15
29-10-20-000-801-A PRESSURE PULSATION DAMPENER - REMOVAL	U	Oct 30/15
29-10-20-400-801-A PRESSURE PULSATION DAMPENER - INSTALLATION	U	Oct 30/15
29-10-22/400 ELECTRIC MOTOR-DRIVEN PUMP CONTACTOR - REMOVAL/INSTALLATION	U	Oct 30/15
29-10-22-000-801-A ELECTRIC MOTOR-DRIVEN PUMP CONTACTOR - REMOVAL	U	Oct 30/15
29-10-22-400-801-A ELECTRIC MOTOR-DRIVEN PUMP CONTACTOR - INSTALLATION	U	Oct 30/15
29-30-01/400 RESERVOIR QUANTITY INDICATOR - REMOVAL/INSTALLATION	U	Oct 30/15
29-30-01-000-801-A RESERVOIR QUANTITY INDICATOR - REMOVAL	U	Oct 30/15
29-30-01-400-801-A RESERVOIR QUANTITY INDICATOR - INSTALLATION	U	Oct 30/15
29-30-01/500 RESERVOIR QUANTITY INDICATOR - ADJUSTMENT/TEST	U	Oct 30/15
29-30-01-700-801-A RESERVOIR QUANTITY INDICATOR (SYSTEM 1) - OPERATIONAL CHECK	U	Oct 30/15
29-30-01-700-802-A RESERVOIR QUANTITY INDICATOR (SYSTEM 2) - OPERATIONAL CHECK	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL


PAGEBLOCK <u>TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
29-30-02/400 PRESSURE TRANSMITTER - REMOVAL/INSTALLATION	U	Oct 30/15
29-30-02-000-801-A PRESSURE TRANSMITTER - REMOVAL	U	Oct 30/15
29-30-02-400-801-A PRESSURE TRANSMITTER - INSTALLATION	U	Oct 30/15
29-30-02/500 PRESSURE TRANSMITTER - ADJUSTMENT/TEST	U	Oct 30/15
29-30-02-700-801-A PRESSURE TRANSMITTER - OPERATIONAL CHECK	U	Oct 30/15
29-30-03/400 HYDRAULIC FILTERS DIFFERENTIAL PRESSURE INDICATORS (DPIS) - REMOVAL/INSTALLATION	U	Oct 31/17
29-30-03-000-801-A DPI - REMOVAL	U	Oct 30/15
29-30-03-400-801-A DPI - INSTALLATION	U	Oct 30/15
29-30-03/500 HYDRAULIC FILTERS DIFFERENTIAL PRESSURE INDICATORS (DPIS) - ADJUSTMENT/TEST	U	Oct 31/17
29-30-03-700-801-A HYDRAULIC FILTERS DIFFERENTIAL PRESSURE INDICATOR (DPIS)- FUNCTIONAL CHECK	U	Feb 16/16
29-30-04/400 EMDP PRESSURE SWITCH - REMOVAL/INSTALLATION	U	Oct 30/15
29-30-04-000-801-A EMDP PRESSURE SWITCH - REMOVAL	U	Oct 30/15
29-30-04-400-801-A EMDP PRESSURE SWITCH - INSTALLATION	U	Oct 30/15
29-30-04-040-801-A EMDP PRESSURE SWITCH - DEACTIVATION PROCEDURES	U	Oct 31/16
29-30-04-440-801-A EMDP PRESSURE SWITCH - REACTIVATION PROCEDURES	U	Oct 30/15

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 29
Page 8 of 9
Rev 55 - Oct 29/18



AIRCRAFT
MAINTENANCE MANUAL

PAGEBLOCK <u>TASK</u>	<u>REVISION STATUS</u>	<u>REVISION DATE</u>
29-30-04/500 EMDP PRESSURE SWITCH - ADJUSTMENT/TEST	U	Oct 30/15
29-30-04-700-801-A EMDP PRESSURE SWITCH - OPERATIONAL CHECK	U	Oct 30/15
29-30-05/400 THERMAL SWITCH - REMOVAL/INSTALLATION	U	Oct 30/15
29-30-05-000-801-A THERMAL SWITCH - REMOVAL	U	Oct 30/15
29-30-05-400-801-A THERMAL SWITCH - INSTALLATION	U	Oct 30/15
29-30-05/500 THERMAL SWITCH - ADJUSTMENT/TEST	U	Oct 30/15
29-30-05-700-801-A THERMAL SWITCH - OPERATIONAL CHECK	U	Feb 16/16

Revision Status: U - Unchanged, R - Revised, N - New, D - Deleted

EMB-145 - AMM 1285

TOC

Chapter 29
Page 9 of 9
Rev 55 - Oct 29/18

