



## AIRCRAFT MAINTENANCE MANUAL

### APRON KEEPER EYEBOLT - INSPECTION/CHECK

EFFECTIVITY: ALL

#### 1. General

- A. This section gives the procedures to do the check of the apron keeper eyebolt.
- B. These procedures are applicable to the LH and RH nacelles.
- C. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
71-13-02-200-801-A	APRON KEEPER EYEBOLT - INSPEC- TION/CHECK	ALL



EMB145 - EMB135

AIRCRAFT  
MAINTENANCE MANUAL

TASK 71-13-02-200-801-A

EFFECTIVITY: ALL

2. APRON KEEPER EYEBOLT - INSPECTION/CHECK

A. General

(1) Obey the instructions below to do the check of the apron keeper eyebolt.

B. References

REFERENCE	DESIGNATION
AMM MPP 71-00-00/200	- MAINTENANCE PRACTICES
AMM TASK 71-12-01-000-801-A/400	ENGINE LOWER COWLING - OPENING
AMM TASK 71-12-01-400-801-A/400	ENGINE LOWER COWLING - CLOSING
AMM TASK 71-13-02-000-801-A/400	APRON KEEPER EYEBOLT - REMOVAL

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
413	Lower cowling	LH engine
423	Lower cowling	RH engine

D. Tools and Equipment

ITEM	DESCRIPTION	PURPOSE	QTY
Commercially available	Workstand	To get access to the engine nacelle	

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Examine the apron keeper eyebolt	LH/RH Engine nacelle



EMB145 – EMB135

AIRCRAFT  
MAINTENANCE MANUAL

I. Preparation

SUBTASK 841-002-A

- WARNING:** • BEFORE YOU DO THE TASK, OBEY THE SAFETY PRECAUTIONS GIVEN IN [AMM MPP 71-00-00/200](#) TO PREVENT INJURY TO PERSONS AND DAMAGE TO MATERIAL.
- DO NOT TOUCH THE ENGINE COMPONENTS UNTIL THEY ARE COOL. TEMPERATURE CAN STAY HOT AFTER THE ENGINE STOPS.

- (1) On the circuit breaker panel, open the circuit breakers below and attach a DO-NOT-CLOSE tag to them:
  - START 1/2.
- (2) Put the workstand in position and get access to the engine nacelle.
- (3) Open the lower cowling ([AMM TASK 71-12-01-000-801-A/400](#)).

J. Inspection/Check (Figure 601)

SUBTASK 211-002-A

- (1) Visually examine the apron keeper eyebolt for signs of corrosion, cracks, damage, or abnormal wear.
- (2) If an incorrect condition is found, remove the apron keeper eyebolt and install a new one ([AMM TASK 71-13-02-000-801-A/400](#)).

K. Follow-on


SUBTASK 842-002-A

- (1) On the circuit breaker panel, close the circuit breakers below and remove the DO-NOT-CLOSE tag from them:
  - START 1/2.
- (2) Close the lower cowling ([AMM TASK 71-12-01-400-801-A/400](#)).
- (3) Remove the workstand from the work area.

**EFFECTIVITY: ALL**

Apron Keeper Eyebolt - Inspection/Check

Figure 601



145AMM710094.MCE A