

P180 Avanti II Quick Reference Handbook

Revision: 03

Date: Friday 22nd May, 2015

NORMAL CHECKLIST

Sections:

PRE-TAXI

TAXI

COLD AND DARK

ENGINE STARTUP

PRE-TAKEOFF

AFTER-TAKEOFF CLIMB

CRUISE FLIGHT LEVEL CHANGE DESCENT

LANDING

AFTER LANDING SHUTDOWN

ABNORMAL CHECKLIST HIGH SPEED LANDING

OVERWEIGHT LANDING LANDING GEAR UNSAFE - FAILURE TO RETRACT

LANDING GEAR UNSAFE - FAILURE TO EXTEND

EMERG CHECKLIST

EMERG - ENGINE FIRE IN FLIGHT

Ι

1.1

1.2

1.3

1.3

1.4

1.4

1.5

1.5

1.5

1.6

1.7

1.7

1.8

ΙI

2.1

2.1

2.2

2.2

III

EMERG - ENGINE FAIL IN FLIGHT

- Intentionally left blank -

P180 II NORMAL CHECKLIST | REV. 03 | 1.01

COLD AND DARK
PARK BRAKE ON
BATTERY ON
BATTERY VOLTAGE CHECK
AVIONICS ON
ANNUNCIATORS TEST PRESS
NAV LIGHT ON
FUEL CALCULATED & REFUELED & CHECKED
ATC CLEARENCE FOR FLIGHT PLAN OBTAINED
FMC SET
RADIOS SET
CABIN PRESSURE SET
V-SPEEDS

NORMAL CHECKLIST

REV. 03 05/22/2015

ENGINE STARTUP
DOORS
FASTEN BELTS SIGNS ON
ATC CLEARENCE FOR ENGINE STARTUP OBTAINED
THROTTLE
BEACON LIGHT ON
FUEL PUMP 1 & 2 ON
For each engine first eng.2 then eng.1: ENGINE AREA

NORMAL CHECKLIST

REV. 03 05/22/2015

PRE-TAXI
INVERTER 1 & 2 ON
WINDOW HEAT ON
PITOT HEAT ON
ENGINE/WING HEAT AS REQ.
AUTOPILOT SET

TAXI
TAXI LIGHT AS REQ.
PARK BRAKE OFF
GROUND SPEED BELOW 20 kt
During taxi:
BARO SET FLAPS MID
TAKEOFF TRIM SET
AUTOBRAKES

NORMAL CHECKLIST

REV. 03 05/22/2015

PRE-TAKEOFF		
ANNUNCIATORS		
FLAPS CHECK		
During lineup:		
LANDING LIGHTS ON STROBE LIGHTS ON		
TRASPONDER TA/RA		
ATC CLEARENCE FOR TAKEOFF OBTAINED		

AFTER-TAKEOFF
GEAR
TAXI LIGHTS OFF
@ 150kt:
FLAPS UP

NORMAL CHECKLIST

REV. 03 05/22/2015

CLIMB
@ 10.000ft / FL100:
PRESSURIZATION CHECK INCREASING IGNITER 1 & 2 OFF LANDING LIGHTS OFF FASTEN BELTS OFF
@ 15.000ft / FL150:
FUEL PUMP 1 & 2 OFF

CRUISE
CONDITION LEVERS SET
AUTOPILOT CHECK
FUEL CHECK

FLIGHT LEVEL CHANGE	
CABINE PRESSURE	SET
CONDITION LEVERS	SET
AUTOPILOT	SET

NORMAL CHECKLIST

REV. 03 05/22/2015

DESCENT
ENGINE HEAT ON
WING HEAT AS REQ.
LANDING WEIGHT CALCULATED
DECISION HEIGHT SET
@ 10.000ft / FL100:
IGNITER 1 & 2 ON FUEL PUMP 1 & 2 ON AUTOBRAKE SET LANDING LIGHTS ON FASTEN BELTS ON
@ 5.000ft / FL050:
ENGINE HEAT
@ 2.000ft:
LANDING GEAR DOWN FLAPS CHECK AS REQ. TAXI LIGHT AS REQ.

NORMAL CHECKLIST

REV. 03 05/22/2015

LANDING
LANDING GEAR DOWN 3 GREEN
FLAPS DOWN
ATC CLEARENCE FOR LANDING OBTAINED

AFTER LANDING
STROBE LIGHTS OFF
TRASPONDER STBY/AS REQ.
FLAPS
WING HEAT OFF
BLEED AIR OFF
IGNITER 1 & 2 OFF
AUTOPILOT OFF

NORMAL CHECKLIST

REV. 03 05/22/2015

SHUTDOWN
PARK BRAKE ON
LANDING & TAXI LIGHT OFF
PITOT HEAT OFF
WINDOW HEAT OFF
INVERTER 1 & 2 OFF
PROP SYNC OFF
For each engine final and 4 hours on 0.
For each engine first eng.1 then eng.2:
ENGINE GENERATOR
ENGINE GENERATOR
ENGINE GENERATOR OFF
ENGINE GENERATOR OFF FUEL VALVE OFF ENGINE IGNITION OFF FUEL PUMP 1 & 2 OFF BEACON LIGHT OFF NAV LIGHT AS REQ.
ENGINE GENERATOR OFF FUEL VALVE OFF ENGINE IGNITION OFF FUEL PUMP 1 & 2 OFF BEACON LIGHT OFF

P180 II	ABNORMAL	CHECKLIST	REV. 03 05/22/2015	2.01
---------	----------	-----------	-----------------------	------

HIGH SPEED LANDING
BRACE
RUDDER
REVERSE FULL JUST BEFORE TOUCHDOWN
BRAKES GENTLY WHEN HIGH SPEED

OVERWEIGHT LANDING

ABNORMAL CHECKLIST

REV. 03 05/22/2015

2.02

HYDRAULIC PRESSURE	CHECK
LDG GEAR HANDLE	DOWN then UP
if landing gear still fails to	retract:
	OFF (DO NOT USE) KEEP DOWN
LANDING GEAR UNSAFE	FAILURE TO EXTEND
LDG GEAR HANDLE	CHECK DOWN
HYDRAULIC PRESSURE	
LDG GEAR HANDLE	UP then DOWN

LDG GEAR HANDLE KEEP DOWN EMERG LDG GEAR HANDLE PULL

if landing gear still fails to extend:

LANDING GEAR UNSAFE - FAILURE TO RETRACT

P180 II EMERG CHECKLIST

REV. 03 05/22/2015

3.01

EMERG - ENGINE FIRE IN FLIGHT If climbing: LEVEL OFF DONE On affected engine: THROTTI F CONDITION LEVER FEATHERED FUEL VALVE OFF IGNITION IGNITER OFF If tank leak suspected: FUEL PUMP (same side engine affected) OFF If fire warning light still on: AFFECTED FNG FIRE BUTTON PRESS BLEED AIR FNG NOT AFFECTED PROP SYNC OFF On affected engine: IGNITER ON LAND ASAP

EMERG CHECKLIST

REV. 03 05/22/2015

EMERG - ENGINE FIRE ON GROUND
ATC
If on runway and situation is safe:
LEAVE RUNWAY DONE
THROTTLE
FUEL VALVE 1 & 2 OFF
IGNITION 1 & 2 OFF
IGNITER 1 & 2 OFF
BLEED AIR OFF
If fire warning light still on: AFFECTED ENG FIRE BUTTON

EMERG CHECKLIST

REV. Ø3 05/22/2015

3.03

EMERG - ENGINE FAIL IN FLIGHT If climbing: LEVEL OFF ATC ADVISED On affected engine: THROTTLE IDLE CONDITION LEVER FEATHERED IGNITER 1 & 2 ON BLEED AIR ENG NOT AFFECTED If no damage suspected, on engine affected, repeat 3 times with interval pauses of 30 s.: FUEL VALVE OFF then ON IGNITION OFF then START (hold 15 s.) ightarrowIf relight OR THROTTLE ADJUST WITH CARE BLEED AIR ightarrowIf NOT relight FUEL VALVE & IGNITION & IGNITER OFF (affected eng) PROP SYNC OFF LAND ASAP LAND ASAP

EMERG CHECKLIST

REV. 03 05/22/2015

EMERG - EVACUATION
AIRPLANE STOP
PARK BRAKE ON
FUEL VALVE 1 & 2 OFF
If any fire suspected:
ENG FIRE BUTTON 1 & 2 ON
BATTERY OFF
PASSENGER/CREW EVACUATE

EMERG - BOMB ON BOARD ATC NOTIFIED DESCENT BELOW FL100 Below FL100: AIRCRAFT DEPRESSURIZED FOREIGN OBJECTS SEARCH If a device is found: PASSANGERS LEAD AWAY FORM BOMB OBJECT: MOVE GENTLY AND MAINTAIN ATTITUDE IMMOBILIZED OBJECT: COVER WITH PLASTIC MATERIAL DONE OBJECT: COVER WITH WET MATERIAL DONE If any fire suspected: ENG FIRE BUTTON 1 & 2 ON BATTERY OFF PASSENGER/CREW EVACUATE