RISC-V REFERENCE

James Zhu <jameszhu@berkeley.edu>

RISC-V Instruction Set

Core Instruction Formats

31 27 26 25	24 20	19	15	14	12	11	7	6	0	
funct7	rs2	rs1		fun	ct3	1	rd	opcode		R-type
imm[11:0]		rs1	rs1		ct3	1	rd	opcode		I-type
imm[11:5]	rs2	rs1		fun	ct3	imm	[4:0]	opcode		S-type
imm[12 10:5]	rs2	rs1		fun	ct3	imm[4:1 11]	opcode		B-type
imm[31:12]							rd	opcode		U-type
im	11 19:12]				1	rd	opcode		J-type	

RV32I Base Integer Instructions

Inst	Name	FMT	Opcode	funct3	funct7	Description (C)	Note
add	ADD	R	0110011	0x0	0x00	rd = rs1 + rs2	
sub	SUB	R	0110011	0x0	0x20	rd = rs1 - rs2	
xor	XOR	R	0110011	0x4	0x00	rd = rs1 ^ rs2	
or	OR	R	0110011	0x6	0x00	rd = rs1 rs2	
and	AND	R	0110011	0x7	0x00	rd = rs1 & rs2	
sll	Shift Left Logical	R	0110011	0x1	0x00	rd = rs1 << rs2	
srl	Shift Right Logical	R	0110011	0x5	0x00	rd = rs1 >> rs2	
sra	Shift Right Arith*	R	0110011	0x5	0x20	rd = rs1 >> rs2	msb-extends
slt	Set Less Than	R	0110011	0x2	0x00	rd = (rs1 < rs2)?1:0	
sltu	Set Less Than (U)	R	0110011	0x3	0x00	rd = (rs1 < rs2)?1:0	zero-extends
addi	ADD Immediate	I	0010011	0x0		rd = rs1 + imm	
xori	XOR Immediate	I	0010011	0x4		rd = rs1 ^ imm	
ori	OR Immediate	I	0010011	0x6		rd = rs1 imm	
andi	AND Immediate	I	0010011	0x7		rd = rs1 & imm	
slli	Shift Left Logical Imm	I	0010011	0x1	imm[5:11]=0x00	rd = rs1 << imm[0:4]	
srli	Shift Right Logical Imm	I	0010011	0x5	imm[5:11]=0x00	rd = rs1 >> imm[0:4]	
srai	Shift Right Arith Imm	I	0010011	0x5	imm[5:11]=0x20	rd = rs1 >> imm[0:4]	msb-extends
slti	Set Less Than Imm	I	0010011	0x2		rd = (rs1 < imm)?1:0	
sltiu	Set Less Than Imm (U)	I	0010011	0x3		rd = (rs1 < imm)?1:0	zero-extends
lb	Load Byte	I	0000011	0x0		rd = M[rs1+imm][0:7]	
lh	Load Half	I	0000011	0x1		rd = M[rs1+imm][0:15]	
lw	Load Word	I	0000011	0x2		rd = M[rs1+imm][0:31]	
lbu	Load Byte (U)	I	0000011	0x4		rd = M[rs1+imm][0:7]	zero-extends
lhu	Load Half (U)	I	0000011	0x5		rd = M[rs1+imm][0:15]	zero-extends
sb	Store Byte	S	0100011	0x0		M[rs1+imm][0:7] = rs2[0:7]	
sh	Store Half	S	0100011	0x1		M[rs1+imm][0:15] = rs2[0:15]	
SW	Store Word	S	0100011	0x2		M[rs1+imm][0:31] = rs2[0:31]	
beq	Branch ==	В	1100011	0x0		if(rs1 == rs2) PC += imm	
bne	Branch !=	В	1100011	0x1		if(rs1 != rs2) PC += imm	
blt	Branch <	В	1100011	0x4		if(rs1 < rs2) PC += imm	
bge	Branch ≥	В	1100011	0x5		if(rs1 >= rs2) PC += imm	
bltu	Branch < (U)	В	1100011	0x6		if(rs1 < rs2) PC += imm	zero-extends
bgeu	Branch \geq (U)	В	1100011	0x7		if(rs1 >= rs2) PC += imm	zero-extends
jal	Jump And Link	J	1101111			rd = PC+4; PC += imm	
jalr	Jump And Link Reg	I	1100111	0x0		rd = PC+4; PC = rs1 + imm	
lui	Load Upper Imm	U	0110111			rd = imm << 12	
auipc	Add Upper Imm to PC	U	0010111			rd = PC + (imm << 12)	
ecall	Environment Call	I	1110011	0x0	imm=0x0	Transfer control to OS	
ebreak	Environment Break	I	1110011	0x0	imm=0x1	Transfer control to debugger	
	1		1	1	1		1

Standard Extensions

RV32M Multiply Extension

Inst	Name	FMT	Opcode	funct3	funct7	Description (C)
mul	MUL	R	0110011	0x0	0x01	rd = (rs1 * rs2)[31:0]
mulh	MUL High	R	0110011	0x1	0x01	rd = (rs1 * rs2)[63:32]
mulsu	MUL High (S) (U)	R	0110011	0x2	0x01	rd = (rs1 * rs2)[63:32]
mulu	MUL High (U)	R	0110011	0x3	0x01	rd = (rs1 * rs2)[63:32]
div	DIV	R	0110011	0x4	0x01	rd = rs1 / rs2
divu	DIV (U)	R	0110011	0x5	0x01	rd = rs1 / rs2
rem	Remainder	R	0110011	0x6	0x01	rd = rs1 % rs2
remu	Remainder (U)	R	0110011	0x7	0x01	rd = rs1 % rs2

RV32A Atomic Extension

31	27	26	25	24	20	19	15	14	12 11	7	6 0			
func	t5	aq	rl	r	s2	rs1		funct3	3 rd opcode		opcode			
5	5 1 1		1		5	5	3		5		7			
Inst	Name			FMT	Opcode	funct3	fun	ct5 I	Description (C)					
lr.w	Load 1	Reserve	ed	R	0101111	0x2	0x0	2 r	rd = M[rs1], reserve M[rs1]					
SC.W	Store	Condit	ional	R	0101111	0x2	0x0	3 i	if (reserved) { M[rs1] = rs2; rd = 0 }					
								e	else { r	d = 1 }				
amoswap.w	Atomi	c Swap)	R	0101111	0x2	0x0	1 r	rd = M[r:	s1]; swap	(rd, rs2); M[rs1] = rd			
amoadd.w	Atomi	c ADD		R	0101111	0x2	0x0	0 r	rd = M[r:	s1] + rs2	; M[rs1] = rd			
amoand.w	Atomi	c AND		R	0101111	0x2	0x0	C r	rd = M[r:	s1] & rs2	; M[rs1] = rd			
amoor.w	Atomi	c OR		R	0101111	0x2	0x0	A rd = M[rs1]		s1] rs2	; M[rs1] = rd			
amoxor.w	Atomi	x XOR		R	0101111	0x2	0x04		rd = M[rs1] ^ rs2; M[rs1] = rd			rd = M[rs1] ^ rs2; M[rs1] = rd		; M[rs1] = rd
amomax.w	Atomi	c MAX		R	0101111	0x2	0x1	4 r	rd = max(M[rs1], rs2); M[rs1] = rd		rs2); M[rs1] = rd			
amomin.w	Atomi	c MIN		R	0101111	0x2	0x1	0 r	rd = min(M[rs1], rs2); M[rs1] = rd					

RV32F / D Floating-Point Extensions

Inst	Name	FMT	Opcode	${ m funct3}$	funct5	Description (C)
flw	Flt Load Word	*				rd = M[rs1 + imm]
fsw	Flt Store Word	*				M[rs1 + imm] = rs2
fmadd.s	Flt Fused Mul-Add	*				rd = rs1 * rs2 + rs3
fmsub.s	Flt Fused Mul-Sub	*				rd = rs1 * rs2 - rs3
fnmadd.s	Flt Neg Fused Mul-Add	*				rd = -rs1 * rs2 + rs3
fnmsub.s	Flt Neg Fused Mul-Sub	*				rd = -rs1 * rs2 - rs3
fadd.s	Flt Add	*				rd = rs1 + rs2
fsub.s	Flt Sub	*				rd = rs1 - rs2
fmul.s	Flt Mul	*				rd = rs1 * rs2
fdiv.s	Flt Div	*				rd = rs1 / rs2
fsqrt.s	Flt Square Root	*				rd = sqrt(rs1)
fsgnj.s	Flt Sign Injection	*				rd = abs(rs1) * sgn(rs2)
fsgnjn.s	Flt Sign Neg Injection	*				rd = abs(rs1) * -sgn(rs2)
fsgnjx.s	Flt Sign Xor Injection	*				rd = rs1 * sgn(rs2)
fmin.s	Flt Minimum	*				rd = min(rs1, rs2)
fmax.s	Flt Maximum	*				rd = max(rs1, rs2)
fcvt.s.w	Flt Conv from Sign Int	*				rd = (float) rs1
fcvt.s.wu	Flt Conv from Uns Int	*				rd = (float) rs1
fcvt.w.s	Flt Convert to Int	*				rd = (int32_t) rs1
fcvt.wu.s	Flt Convert to Int	*				rd = (uint32_t) rs1
fmv.x.w	Move Float to Int	*				rd = *((int*) &rs1)
fmv.w.x	Move Int to Float	*				rd = *((float*) &rs1)
feq.s	Float Equality	*				rd = (rs1 == rs2) ? 1 : 0
flt.s	Float Less Than	*				rd = (rs1 < rs2) ? 1 : 0
fle.s	Float Less / Equal	*				rd = (rs1 <= rs2) ? 1 : 0
fclass.s	Float Classify	*				rd = 09

RV32C Compressed Extension

15 14 13	12	11	10	9	8	7	6	5	4	3	2	1	0	
funct	4		rd/rs1			rs2				О	p	CR-type		
funct3	funct3 imm rd/rs1							imm	1		0	p	CI-type	
funct3		i	mm					rs2				op CSS-type		
funct3			j	mm	1				rd'			0	p	CIW-type
funct3	in	ım			rs1'	'	im	m		rď		0	p	CL-type
funct3	in	imm			rd'/rs1'			imm rs2'			0	p	CS-type	
funct3	in	imm rs1'			'	imm				0	p	CB-type		
funct3	offset						•					0	p	CJ-type

Inst	Name	FMT	OP	Funct	Description
c.lwsp	Load Word from SP	CI	10	010	lw rd, (4*imm)(sp)
c.swsp	Store Word to SP	CSS	10	110	sw rs2, (4*imm)(sp)
c.lw	Load Word	CL	00	010	lw rd', (4*imm)(rs1')
C.SW	Store Word	CS	00	110	sw rs1', (4*imm)(rs2')
c.j	Jump	CJ	01	101	jal x0, 2*offset
c.jal	Jump And Link	CJ	01	001	jal ra, 2*offset
c.jr	Jump Reg	CR	10	1000	jalr x0, rs1, 0
c.jalr	Jump And Link Reg	CR	10	1001	jalr ra, rs1, 0
c.beqz	Branch $== 0$	CB	01	110	beq rs', x0, 2*imm
c.bnez	Branch != 0	CB	01	111	bne rs', x0, 2*imm
c.li	Load Immediate	CI	01	010	addi rd, x0, imm
c.lui	Load Upper Imm	CI	01	011	lui rd, imm
c.addi	ADD Immediate	CI	01	000	addi rd, rd, imm
c.addi16sp	ADD Imm * 16 to SP	CI	01	011	addi sp, sp, 16*imm
c.addi4spn	ADD Imm * 4 + SP	CIW	00	000	addi rd', sp, 4*imm
c.slli	Shift Left Logical Imm	CI	10	000	slli rd, rd, imm
c.srli	Shift Right Logical Imm	CB	01	100x00	srli rd', rd', imm
c.srai	Shift Right Arith Imm	CB	01	100x01	srai rd', rd', imm
c.andi	AND Imm	CB	01	100x10	andi rd', rd', imm
c.mv	MoVe	CR	10	1000	add rd, x0, rs2
c.add	ADD	CR	10	1001	add rd, rd, rs2
c.and	AND	CS	01	10001111	and rd', rd', rs2'
c.or	OR	CS	01	10001110	or rd', rd', rs2'
c.xor	XOR	CS	01	10001101	xor rd', rd', rs2'
c.sub	SUB	CS	01	10001100	sub rd', rd', rs2'
c.nop	No OPeration	CI	01	000	addi x0, x0, 0
c.ebreak	Environment BREAK	CR	10	1001	ebreak

Pseudo Instructions

Pseudoinstruction	Base Instruction(s)	Meaning
la rd, symbol	<pre>auipc rd, symbol[31:12] addi rd, rd, symbol[11:0]</pre>	Load address
l{b h w d} rd, symbol	<pre>auipc rd, symbol[31:12] l{b h w d} rd, symbol[11:0](rd)</pre>	Load global
s{b h w d} rd, symbol, rt	<pre>auipc rt, symbol[31:12] s{b h w d} rd, symbol[11:0](rt)</pre>	Store global
fl{w d} rd, symbol, rt	<pre>auipc rt, symbol[31:12] fl{w d} rd, symbol[11:0](rt)</pre>	Floating-point load global
fs{w d} rd, symbol, rt	<pre>auipc rt, symbol[31:12] fs{w d} rd, symbol[11:0](rt)</pre>	Floating-point store global
nop	addi x0, x0, 0	No operation
li rd, immediate	Myriad sequences	Load immediate
mv rd, rs	addi rd, rs, 0	Copy register
not rd, rs	xori rd, rs, -1	One's complement
neg rd, rs	sub rd, x0, rs	Two's complement
negw rd, rs	subw rd, x0, rs	Two's complement word
sext.w rd, rs	addiw rd, rs, 0	Sign extend word
seqz rd, rs	sltiu rd, rs, 1	Set if = zero
snez rd, rs	sltu rd, x0, rs	Set if \neq zero
sltz rd, rs	slt rd, rs, x0	Set if < zero
sgtz rd, rs	slt rd, rs, xo	Set if > zero
fmv.s rd, rs	fsgnj.s rd, rs, rs	Copy single-precision register
fabs.s rd, rs	fsgnjx.s rd, rs, rs	Single-precision absolute value
fneg.s rd, rs	fsgnjn.s rd, rs, rs	Single-precision absolute value Single-precision negate
fmv.d rd, rs	fsgnj.d rd, rs, rs	Copy double-precision register
fabs.d rd, rs	fsgnjx.d rd, rs, rs	Double-precision absolute value
fneg.d rd, rs	fsgnjn.d rd, rs, rs	Double-precision negate
begz rs, offset	beq rs, x0, offset	Branch if = zero
		Branch if \neq zero
bnez rs, offset	bne rs, x0, offset	•
blez rs, offset	bge x0, rs, offset	Branch if \leq zero
bgez rs, offset	bge rs, x0, offset	Branch if \geq zero
bltz rs, offset	blt rs, x0, offset	Branch if < zero
bgtz rs, offset	blt x0, rs, offset	Branch if > zero
bgt rs, rt, offset	blt rt, rs, offset	Branch if >
ble rs, rt, offset	bge rt, rs, offset	Branch if \leq
bgtu rs, rt, offset	bltu rt, rs, offset	Branch if >, unsigned
bleu rs, rt, offset	bgeu rt, rs, offset	Branch if \leq , unsigned
j offset	jal x0, offset	Jump
jal offset	jal x1, offset	Jump and link
jr rs	jalr x0, rs, 0	Jump register
jalr rs	jalr x1, rs, 0	Jump and link register
ret	jalr x0, x1, 0	Return from subroutine
call offset	<pre>auipc x1, offset[31:12] jalr x1, x1, offset[11:0]</pre>	Call far-away subroutine
tail offset	<pre>auipc x6, offset[31:12] jalr x0, x6, offset[11:0]</pre>	Tail call far-away subroutine
fence	fence iorw, iorw	Fence on all memory and I/O
	· · · · · · · · · · · · · · · · · · ·	<u> </u>

Registers

Register ABI Name		Description	Saver			
x0	zero	Zero constant	_			
x1	ra	Return address	Caller			
x2	sp	Stack pointer	_			
х3	gp	Global pointer	_			
x4	tp	Thread pointer	Callee			
x5-x7	t0-t2	Temporaries	Caller			
x8	s0 / fp	Saved / frame pointer	Callee			
x9	s1	s1 Saved register a0-a1 Fn args/return values				
x10-x11	a0-a1					
x12-x17	a2-a7	Fn args	Caller			
x18-x27	s2-s11	Saved registers	Callee			
x28-x31	t3-t6	Temporaries	Caller			
f0-7	ft0-7	FP temporaries	Caller			
f8-9	fs0-1	FP saved registers	Callee			
f10-11	fa0-1	Caller				
f12-17	fa2-7	FP args	Caller			
f18-27	fs2-11	FP saved registers	Callee			
f28-31	ft8-11	FP temporaries	Caller			