P · 4 · 4 · 1 · 1 · 1	
Práctica 4. Enrutamiento dinán	nia an OSPF
1- Configurar les áreas:	
R1(config) # exter app	R4 (config) # router sept
Pl(config-router)# network 10.0.0.8130 area 1	R4 (config-router) # network 10.0.0.16/30 area 2
R1(config-router) # network 10.0.0.22/30 area 1	R4 (config-router) # network 10.0.0.12   so area 2
R1(config-router)# network 10.1.0.0/24 area 1	R4 (config-router) # network 10.2.1.0 124 area Z
R2 (config) # router expl	RS (onlig) # recter expl
R2 (config-router) # network 10.0.0.22/30 area 1	R5 (config-router) # network 10.0.0.16 30 area 2
R2 (config-router) # network 10.1.1.0/24 area 1	B(config-router)# network 10.2.0.0124 area 2
	\$5 (config-router) # network 10.0.0.24130 area 2
R3 (config) # outer sept	
RS (config-router) # network 10.0.0.8130 and	R6 (config) # router ospf
R3 (config-router) # network 10.0.0.12 30 anea2	R6 (config)# network 10.0.0.4130 area 0
RS (config-router) # network 10.0.0.4130 area0	R6 (config) # network 10.0.0.0130 area 0
RS(config-router) # network 10.0.0.24/30 0000 2	
	opogación de un ruta por defecto
RX (config) # router aspf	(R6(config) # ip rate 0.0.0.0/0 10.0.0.2/50
RX (config-router) H router-id X.X.X.X	R6(confis) # router oxpl
4- Areas tipo stub	(R6(confirmation)# default-information originate
RX(config)# router oxpf (Aplian on R) y R2	>> Propagar rula por defecto nacia el resto de la red
KX(only)# area 1 stub	> tropagas who por dejecto hair d servidos
5- Areas tipo Totally Stub	
R3 (configure-nouter) # anon 1 stub no-summary	
R3 (configure-router) # area Z stub 10-summary	
11.5 ( whighe keep) To allow C SWS 10-SUMMORY	

