```
UF_KF_class_type_t (view source)
```

Defined in: uf_kf.h

Data Members

```
UF_KF_ASK_USER_ONLY = 0
UF_KF_ASK_SYSTEM_ONLY
```

UF_KF_type_t (view source)

UF_KF_ASK_ALL

Defined in: uf_kf.h

Data Members

UF_KF_null = 0

UF_KF_error_type

UF_KF_any

UF_KF_boolean

UF_KF_defeval

UF_KF_frame

A UF MTX4 transformation matrix. All the UF MTX4 functions apply.

UF_KF_tag

This is hostpointer, not NX tag.

UF_KF_integer

UF_KF_list

UF_KF_marker

UF_KF_name

UF_KF_no_value

UF_KF_number

UF_KF_instance

UF_KF_point

UF_KF_string

UF_KF_vector

This is hostpointer, not NX tag.

UF_KF_user